



# SPECTRA VAIL OPERATOR GUIDE



[www.SpectraLogic.com](http://www.SpectraLogic.com)

---

# TABLE OF CONTENTS

Table Of Contents .....	2
Document Information .....	4
Copyright .....	5
Notices .....	5
Trademarks .....	5
Master License Agreement .....	6
Contacting Spectra Logic .....	12
View Capacity Information .....	13
View Performance Metrics .....	16
View Vail Bucket Details .....	18
View Vail Bucket Contents .....	22
View Object Details .....	24
Create an Object Clone .....	27
Verify an Object Clone .....	30
Delete an Object Clone .....	32
Consolidate Storage .....	34
View Lifecycle Details .....	35
View Reports .....	38
View Spectra Vail Application Messages .....	40
Message Details .....	42
Spectra Vail Application Logs .....	43
Accessing the Technical Support Portal .....	44
Create an Account .....	44
Log Into the Portal .....	45
Opening a Support Ticket .....	46
Using the Embedded BlackPearl Dashboard .....	50
View the Status of the BlackPearl System .....	51
View System Overview .....	51
View Notifications .....	52
View Jobs .....	53
View Buckets .....	54
View Pools .....	55

---

View Volumes .....	56
View Tape Partitions - Main View .....	57
View Tape Partitions - Tape State View .....	58
View Tape Drives .....	59
View Tape Management .....	60
Dashboard Actions .....	61
Create a Volume Snapshot .....	61
Export a Tape Cartridge .....	61
Online a Tape Cartridge .....	62
Verify a Tape Cartridge .....	62
Change Job Priority .....	63

---

# DOCUMENT INFORMATION

Documentation part number:

- 90990177

Documentation revision:

Revision	Date	Description
A	September 2024	Initial Release

---

## COPYRIGHT

Copyright © 2022-2024 Spectra Logic Corporation. All rights reserved. This item and the information contained herein are the property of Spectra Logic Corporation.

## NOTICES

Except as expressly stated herein, Spectra Logic Corporation makes its products and associated documentation on an “AS IS” BASIS, WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, BOTH OF WHICH ARE EXPRESSLY DISCLAIMED. In no event shall Spectra Logic be liable for any loss of profits, loss of business, loss of use or data, interruption of business, or for indirect, special, incidental or consequential damages of any kind, even if Spectra Logic has been advised of the possibility of such damages arising from any defect or error.

Information furnished in this manual is believed to be accurate and reliable. However, no responsibility is assumed by Spectra Logic for its use. Due to continuing research and development, Spectra Logic may revise this publication from time to time without notice, and reserves the right to change any product specification at any time without notice.

## TRADEMARKS

ArcticBlue, BlackPearl, BlueScale, RioBroker, Spectra Cube, Spectra Logic, Spectra Vail, Spectra, SpectraGuard, StorCycle, TeraPack, TFinity, and TranScale are registered trademarks of Spectra Logic Corporation. All rights reserved worldwide. All other trademarks and registered trademarks are the property of their respective owners.

---

# MASTER LICENSE AGREEMENT

This Master License Agreement governs use of Spectra Logic Corporation stand-alone software such as StorCycle software ("Software"). Your organization has agreed to the license contained herein and terms and conditions of this Master License Agreement (the "MLA"). Use of the Software is affirmation of your acceptance and grants to your organization ("Licensee") the right to use the Software.

## 1. License.

**1.1 Grant of License.** Subject to all of the terms and conditions of this MLA, Spectra Logic Corporation and its wholly-owned subsidiaries ("Spectra") grant to Licensee a non-transferable, non-sublicensable, non-exclusive license during the applicable Term (as defined below) to use the object code form of the Software specified in the quote supplied either by Spectra or an authorized reseller internally and for operational use, and only in accordance with the technical specification documentation generally made available by Spectra to its licensees with regard to the Software ("Documentation"). The term "Software" will include any Documentation and any ordered Support and maintenance releases of the same specific Software product provided to Licensee under this MLA.

**1.2 Term and Renewals.** The Software is licensed under a subscription basis or is permanently licensed, as defined herein. Licensee's Software license is stated on the quote provided to Licensee.

(a) If the Software is ordered on a subscription basis ("Subscription"), the term of the software license will (i) commence upon receipt of a purchase order issued to Spectra directly from Licensee or from an authorized reseller issued on your behalf and will (ii) continue for the number of year(s) noted on the quote commencing on the date of activation of key(s) performed by Spectra Professional Services ("Subscription Term"). Unless terminated earlier in accordance with section 4, each Software Subscription Term will automatically renew upon expiration of the initial Software Subscription Term for additional successive terms unless either party gives the other prior written notice of cancellation at least thirty (30) days prior to expiration of the then-current term. Unless otherwise specified on the quote, the license fee for any Software Subscription Term renewal will be based on the then-current Subscription rates.

(b) If the Software is ordered on a permanent license basis ("Permanent"), the term of the software license will not expire except in accordance with section 4. The term of associated products such as support, user, server and storage elections will commence upon on the date of activation of key(s) performed by Spectra Professional Services and may be renewed at such time as the term of such quoted election(s) expire.

**1.3 Installation.** Software may be installed on Licensee's computers only by Licensee's employees, authorized resellers, or by Spectra Professional Services as requested by Licensee.

**1.4 License Restrictions.** Licensee shall not (and shall not allow any third party) to

(a) decompile, disassemble, or otherwise reverse engineer the Software or attempt to reconstruct or discover any source code, underlying ideas, algorithms, file formats or programming interfaces of the Software by any means whatsoever (except and only to the extent that applicable law prohibits or restricts reverse engineering restrictions, and then only with prior written notice to Spectra), (b) distribute, sell, sublicense, rent, lease or use the Software (or any portion thereof) for time sharing, hosting, service provider or like purposes, (c) remove any product identification, proprietary, copyright or other notices contained in the Software, (d) modify any part of the Software, create a derivative work of any part of the Software, or incorporate the Software into or with other software, except to the extent expressly authorized in writing by Spectra, or (e) publicly disseminate Software performance information or analysis (including, without limitation, benchmarks).

---

## 2. Ownership.

Notwithstanding anything to the contrary contained herein, except for the limited license rights expressly provided herein, Spectra retains all rights, title and interest in and to the Software (including, without limitation, all patent, copyright, trademark, trade secret and other intellectual property rights) and all copies, modifications and derivative works thereof. Licensee acknowledges that it is obtaining only a limited license right to the Software and that irrespective of any use of the words "purchase", "sale" or like terms hereunder no ownership rights are being conveyed to Licensee under this MLA or otherwise.

## 3. Payment and Delivery.

**3.1 Payment.** All payments, either to Spectra or an authorized reseller, are non-refundable (except as expressly set forth in this MLA). Unless otherwise specified on the applicable quote, all license fees, support and Professional Services fees, if any, are due within thirty (30) days of date of invoice. Licensee shall be responsible for all taxes, withholdings, duties and levies arising from the order (excluding taxes based on the net income of Spectra). Any late payments shall be subject to a service charge equal to 1.5% per month of the amount due or the maximum amount allowed by law, whichever is less.

**3.2 Delivery.** Immediately upon receipt of a purchase order from Licensee or on behalf of Licensee or from an authorized reseller on behalf of Licensee, Licensee will have the right to access the Software. Software will be delivered by electronic means unless otherwise specified on the applicable quote. Spectra will contact Licensee and request its server identification number(s) and provide Activation code(s).

## 4. Term of MLA.

### 4.1 Term.

(a)(i) If Licensee ordered a Software Subscription License, this MLA expires on the day the Term of the Software expires. However, the ability to retrieve/restore archived data will continue indefinitely.

(ii) If a Permanent Software License was ordered, the software license does not expire.

(b) Section 4.1(a) is subordinate to this section 4.1(b). Either party may terminate this MLA if the other party (a) fails to cure any material breach of this MLA within thirty (30) days after written notice of such breach, (b) ceases operation without a successor; or (c) seeks protection under any bankruptcy, receivership, trust deed, creditors arrangement, composition or comparable proceeding, or if any such proceeding is instituted against such party (and not dismissed within sixty (60) days thereafter). Termination is not an exclusive remedy and the exercise by either party of any remedy under this MLA will be without prejudice to any other remedies it may have under this MLA, by law, or otherwise.

**4.2 Survival.** Sections 1.4 (License Restrictions), 2 (Ownership), 3 (Payment and Delivery), 4 (Term of MLA), 5.3 (Disclaimer), 8 (Limitation of Remedies and Damages), 10 (Confidential Information), 11 (General), and Licensee's right to Work Product and ownership of Licensee Content described in Section 7 shall survive any termination or expiration of this MLA.

---

## 5. Limited Warranty and Disclaimer.

**5.1 Limited Warranty.** Spectra warrants to Licensee that for a period of ninety (90) days from the effective date (the "Warranty Period"), the Software shall operate in substantial conformity with the Documentation. In addition, Spectra warrants that (i) it has the right to enter into and perform all obligations under this MLA, (ii) no agreement exists that restricts or conflicts with the performance of Spectra's rights and obligation hereunder, (ii) the technical information provided to Licensee is accurate and complete, and (iv) the Software is free from any third-party intellectual property infringement claims. Spectra does not warrant that Licensee's use of the Software will be uninterrupted or error-free, will not result in data loss, or that any security mechanisms implemented by the Software will not have inherent limitations. Spectra's sole liability (and Licensee's exclusive remedy) for any breach of this warranty shall be, in Spectra's sole discretion, to use commercially reasonable efforts to provide Licensee with an error-correction or work-around which corrects the reported non-conformity, to replace the non-conforming Software with conforming Software, or if Spectra determines such remedies to be impracticable within a reasonable period of time, to terminate the Software license and refund the license fee and support fee, if any, paid for the non-conforming Software. Spectra shall have no obligation with respect to a warranty claim unless notified of such claim within the Warranty Period.

**5.2 Exclusions.** The above warranty will not apply (a) if the Software is used with hardware or software not specified in the Documentation, (b) if any modifications are made to the Software by Licensee or any third party, (c) to defects in the Software due to accident, abuse or improper use by Licensee, or (d) to items provided on a no charge or evaluation basis.

**5.3 Disclaimer.** THIS SECTION 5 CONTAINS A LIMITED WARRANTY AND EXCEPT AS EXPRESSLY SET FORTH IN THIS SECTION 5 THE SOFTWARE AND ALL SERVICES ARE PROVIDED "AS IS". NEITHER SPECTRA NOR ANY OF ITS SUPPLIERS MAKES ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE. LICENSEE MAY HAVE OTHER STATUTORY RIGHTS. HOWEVER, TO THE FULL EXTENT PERMITTED BY LAW, THE DURATION OF STATUTORILY REQUIRED WARRANTIES, IF ANY, SHALL BE LIMITED TO THE LIMITED WARRANTY PERIOD.

## 6. Support.

Spectra will provide the support services identified in the quote ("Support"). Support services for the Subscription License will coincide with the license term.

## 7. Professional Services.

**7.1 Professional Services.** Professional Services may be ordered by Licensee pursuant to a quote describing the work to be performed, fees and any applicable milestones, dependencies and other technical specifications or related information. The parties acknowledge that the scope of the Professional Services provided hereunder consists solely of either or both of (a) assistance with Software installation, deployment, and usage or (b) development or delivery of additional related Spectra copyrighted software or code. Spectra shall retain all right, title and interest in and to any such work product, code or software and any derivative, enhancement or modification thereof created by Spectra (or its agents) ("Work Product").

**7.2 Licensee Content.** Licensee grants Spectra a limited right to use any Licensee materials provided to Spectra in connection with the Professional Services (the "Licensee Content") solely for the purpose of performing the Professional Services for Licensee. Licensee owns and will retain ownership (including all intellectual property rights) in the Licensee Content.



---

## **8. Limitation of Remedies and Damages.**

**8.1** NEITHER PARTY SHALL BE LIABLE FOR ANY LOSS OF USE, LOST DATA, FAILURE OF SECURITY MECHANISMS, INTERRUPTION OF BUSINESS, OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND (INCLUDING LOST PROFITS), REGARDLESS OF THE FORM OF ACTION, WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY OR OTHERWISE, EVEN IF INFORMED OF THE POSSIBILITY OF SUCH DAMAGES IN ADVANCE.

**8.2** NOTWITHSTANDING ANY OTHER PROVISION OF THIS MLA, SPECTRA'S AND AUTHORIZED RESELLER'S, IF ANY, ENTIRE LIABILITY TO LICENSEE SHALL NOT EXCEED THE AMOUNT ACTUALLY PAID BY LICENSEE UNDER THIS MLA.

**8.3** THIS SECTION 8 SHALL NOT APPLY WITH RESPECT TO ANY CLAIM ARISING UNDER THE SECTIONS TITLED "GRANT OF LICENSE," "LICENSE RESTRICTIONS" OR "CONFIDENTIAL INFORMATION."

## **9. Indemnification.**

(a) Spectra shall defend, indemnify and hold harmless Licensee from and against any claim of infringement of a patent, copyright, or trademark asserted against Licensee by a third party based upon Licensee's use of the Software in accordance with the terms of this MLA, provided that Spectra shall have received from Licensee (i) prompt written notice of such claim (but in any event notice in sufficient time for Spectra to respond without prejudice), (ii) the exclusive right to control and direct the investigation, defense, and settlement (if applicable) of such claim, and (iii) all reasonably necessary cooperation of Licensee.

(b) If Licensee's use of any of the Software is, or in Spectra's opinion is likely to be, enjoined due to the type of infringement specified above, or if required by settlement, Spectra may, in its sole discretion (i) substitute for the Software substantially functionally similar programs and documentation, (ii) procure for Licensee the right to continue using the Software, or if (i) and (ii) are commercially impracticable, (iii) terminate the MLA and refund to Licensee the license fee.

(c) The foregoing indemnification obligation of Spectra shall not apply if the Software is modified by any person other than Spectra, but solely to the extent the alleged infringement is caused by such modification, if the Software is combined with other non-Spectra products or process not authorized by Spectra, but solely to the extent the alleged infringement is caused by such combination, to any unauthorized use of the Software, to any unsupported release of the Software, or to any open source software or other third-party code contained within the Software. THIS SECTION 9 SETS FORTH SPECTRA'S AND RESELLER'S, IF ANY, SOLE LIABILITY AND LICENSEE'S SOLE AND EXCLUSIVE REMEDY WITH RESPECT TO ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT.

---

## 10. Confidential Information.

Each party agrees that all code, inventions, know-how, business, technical and financial information it obtains ("Receiving Party") from the disclosing party ("Disclosing Party") constitute the confidential property of the Disclosing Party ("Confidential Information"), provided that it is identified as confidential at the time of disclosure or should be reasonably known by the Receiving Party to be Confidential Information due to the nature of the information disclosed and the circumstances surrounding the disclosure. Any software, documentation or technical information provided by Spectra (or its agents), performance information relating to the Software, and the terms of this MLA shall be deemed Confidential Information of Spectra without any marking or further designation. Except as expressly authorized herein, the Receiving Party will hold in confidence and not use or disclose any Confidential Information except as necessary to carry out the purpose of this MLA. The Receiving Party's nondisclosure obligation shall not apply to information which the Receiving Party can document (a) was rightfully in its possession or known to it prior to receipt of the Confidential Information, (b) is or has become public knowledge through no fault of the Receiving Party, (c) is rightfully obtained by the Receiving Party from a third party without breach of any confidentiality obligation, (d) is independently developed by employees of the Receiving Party who had no access to such information, or (e) is required to be disclosed pursuant to a regulation, law or court order (but only to the minimum extent required to comply with such regulation or order and with advance notice to the Disclosing Party). The Receiving Party acknowledges that disclosure of Confidential Information would cause substantial harm for which damages alone would not be a sufficient remedy, and therefore that upon any such disclosure by the Receiving Party the Disclosing Party shall be entitled to appropriate equitable relief in addition to whatever other remedies it might have at law.

## 11. General.

**11.1 Assignment.** This MLA will bind and inure to the benefit of each party's permitted successors and assigns. Neither party shall assign this MLA (or any part thereof) without the advance written consent of the other party, except that either party may assign this MLA in connection with a merger, reorganization, acquisition or other transfer of all or substantially all of such party's assets or voting securities. Any attempt to transfer or assign this MLA except as expressly authorized under this section 11.1 is null and void.

**11.2 Severability.** If any provision of this MLA shall be adjudged by any court of competent jurisdiction to be unenforceable or invalid, that provision shall be limited to the minimum extent necessary so that this MLA shall otherwise remain in effect.

**11.3 Governing Law; Jurisdiction and Venue.** This MLA shall be governed by the laws of the State of Colorado and the United States without regard to conflicts of laws provisions thereof, and without regard to the United Nations Convention on the International Sale of Goods. Except where statutory laws prohibit Licensee from entering into arbitration or choice of laws, any dispute or claim relating in any way to Licensee's use of the Software, or of a copyright issue, or to any associated support services, will be resolved by binding arbitration in Denver, Colorado. The prevailing party in any action to enforce this MLA will be entitled to recover its attorneys' fees and costs in connection with such action.

**11.4 Amendments; Waivers.** No supplement, modification, or amendment of this MLA shall be binding, unless executed in writing by an authorized representative of both parties. No waiver will be implied from conduct or failure to enforce or exercise rights under this MLA. No provision of any purchase order or other business form employed by Licensee will supersede the terms and conditions of this MLA, and any such document relating to this MLA shall be for administrative purposes only and shall have no legal effect.

---

**11.5 Force Majeure.** Neither party shall be liable to the other for any delay or failure to perform any obligation under this MLA (except for a failure to pay fees) if the delay or failure is due to events which are beyond the reasonable control of such party, including but not limited to any strike, blockade, war, act of terrorism, riot, natural disaster, failure or diminishment of power or of telecommunications or data networks or services, or refusal of approval or a license by a government agency.

**11.6 Export Compliance.** Licensee acknowledges that the Software is subject to export restrictions by the United States government and import restrictions by certain foreign governments. Licensee shall not and shall not allow any third-party to remove or export from the United States or allow the export or re-export of any part of the Software or any direct product thereof (a) into (or to a national or resident of) any embargoed or terrorist-supporting country, (b) to anyone on the U.S. Commerce Department's Table of Denial Orders or U.S. Treasury Department's list of Specially Designated Nationals, (c) to any country to which such export or re-export is restricted or prohibited, or as to which the United States government or any agency thereof requires an export license or other governmental approval at the time of export or re-export without first obtaining such license or approval, or (d) otherwise in violation of any export or import restrictions, laws or regulations of any United States or foreign agency or authority. Licensee agrees to the foregoing and warrants that it is not located in, under the control of, or a national or resident of any such prohibited country or on any such prohibited party list. The Software is further restricted from being used for the design or development of nuclear, chemical, or biological weapons or missile technology, or for terrorist activity, without the prior permission of the United States government.

**11.7 Third-Party Code.** The Software may contain or be provided with components subject to the terms and conditions of third party "open source" software licenses ("Open Source Software"). Open Source Software may be identified in the Documentation, or Spectra shall provide a list of the Open Source Software for a particular version of the Software to Licensee upon Licensee's written request. To the extent required by the license that accompanies the Open Source Software, the terms of such license will apply in lieu of the terms of this MLA with respect to such Open Source Software.

**11.8 Entire Agreement.** This MLA is the complete and exclusive statement of the mutual understanding of the parties and supersedes and cancels all previous written and oral agreements and communications relating to the subject matter contained herein.

## **Amazon Web Services**

If Licensee has licensed Software for use in conjunction with Amazon Web Services, such web services will be provided by Amazon in accordance with its standard terms and conditions. SPECTRA MAKES NO WARRANTY REGARDING AMAZON SERVICES AND SUGGESTS THE USE OF AMAZON'S CONTINUOUS DATA BACK UP SERVICES.

# CONTACTING SPECTRA LOGIC

<b>To Obtain General Information - Spectra Logic Website: <a href="http://www.spectrallogic.com">www.spectrallogic.com</a></b>	
<b>United States Headquarters</b>	<b>European Office</b>
Spectra Logic Corporation 6285 Lookout Road Boulder, CO 80301 USA	Spectra Logic Europe Ltd. 329 Doncastle Road Bracknell Berks, RG12 8PE United Kingdom
<b>Phone:</b> 1.800.833.1132 or 1.303.449.6400 <b>International:</b> 1.303.449.6400 <b>Fax:</b> 1.303.939.8844	<b>Phone:</b> 44 (0) 870.112.2150 <b>Fax:</b> 44 (0) 870.112.2175
<b>Spectra Logic Technical Support Technical Support Portal: <a href="http://support.spectrallogic.com">support.spectrallogic.com</a></b>	
United States and Canada - Phone <b>Toll free US and Canada:</b> 1.800.227.4637 <b>International:</b> 1.303.449.0160	Europe, Middle East, Africa <b>Phone:</b> 44 (0) 870.112.2185 Deutsch Sprechende Kunden <b>Phone:</b> 49 (0) 6028.9796.507 <b>Email:</b> spectrallogic@stortrec.de
Mexico, Central and South America, Asia, Australia, and New Zealand <b>Phone:</b> 1.303.449.0160	
<b>Spectra Logic Sales Website: <a href="http://shop.spectrallogic.com">shop.spectrallogic.com</a></b>	
United States and Canada <b>Phone:</b> 1.800.833.1132 or 1.303.449.6400 <b>Fax:</b> 1.303.939.8844 <b>Email:</b> sales@spectrallogic.com	Europe <b>Phone:</b> 44 (0) 870.112.2150 <b>Fax:</b> 44 (0) 870.112.2175 <b>Email:</b> eurosales@spectrallogic.com
<b>To Obtain Documents - Spectra Logic Website: <a href="http://support.spectrallogic.com/documentation">support.spectrallogic.com/documentation</a></b>	

# VIEW CAPACITY INFORMATION


The Capacity page allows you to see data capacity information for the Spectra Vail® sphere endpoints, each configured location, and cloud storage.

**Note:** Capacity values for BlackPearl storage display zeros until data is written to the storage.

In the Vail management console taskbar, click **Capacity**.

The Capacity screen is separated into three sections:


- The **Sphere Endpoint Physical Capacity** pane displays the combined total of all configured BlackPearl, Vail VM node, and cloud storage endpoints.



**Figure 1** The Sphere Endpoint Physical Capacity pane.

Field	Description
<b>Storage</b>	The type of storage.
<b>Used</b>	The amount of space used for each storage type.
<b>Optional</b>	The amount of space used by the optional clones. There is a delay before this field is populated after creating storage.
<b>Available</b>	The available space used for each storage type. <b>Note:</b> Available capacity does not account for capacity used by file system overhead.


- The **Location Capacity** pane displays data capacity information for each configured location. Buttons in the top left of the pane allow you to view information for each location.



**Figure 2** The Location Capacity pane.

Field	Description
<b>Storage</b>	The name of the location.
<b>Type</b>	The type of storage used for each location. <b>Tape</b> - Storage on tape media on a BlackPearl system. <b>Volume</b> - Storage on disk volume storage on a BlackPearl system.
<b>Storage Class</b>	The storage class used by the storage location.
<b>Partitions</b>	The BlackPearl data partition(s) that are used for storage.
<b>Used</b>	The amount of space used for each location.
<b>Optional</b>	The amount of space used for optional object clones.
<b>Available</b>	The available space used for each location. BlackPearl storage is over-provisioned, and may be used by multiple storage endpoints. <b>Note:</b> Available capacity does not account for capacity used by file system overhead.

- 
- The **Cloud Capacity** pane displays aggregated data capacity information for each type of storage class used by cloud endpoints.




**Figure 3** The Cloud Capacity pane.

# VIEW PERFORMANCE METRICS

The Performance page displays data transfer and operation performance for the Vail sphere and all configured endpoints. The performance graphs display information in five minute or one day intervals.

In the Vail management console taskbar, click **Performance**.




**Figure 4** The Performance screen.

- Use the **Endpoint** drop-down menu to select an endpoint for any graph on the Performance screen.
- Use the **Graph Type** drop-down menu to select which graph to display.
- Use the **Length** drop-down menu to select between intervals of five minutes or one day.
- Toggle the **Refresh** slider to refresh the display.



- To display the exact time and performance information, **mouseover** any point on a graph.



**Figure 5** The Operations graph - mouseover.


# VIEW VAIL BUCKET DETAILS

The buckets detail screen displays information about the selected Vail bucket, including bucket properties, ACLs, and policy.

Here is how to view the details of a Vail bucket:


1. In the Vail management console taskbar, click **Buckets**.
2. Under the **Buckets** banner, select a bucket row, then click the **View Details** icon on the right side of the pane.

**Note:** If you click the bucket name instead of the bucket row, the Bucket Contents pane displays. See [View Vail Bucket Contents](#) on page 22.



**Figure 6** The Buckets pane.

3. Click **Properties**, **Usage**, **ACLs**, or **Policy** to view the current Vail bucket settings.



**Figure 7** The Bucket Details - Properties screen.

- If you click **Properties...**

<b>Field</b>	<b>Description</b>
<b>Owner</b>	The AWS Canonical ID of the Vail bucket owner. By default the Vail sphere administrator is the bucket owner.
<b>Linked Storage</b>	The name of the bucket on the BlackPearl system or AWS cloud storage location to which the Vail bucket is linked, if applicable.
<b>Versioning</b>	Indicates if versioning is enabled or disabled for the Vail bucket.
<b>Object Locking</b>	Indicates if object locking is enabled or disabled for the Vail bucket.
<b>Encryption</b>	Indicates if encryption is enabled or disabled for the Vail bucket
<b>Compression</b>	Indicates if compression is enabled or disabled for the Vail bucket.
<b>Hide Glacier Operations</b>	Indicates if hiding glacier operations is enabled or disabled for the Vail bucket.
<b>Object Ownership</b>	Indicates the type of object ownership configured for the bucket
<b>Lifecycle</b>	The lifecycle associated with the Vail bucket.
<b>Creation date</b>	The date the Vail bucket was created.
<b>Default Retention Mode</b>	Indicates if default retention mode is enabled or disabled for the Vail bucket
<b>Default Retention Period</b>	The retention time period configured for the bucket.

- If you click **Usage...**

Field	Description
<b>Number of Objects</b>	The number of objects currently in the bucket.
<b>Total Size of Objects</b>	The current size of all objects in the bucket, in GiB.
<b>Average Object Size</b>	The current average size of the objects in the bucket, in GiB.

- If you click **ACLs....**

Field	Description
<b>Block Public ACLs</b>	Indicates if the Vail bucket blocks public ACLs.
<b>Ignore Public ACLs</b>	Indicates if the Vail bucket allows public ACLs.
<b>AWS Canonical ID</b>	The ID of a users configured with ACL permissions for the Vail bucket.
<b>Permissions</b>	The ACL permission level for the user.

- If you click **Policy...**

Field	Description
<b>Block Public Policy</b>	Indicates if the Vail bucket blocks or allows public policies.
<b>Restrict Public Buckets</b>	Indicates if the Vail bucket blocks or allows public buckets.
<b>Policy</b>	The AWS policy information entered when the bucket was created displays.


4. Click the **X** in the upper-right corner to close the window.

# VIEW VAIL BUCKET CONTENTS

The buckets contents screen displays all objects in a Vail bucket. If versioning is enabled for the bucket, other versions of the current object can also be viewed.

Here is how to view the contents of a Vail bucket:


1. In the Vail management console taskbar, click **Buckets**.



**Figure 8** The Buckets screen.

2. Under the **Buckets** banner, click a **bucket name**.


**Note:** You must click the name directly. Clicking the row of the bucket does not display the bucket contents screen.



**Figure 9** The Bucket Contents screen.

- Use the **Find objects by prefix** entry field to filter objects.

- Click **Show All Versions** to display every object version in the Vail bucket. The Last Modified field displays the day and time the object was uploaded.




**Figure 10** The Bucket Contents - Show All Versions screen.

3. Click **Buckets** in the upper-left corner of the pane to return to the Buckets screen.

## View Object Details

On the Bucket Details screen, **click the row** of an object to view its details. By default, the **Properties** pane displays.



10testfiletape	
PROPERTIES	STORAGE
Version	7YFM058G2164T3GCSM6GWP8B9G
Size	5.1 KiB
Owner	vail.test
Storage class	STANDARD
Last modified	Sep 02, 2022 1:27:02 PM
Restored until	--
Legal hold	--
Retention mode	--
Retain until	--

**Figure 11** The Object Details - Properties screen.


Field	Description
<b>Version</b>	The UUID for the current version of the object.
<b>Size</b>	The object size on the storage target.
<b>Owner</b>	The AWS account name of the owner of the object.
<b>Storage Class</b>	The current storage class for the object.
<b>Last Modified</b>	The last modified date of the object.



---

<b>Field</b>	<b>Description</b>
<b>Restored Until</b>	The timestamp of when the object expires.
<b>Legal Hold</b>	Indicates if the object has a legal hold.
<b>Retention Mode</b>	Indicates the retention mode.
<b>Retain Until</b>	The duration that the object is retained by a legal hold.

Click **Storage** to display the current storage information for the object.



**Figure 12** The Object Details - Storage screen.


Field	Description
<b>Lifecycle Status</b>	Indicates what Lifecycle-based changes are scheduled for the object.
<b>Storage</b>	The name of the storage endpoint where the object is stored. If the object is 256 bytes or less after compression, it is stored in the application database and not on a storage endpoint. The storage field is blank when the object is stored in the database.
<b>Attributes</b>	<b>Archived</b> - The object is archived and must be restored in order to be accessed. <b>Restored</b> - The object is restored can be accessed.
<b>Storage Class</b>	The current storage class for the object.
<b>Optional</b>	If yes, the clone is deleted when space is required.

# CREATE AN OBJECT CLONE

If desired, you can delete a clone of an object in a Vail bucket using the Vail management console. You can only create an object clone if the object does not exist on all storage targets. You cannot have multiple clones on the same storage target.

Here is how to create an object clone using the Vail management console:


1. In the Vail management console taskbar, click **Buckets**.



**Figure 13** The Buckets screen.


2. Under the **Buckets** banner, click a **bucket name**.

**Note:** You must click the name directly. Clicking the row of the bucket does not display the bucket contents screen.



**Figure 14** The Bucket Contents screen.


3. If necessary, click **Show All Versions** to display every object version in the Vail bucket. The Last Modified field displays the day and time the object was uploaded.



**Figure 15** The Bucket Contents - Show All Versions screen.

4. **Click** the row of the object you want to clone. The Object Properties window displays.


5. Click the **Storage** tab.



**Figure 16** The Object Details - Storage screen.

6. Select the row of the object (1), and click **Create** (2).

7. Using the **Select Storage** drop-down menu, select a location to create the object clone.




**Figure 17** The Create Object Clone screen.

8. Click **Submit** on the confirmation screen to create an object clone.

# VERIFY AN OBJECT CLONE

Here is how to verify an object clone using the Vail management console:


1. In the Vail management console taskbar, click **Buckets**.



**Figure 18** The Buckets screen.


2. Under the **Buckets** banner, click a **bucket name**.

**Note:** You must click the name directly. Clicking the row of the bucket does not display the bucket contents screen.




**Figure 19** The Bucket Contents screen.

3. If necessary, click **Show All Versions** to display every object version in the Vail bucket. The Last Modified field displays the day and time the object was uploaded.



**Figure 20** The Bucket Contents - Show All Versions screen.

4. Click the row of the clone you want to delete. The Object Properties window displays.
5. Click **Storage**.



**Figure 21** The Object Details - Storage screen.

6. Select the row of the clone (1), and click **Verify** (2).
7. Click **Submit** on the confirmation screen to verify the object clone.

# DELETE AN OBJECT CLONE

If desired, you can delete a clone of an object in a Vail bucket using the Vail management console. You can only delete an object if another clone of the object exists elsewhere in the Vail sphere. If there is only one instance of the object in the sphere, it cannot be deleted.

Here is how to delete an object clone using the Vail management console:

1. In the Vail management console taskbar, click **Buckets**.




Figure 22 The Buckets screen.

2. Under the **Buckets** banner, click a **bucket name**.

**Note:** You must click the name directly. Clicking the row of the bucket does not display the bucket contents screen.





Figure 23 The Bucket Contents screen.




3. If necessary, click **Show All Versions** to display every object version in the Vail bucket. The Last Modified field displays the day and time the object was uploaded.



**Figure 24** The Bucket Contents - Show All Versions screen.

4. Click the row of the clone you want to delete. The Object Properties window displays.
5. Click **Storage**.




**Figure 25** The Object Details - Storage screen.

6. Select the row of the clone (1), and click **Delete** (2).
7. Click **Delete** on the confirmation screen to delete the object clone.

# CONSOLIDATE STORAGE

Here is how you consolidate storage:

1. In the Vail management console taskbar, click **Storage**.
2. Under the **Endpoint Storage** or banner, (1) select the row of the storage, and (2) click **Consolidate**.



**Figure 26** The Endpoint Storage pane.


3. On the confirmation screen, click **Consolidate**.

# VIEW LIFECYCLE DETAILS

The lifecycles detail screen displays information about the selected lifecycle, including all lifecycle properties and rules.

Here is how to view the details of a lifecycle:


1. In the Vail management console taskbar, click **Lifecycles**.
2. Under the **Lifecycles** banner, click the **View Details** icon on the right side of the pane for the lifecycle which you want to view details.



**Figure 27** The Lifecycles pane.

3. Click **Properties** or **Rules** to view the current lifecycle settings. Click the **X** in the upper-right corner to close the window.


- The Properties screen:



**Figure 28** The Lifecycle Rule Details - Properties screen.

Field	Description
<b>Description</b>	The text, if any, entered in the Description field when creating the bucket.
<b>Upload Expiration</b>	The number of days that must pass before a multipart upload is aborted. When a multipart upload is aborted, it deletes all parts associated with the upload, which prevents remaining incomplete uploads from being stored.
<b>Marker Expiration</b>	Indicates if the Delete Marker Expiration option is <b>Enabled</b> or <b>Disabled</b> .
<b>Modified</b>	The date and time the lifecycle was last modified.

- The Rules screen:




**Figure 29** The Lifecycle Rule Details - Rules screen.

Field	Description
<b>Name</b>	The name of the lifecycle.
<b>Type</b>	The type of lifecycle rule. <b>Values:</b> Clone, Move, Expiration.
<b>Apply After</b>	The number of days before the lifecycle rule is applied.
<b>Destinations - Count</b>	The number of destinations configured for the lifecycle. <b>Values:</b> 1-5, All.
<b>Destinations - Storage</b>	The storage endpoint(s) used by the lifecycle.
<b>Destinations - Delete</b>	Whether or not the lifecycle is configured to delete clones on storage destinations that are not configured in the lifecycle.
<b>Filters - Versions</b>	The versioning setting configured for the lifecycle.
<b>Filters - Include</b>	The text string used to filter objects to include in storage operations.
<b>Filters - Exclude</b>	The text string used to filter objects to exclude from storage operations.

# VIEW REPORTS

The Reports screen allows you to view any existing audit logs for the Spectra Vail application, and detailed information for each audit log.

- In the Vail management console taskbar, click **Reports**.




**Figure 30** The Reports screen.

- Use the **User Name**, **Start Date**, or **End Date** menus to refine the list of audit logs.

**Note:** Not all audit logs contain a User Name.

- Click the **View Details** icon on the right end of each audit log row to view details about the audit log.



**Figure 31** The Audit Logs details screen.

Option	Description
<b>Description</b>	The description of the audit log.
<b>User</b>	The user associated with the log.
<b>Request Path</b>	The API path for the log.
<b>Request Method</b>	The method by which the log was generated.
<b>Request Data</b>	The contents of the log.
<b>Request Timestamp</b>	The time and date the log was generated.
<b>Resource ID</b>	The ID of the resource associated with the log.
<b>Resource Name</b>	The name of the resource associated with the log.
<b>Host IP</b>	The IP address of the Vail sphere.
<b>Client IP</b>	The IP address of the BlackPearl system or Vail VM node associated with the log.
<b>Server</b>	The name of the resource within the Vail sphere.


---

# VIEW SPECTRA VAIL APPLICATION MESSAGES

Spectra Vail application messages provide important information about the status and current functionality of the Vail sphere. If desired, you can configured sphere administrators to receive messages automatically.

Here is how to view messages:


In the upper right corner of the management console, click the **bell icon**. The value to the left of the icon indicate the number of unread messages.



**Figure 32** The Bell icon.



The messages screen displays. Any unread messages are shown in bold font.




**Figure 33** The Messages screen.

- To view message details, on the right end of the message row, click the **View Details** icon (1).
- You can sort messages using the **Minimum Severity**, **Start Date**, **End Date**, and **Read Status** drop-down menus (2).
- You can search messages for a text string by typing in the **Search** field (3).
- To download messages to your local host, in the upper-right corner of the Messages pane, click the **disk icon** (4).
- To mark all messages as read, in the upper-right corner of the Messages pane, click the **check mark icon** (5).

## Message Details

In addition to the information on the Messages screen, the message details pane also displays the message key.



**Figure 34** The Message Details screen.

Field	Description
<b>ID</b>	The ID value of the message.
<b>Severity</b>	The severity of the message. <b>Info</b> - an event occurred such as a successful firmware update of the Vail sphere. <b>Warning</b> - An event that may affect data transfers occurred, such as the Vail sphere detects a down-level firmware version. <b>Error</b> - An event that prevents data transfers occurred, such as the nonavailability of a storage endpoint.
<b>Description</b>	The message description.
<b>Key</b>	The message key. This value is useful when using the REST API to gather messages.
<b>Time</b>	The date and time the message was generated.

# SPECTRA VAIL APPLICATION LOGS

Use the Logs page to generate and download logs for use in troubleshooting problems with the Vail sphere.

In the upper right corner of the Vail management console, click the **gear icon** and select **Logs**.



**Figure 35** The Logs screen.

- To download an existing logset, select the row of the logset and click **Download**.
- To delete an existing logset, select the row of the logset and click **Delete**.

# ACCESSING THE TECHNICAL SUPPORT PORTAL


The Spectra Logic® Technical Support portal provides access to the Knowledge Base, the current version of Vail software, and additional service and support tools. You can also open or update a support incident and upload log files.

## Create an Account

Access to *User Guides* and compatibility matrices does not require you to create an account. You must create a user account and log in to access *Release Notes*, to download the latest version of Vail software, or to open a support incident.


**Note:** If you have multiple Spectra Logic products, the serial numbers for all products will be associated with your account. If you do not see the serial numbers for all of your products when you log in, contact Technical Support (see [Contacting Spectra Logic](#)).

1. Access the Technical Support portal login page at [support.spectralogic.com](http://support.spectralogic.com).
2. On the home page, click **Register Now**.



**Figure 36** The Spectra Logic Technical Support portal home page.

- 
3. Enter your registration information. Your account is automatically associated with the serial numbers of all Spectra Logic products owned by your site.
    - If you have an invitation, follow the link and enter the invitation code.



The image shows a web form titled "Signup". It contains two columns of input fields. The left column includes: "First Name" (text input), "Last Name" (text input), "Email Address" (text input), and "Phone" (text input). The right column includes: "Preferred Method of Contact" (dropdown menu with "Any" selected), "Company Name" (text input), "Account Type" (dropdown menu with "Customer" selected), and "Serial Number" (text input). A red "Submit" button is located at the bottom left of the form.

**Figure 37** The Signup screen.

- If you do not have an invitation, enter the requested information to create your account. When you are finished, click **Submit**.

When the account is approved, you receive an email with an initial password. Use your email address and the password provided in the email to log in to your account. After you log in, you can change your password if desired.


## Log Into the Portal

1. Access the Technical Support portal login page at [support.spectralogic.com](https://support.spectralogic.com).
2. Use your email address and password to log into the Technical Support Portal.

# OPENING A SUPPORT TICKET

You can open a support incident using the Spectra Logic Technical Support portal or telephone.

- To contact Spectra Logic Technical Support by telephone, see [Contacting Spectra Logic](#).
- Use the following instructions to open a support incident through the portal:




**Figure 38** The Spectra Logic Technical Support portal home page.

1. Make notes about the problem, including what happened just before the problem occurred.
2. Gather the following information:
  - Your Spectra Logic customer number
  - Company name, contact name, phone number, and email address
  - The software serial number
  - Type of host system being used
  - Type and version of host operating system being used
  - Type and version of host storage management software being used
1. Access the Technical Support portal login page at [support.spectralogic.com](https://support.spectralogic.com).
2. If necessary, log in to the Support Portal by clicking **Login**, enter your **email address** and **password**, and click **Log in**.

**Note:** See [Create an Account on page 44](#) if you have not previously created an account on the Technical Support portal.


3. Submit a support incident.

- Use the following instructions to search for help before submitting a ticket, or skip to [Submit an Incident Directly](#) on page 49.
  - i. From any page, select **Incident>Incidents & Inventory**.



**Figure 39** Select **Incidents>Incidents & Inventory**.

ii. Select **Open or View Incidents**.



**Figure 40** Select **Open or View Incidents**.

- iii. In the Search dialog box, enter a term or phrase about your problem (1) and click **Search** (2).




Figure 41 Enter a search phrase and click **Search**.

- iv. If the search does not provide an answer, click **Open a New Incident**.





Figure 42 Click **Open a New Incident**.

- v. Continue with Step 4 on page 49.



- Submit an Incident Directly
  - i. From any page, select **Inventory>My Inventory**.
  - ii. Locate the row of the product for which you want to submit an incident and click **Create Incident**.



**Figure 43** Click **Create Incident**.

- iii. Continue with Step 4 on page 49.
4. On the Create Incident page, enter the requested information providing as much detail as possible. When you are finished, click **Submit**.


The screenshot shows the 'Create Incident' form with the following fields:

- Severity:
- Problem Description:
- Email addresses to include in correspondence:
- Customer:
- Product:
- Select files...:
- DELIVERY Address For Shipping Parts:
- Confirm The Ship To Address
- 

**Figure 44** Enter information about your incident and click **Submit**.

# USING THE EMBEDDED BLACKPEARL DASHBOARD

The embedded BlackPearl® dashboard allows you to quickly view the status of critical aspects of a BlackPearl system in the Vail sphere, and easily perform commonly used functions of the system.




**Figure 45** The Embedded Dashboard.

# VIEW THE STATUS OF THE BLACKPEARL SYSTEM

Use the sections below to view the status of multiple aspects of the BlackPearl system.

## View System Overview


The Overview pane provides a quick look at the most critical aspects of the BlackPearl system.



**Figure 46** The Overview pane.

1. The BlackPearl system cache capacity and percentage of used cache space.
2. The capacity of the BlackPearl system database and percentage of used space.
3. The capacity of all disk-based storage connected to the BlackPearl system and percentage of used space.
4. The capacity of all tape-based storage in the tape library connected to the BlackPearl system and percentage of used space.
5. The number of active jobs running on the BlackPearl system.


Mouse-over the green section of any percentage graph to display the amount of used space, and over the gray section to display the amount of remaining space.



**Figure 47** Mouse-over a graph to view specific details.


## View Notifications

Notifications provide information about errors that occur on the system, caution messages that alert you to issues that may impact your workflow, and informational messages. Additionally, notifications may provide troubleshooting advice to help you resolve issues that may occur.



**Figure 48** The Notifications pane.

1. Use the **Notification Type** buttons to switch between OK, Info, Warning, and Error messages.
2. Contains a brief description of the notification.
3. Displays the timestamp the notification was generated.
4. Click the **Details Button** to view additional message **Details** and **Troubleshooting Advice**.



**Figure 49** The Notification details dialog box.

## View Jobs

The Jobs pane provides information on each Active, Canceled, or Completed job processed by the BlackPearl system.

2	3	4	5	6		7
Name	Bucket	Request Type	Priority	Original Size	Amount Transferred to Cache	Created
PUT by 127.0.0.1	Spectra-BlackPearl-Backup-sm4u-21-50030480018b8b3f	PUT	Normal	6.61 MiB	6.61 MiB	August 24, 2023 9:00 pm
PUT by 127.0.0.1	Spectra-BlackPearl-Backup-sm4u-21-50030480018b8b3f	PUT	Normal	5.25 MiB	5.25 MiB	August 23, 2023 9:00 pm
PUT by 127.0.0.1	Spectra-BlackPearl-Backup-sm4u-21-50030480018b8b3f	PUT	Normal	6.1 MiB	6.1 MiB	August 22, 2023 9:00 pm
PUT by 10.5.2.130	g	PUT	Normal	1000 MiB	1000 MiB	August 22, 2023 12:38 pm
PUT by 127.0.0.1	Spectra-BlackPearl-Backup-sm4u-21-50030480018b8b3f	PUT	Normal	5.4 MiB	5.4 MiB	August 21, 2023 9:00 pm
PUT by 10.5.2.130	SpectraApp1	PUT	Normal	4.35 MiB	4.35 MiB	August 21, 2023 2:46 pm
PUT by 10.5.2.130	d	PUT	Normal	3 GiB	3 GiB	August 21, 2023 2:46 pm
PUT by 10.5.2.130	e	PUT	Normal	25 MiB	25 MiB	August 21, 2023 2:46 pm
PUT by 10.5.2.130	SpectraApp2	PUT	Normal	300 MiB	300 MiB	August 21, 2023 2:46 pm
PUT by 10.5.2.130	c	PUT	Normal	75 MiB	75 MiB	August 21, 2023 2:46 pm

Rows per page: 10 1-10 of 15

**Figure 50** The Jobs pane.

1. Use the **Job Type** buttons to switch between Active, Canceled, and Completed jobs.
2. The name of the job includes the job type and the IP address of the job initiator.
3. The bucket used in the PUT or GET operation.
4. The type of job request.
5. The assigned priority of the job.
6. The original size and amount of data transferred to the BlackPearl system cache.
7. Displays the timestamp of when the job was initiated.

Use the **Change Priority** button to change the priority of an active job. See [Change Job Priority](#) on page 63 for more information.

## View Buckets

The Buckets pane provides information about all buckets configured on the BlackPearl system.

Name	Owner	Data Policy	Created
Spectra-BlackPearl-Backup-sm4u-21-50030480018b8b3f	Administrator	Database Backup	August 21, 2023 9:00 pm
SpectraApp	SpectraApp	Single Copy on Tape	August 21, 2023 2:33 pm
SpectraApp1	SpectraApp	Single Copy on Tape	August 21, 2023 2:45 pm
SpectraApp2	SpectraApp	Single Copy on Tape	August 21, 2023 2:45 pm
a	SpectraApp	Single Copy on Tape	August 21, 2023 2:45 pm
b	SpectraApp	Single Copy on Tape	August 21, 2023 2:45 pm
c	SpectraApp	Single Copy on Tape	August 21, 2023 2:45 pm
d	SpectraApp	Single Copy on Tape	August 21, 2023 2:45 pm
e	SpectraApp	Single Copy on Tape	August 21, 2023 2:45 pm
f	SpectraApp	Single Copy on Tape	August 21, 2023 2:46 pm


Rows per page: 10 1-10 of 12 < >

**Figure 51** The Buckets pane.

1. Displays the name of the bucket.
2. The bucket owner configured on the BlackPearl system.
3. The data policy used by the bucket.
4. Displays the timestamp of when the bucket was created.


## View Pools

The Pools pane displays information about all disk storage pools configured on the BlackPearl system including dedicated BlackPearl system cache and database pools.



**Figure 52** The Pools pane.


1. Each percentage graph displays both the used and remaining space for the associated pool.
2. Use the **Filter** button to select which pools to display on the Pools pane.
3. Click the **Details** button to view additional information about a specified pool.



**Figure 53** The pool details dialog box.

## View Volumes

The Volumes pane displays information about all volumes configured on the BlackPearl system.



**Figure 54** The Volumes pane.

1. Each percentage graph displays both the used and remaining space for the associated pool.
2. Use the **filter button** to select which pools to display on the Pools pane.


Use the **Snapshot** button to create a snapshot. For more information see [Create a Volume Snapshot](#) on page 61.



## View Tape Partitions - Main View

The Tape Partitions pane displays information about the tape partitions configured on the tape library attached to the BlackPearl system. The Tape Partitions pane features both a main view and a tape cartridge state view.

To display the main view, manipulate the slider (2) to the left position.




**Figure 55** The Tape Partitions pane - main view.

1. Each percentage graph displays both the used and remaining space for the associated type and generation of media present in the tape partition. Mouse-over the green section of any percentage graph to display the amount of used space, and over the gray section to display the amount of remaining space.
2. Use the slider to change the display a graph of the current state of each tape cartridge present in the partition.
3. Use the **Filter** button to select which pools to display on the Tape Partitions pane.

## View Tape Partitions - Tape State View

The Tape Partitions pane displays information about the tape partitions configured on the tape library attached to the BlackPearl system. The Tape Partitions pane features both a main view and a tape cartridge state view.

To display the tape cartridge state view, manipulate the slider (2) to the right position.




**Figure 56** The Tape Partitions pane - main view.

1. The state of all tape cartridges in the partition. Each state combines different generations of tape media if present. Mouse-over any part of the graph to display more detailed information.
2. Use the slider to change the display a graph of the current state of each tape cartridge present in the partition.
3. Use the **Filter** button to select which pools to display on the Tape Partitions pane.

## View Tape Drives

The Tape Drives pane displays information about all tape drives installed in the tape library connected to the BlackPearl system.



The screenshot shows the 'Tape Drives' pane in a management interface. At the top, there is a 'TAKE OFFLINE' button. Below it is a table with columns for Status, Type, Serial Number, Tape Barcode, Current Task, Cleaning Required, Online, and Reserved Task Type. Two rows of data are shown, both with 'Normal' status and 'LTO6' type. The 'Current Task' for both is 'WriteChunkToTapeTask'. The 'Cleaning Required' is 'No' and 'Online' is 'Yes' for both. The 'Reserved Task Type' is 'ANY' for both. Numbered callouts 1 through 8 are placed above the table headers to indicate specific fields: 1 (Status), 2 (Type), 3 (Serial Number), 4 (Tape Barcode), 5 (Current Task), 6 (Cleaning Required), 7 (Online), and 8 (Reserved Task Type).


1 Status	2 Type	3 Serial Number	4 Tape Barcode	5 Current Task	6 Cleaning Required	7 Online	8 Reserved Task Type
Normal	LTO6	1023003646	519815L5	WriteChunkToTapeTask	No	Yes	ANY
Normal	LTO6	1024003646	503887L5	WriteChunkToTapeTask	No	Yes	ANY

**Figure 57** The Tape Drives pane.

1. The current status of the tape drive.
2. The drive type and generation.
3. The drive serial number as assigned by the tape library.
4. The physical barcode of the tape cartridge loaded into the tape drive. This field is blank when no tape is loaded.
5. The current task being performed by the drive. This field is blank when no task is in progress.
6. Indicates if the tape drive requires cleaning.
7. Indicates if the tape drive is online or offline.
8. The reserved task type, if configured. The default setting is Any.

## View Tape Management

The Tape Management pane displays the status of all managed tapes in the tape library connected to the BlackPearl gateway.



**Figure 58** The Tape Management pane.

1. The physical barcode label on the tape cartridge.
2. The current state of the tape cartridge.
3. Indicates if the tape is configured for use as a **Normal** or **Test** tape.
4. The physical **Write Protected** status of the tape cartridge.
5. The name of any BlackPearl system bucket(s) present on the tape cartridge.
6. Displays the timestamp of the last tape verification.
7. Click the **Details** button to display additional information about the selected tape cartridge.
8. Use the **Search** entry field and **Search By** drop-down menu to find a specific tape cartridge.

See one of the following sections for instructions to export, verify, or online a tape cartridge:

- [Export a Tape Cartridge on the next page](#)
- [Verify a Tape Cartridge on page 62](#)
- [Online a Tape Cartridge on page 62](#)

---

# DASHBOARD ACTIONS


In addition to displaying information about the BlackPearl system, the embedded dashboard allows you to perform the most frequently-used actions as described in the sections below.

## Create a Volume Snapshot

A volume snapshot is an image of a volume's configuration and data makeup as they were when the snapshot was generated. Restoring to a previously created snapshot allows you to go “back in time” and restore the volume to the state it was in when the snapshot was created.

Here is how to create a volume snapshot:

1. In the BlackPearl dashboard, navigate to the **Volumes** pane.
2. **Select** the volume for which you want to create a snapshot.
3. Click **Snapshot**.
4. If desired, edit the pre-generated **Snapshot** name.



**Figure 59** The Export Tape dialog box.


5. Click **Submit**.

## Export a Tape Cartridge

Exporting a tape cartridge prepares it for physical removal from the attached tape library. In a Spectra Logic tape library, the cartridge is moved from the storage pool to the Entry/Exit pool, before it is physically exported from the library at the library front panel.

1. In the BlackPearl system dashboard, navigate to the **Tape Management** pane.
2. **Select** the tape you want to export.
3. Click **Export**.

- 
4. If desired, edit the **Export Label** and **Export Location**.



**Figure 60** The Export Tape dialog box.

5. Click **Submit**.

## Online a Tape Cartridge

Setting a tape cartridge to "online" prepares the cartridge for use by the BlackPearl system. This allows the system to use the tape cartridge for data storage operations.

Here is how to online a tape cartridge:

1. In the BlackPearl system dashboard, navigate to **Tape Management**.
2. Select a tape in the **Offline** state.
3. Click **Online Tape**.
4. Click **Submit**.

## Verify a Tape Cartridge

The BlackPearl system can perform a data integrity verification of all data on a selected tape cartridge to confirm it is still viable. While the verification is in progress, client access has priority over the data integrity scan.

Here is how to verify a tape cartridge:

1. In the BlackPearl system dashboard, navigate to **Tape Management**.
2. **Select** the tape you want to verify.
3. Click **Verify Tape**.
4. Click **Submit**.

---

## Change Job Priority

If desired, you can change the priority of an active job on the BlackPearl system.

Here is how you change the priority of a job:

1. In the BlackPearl system dashboard, navigate to the **Jobs** pane.
2. If necessary, click **Active** to display the list of active jobs.
3. **Select** the job for which you want to change priority.
4. Use the **drop-down** menu to select a new priority for the job.
5. Click **Submit**.