



Spectra Tape Libraries

SCSI Developer's Guide

SPECTRALOGIC.COM

Copyright

Copyright © 2005–2019 Spectra Logic Corporation. All rights reserved. This item and the information contained herein are the property of Spectra Logic Corporation.

Notices

Except as expressly stated herein, Spectra Logic Corporation makes its products and associated documentation on an “AS IS” BASIS, WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, BOTH OF WHICH ARE EXPRESSLY DISCLAIMED. In no event shall Spectra Logic be liable for any loss of profits, loss of business, loss of use or data, interruption of business, or for indirect, special, incidental or consequential damages of any kind, even if Spectra Logic has been advised of the possibility of such damages arising from any defect or error.

Information furnished in this manual is believed to be accurate and reliable. However, no responsibility is assumed by Spectra Logic for its use. Due to continuing research and development, Spectra Logic may revise this publication from time to time without notice, and reserves the right to change any product specification at any time without notice.

Trademarks

ArcticBlue, BlackPearl, BlueScale, BlueVision, CC, Spectra, SpectraGuard, Spectra Logic, TeraPack, TFinity, TranScale, and Verde are registered trademarks of Spectra Logic Corporation. SeeVault, Eon Protect, and MigrationPass are trademarks of Spectra Logic Corporation. All rights reserved worldwide. All other trademarks and registered trademarks are the property of their respective owners.

Part Number

90940001 Revision H

Revision History

Revision	Date	Description
E	September 2005	
F	October 2009	Updated to encompass all tape libraries that return SPECTRA PYTHON in the Inquiry string. Removed unsupported Extended Copy and Receive Copy Results commands.
G	April 2015	Update commands for new features. Add READ BUFFER command. Update trademarks.
H	January 2019	Update Read Element Status response for LTO-7, LTO-8, and TFinity media zoning. Add GTAOS and RTAOS.

Note: To make sure you have the most current version of this guide check the Spectra Logic website at support.spectralogic.com/documentation. To make sure you have the release notes for the most current version of the BlueScale software, log into the Spectra Logic Technical Support portal at support.spectralogic.com. The release notes contain updates to the *User Guide* since the last time it was revised.

**End User
License
Agreement****1. READ CAREFULLY**

YOU SHOULD READ THE FOLLOWING TERMS AND CONDITIONS BEFORE ACCEPTING THIS END-USER LICENSE AGREEMENT ("EULA"). THIS EULA IS A LEGAL AGREEMENT BETWEEN YOUR ORGANIZATION, THE END USER, AND SPECTRA LOGIC CORPORATION ("SPECTRA") FOR THE SPECTRA SOFTWARE PRODUCT WHICH INCLUDES COMPUTER SOFTWARE AND MAY INCLUDE ASSOCIATED MEDIA, PRINTED MEDIA, AND "ONLINE" OR ELECTRONIC DOCUMENTATION (COLLECTIVELY, "SOFTWARE PRODUCT"). BY INSTALLING, COPYING, OR OTHERWISE USING THE SOFTWARE PRODUCT, YOU AGREE TO BE BOUND BY THE TERMS OF THIS EULA. IF YOU DO NOT AGREE TO THE TERMS OF THIS EULA, YOU MAY NOT INSTALL, COPY, DOWNLOAD OR USE THE SOFTWARE PRODUCT. YOU AGREE THAT YOUR USE OF THE SOFTWARE ACKNOWLEDGES THAT YOU HAVE READ THIS AGREEMENT, UNDERSTAND IT, AND AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS.

2. OWNERSHIP

It is understood and agreed that Spectra Logic Corporation, a Delaware corporation with offices at 6285 Lookout Road, Boulder, CO 80301 ("Licensor") is the owner of all right, title and interest to the Software Product, regardless of the media or form of the original download, whether by the World Wide Web, disk or otherwise. You, as licensee ("Licensee") through your downloading, installing, copying or use of this product do not acquire any ownership rights to the Software Product.

3. GENERAL

The Software Product is licensed, not sold, to you by Spectra for use only under the terms of this EULA. The Software Product is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The rights granted herein are limited to Spectra's and its licensors' intellectual property rights in the Software Product and do not include any other patents or intellectual property rights. The terms of this EULA will govern any software upgrades provided by Spectra that replace and/or supplement the original Software Product, unless such upgrade is accompanied by a separate license in which case the terms of that license will govern.

4. SOFTWARE PRODUCT

The Software Product, as used in this EULA, means, collectively and/or as applicable:

- The Software Product package;
- Any and all contents, components, attachments, software, media, and code with which this Agreement is provided and delivered;
- Any and all images, photographs, art, art work, clip art, fonts or other artistic works (the "Art Work");
- Related explanatory written materials and instructions, and any other possible documentation related thereto ("Documentation"); and
- Upgrades, modified versions, updates, additions and copies of the Software Product (the "Upgrades"), if any, licensed to by Spectra under this EULA.

5. GRANT OF LICENSE AND RESTRICTIONS

- A. Spectra grants you a non-exclusive, non-transferable End-User license right to install the Software Product solely for the purpose for which it was created.
- B. Unless provided otherwise in the Documentation or by prior express written consent of Spectra, you shall not display, modify, reproduce and distribute any Art Work, or portion(s) thereof, included with or relating to the Software Product, if any. Any such authorized display, modification, reproduction and distribution shall be in full accord with this EULA. Under no circumstances will your use, display, modification, reproduction and distribution of the Art Work give you any Intellectual Property or Proprietary Rights of the Art Work. All rights, title, and interest belong solely to Spectra.
- C. Except for the initial loading of the Software Product, you shall not, without Spectra's express written consent:
 - Copy or reproduce the Software Product; or
 - Modify, adapt, or create derivative works based on the Software Product or any accompanying materials.

6. DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS

- A. Spectra will provide you with support services related to the Software Product ("Support"). Such Support will be provided in accordance with the Spectra Master Support Agreement, available for download and viewing on the Spectra Corporate Web site. Use of Support is governed by this EULA and Spectra's Master Support Agreement.
- B. Any supplemental software, code, content, or media provided to you in the course of Support shall be considered part of the Software Product and subject to the terms and conditions of this EULA.
- C. Spectra retains all right, title, and interest in and to the Software Product, and any rights not granted to you herein are reserved by Spectra. You hereby expressly agree not to extract information, reverse engineer, disassemble, decompile, or translate the Software Product, or otherwise attempt to derive the source code of the Software, except to the extent allowed under any applicable law. In the event that such activities are permitted by applicable law, any information you, or your authorized agent, discover shall be promptly disclosed to Spectra and shall be deemed the confidential information of Spectra.
- D. You shall not modify, sublicense, assign, or transfer the Software Product or any rights under this EULA, except as expressly provided in this EULA. Any attempt to sublicense, assign, or transfer any of the rights, duties, or obligations will be void.
- E. You may permanently transfer all of your rights under this EULA, provided you retain no copies. The other party must agree to accept the terms and conditions of the EULA.

7. ALL RESERVED

All rights not expressly granted herein are reserved by Spectra.

8. TERM

- A.** This License is effective until terminated. Licensee may terminate it at any time by destroying the Software Product with all copies, full or partial, and removing all of its component parts.
- B.** Your rights under this EULA will terminate automatically without notice from Spectra if you fail to comply with any term(s) or condition(s) of this EULA. In such event, no notice shall be required by Spectra to effect such termination.
- C.** Upon termination of this EULA, you shall cease all use of the Software Product and destroy all copies, full or partial, together with all backup copies, modifications, printed or written materials, and merged portions in any form and remove all component parts of the Software Product.

9. INTELLECTUAL PROPERTY RIGHTS

- A.** Spectra shall retain all right, title, and interest in the Software Product and to any modifications or improvements made thereto, and any upgrades, updates or Documentation provided to End User. End User will not obtain any rights in the Software Product, its updates, upgrades, and Documentation, as a result of its responsibilities hereunder.
- B.** End User acknowledges Spectra's exclusive rights in the Software Product and that the Software Product is unique and original to Spectra and that Spectra is owner thereof. Unless otherwise permitted by law, End User shall not, at any time during or after the effective Term of the Agreement, dispute or contest, directly or indirectly, Spectra's exclusive right and title to the Software Product or the validity thereof.

10. U.S. GOVERNMENT END USERS

The Software Product and related documentation are "Commercial Items," as that term is defined at 48 C.F.R. §2.101, consisting of "Commercial Computer Software" and "Commercial Computer Software Documentation," as such terms are used in 48 C.F.R. §12.212 or 48 C.F.R. §§227.7202-1 through 227.7202-4, as applicable. The Commercial Computer Software and Commercial Computer Software Documentation are being licensed to U.S. Government end users (a) only as Commercial Items and (b) with only those rights as are granted to all other End Users pursuant to the terms and conditions herein. Unpublished rights reserved under the copyright laws of the United States.

11. EXPORT LAW ASSURANCES

You may not use or otherwise export or re-export the Software Product except as authorized by United States law and the laws of the jurisdiction in which the Software Product was obtained. In particular, but without limitation, the Software Product may not be exported or re-exported (a) into (or to a nation or resident of) any U.S. embargoed countries or (b) to anyone on the U.S. Treasury Department's list of Specially Designated Nationals or the U.S. Department of Commerce Denied Persons List or Entity List. By installing or using any component of the Software Product, you represent and warrant that you are not located in, under control of, or a national or resident of any such country or on any such list.

12. DISCLAIMER OF WARRANTIES

YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF THE SOFTWARE PRODUCT IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AND EXCEPT AS MAY BE STATED IN THE SPECTRA MASTER SERVICE AGREEMENT, THE SOFTWARE PRODUCT IS PROVIDED "AS IS," WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND, AND SPECTRA AND SPECTRA'S AFFILIATES (COLLECTIVELY REFERRED TO AS "SPECTRA" FOR THE PURPOSES OF SECTIONS 12 AND 13) HEREBY DISCLAIM ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE SOFTWARE PRODUCT, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY, OF SATISFACTORY QUALITY, OF FITNESS FOR A PARTICULAR PURPOSE, OF ACCURACY, OF QUIET ENJOYMENT, AND NON-INFRINGEMENT OF THIRD-PARTY RIGHTS. SPECTRA DOES NOT WARRANT AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE PRODUCT THAT THE FUNCTIONS CONTAINED IN THE SOFTWARE PRODUCT WILL MEET YOUR REQUIREMENTS, THAT THE OPERATION OF THE SOFTWARE PRODUCT WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT DEFECTS IN THE SOFTWARE PRODUCT WILL BE CORRECTED. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SPECTRA OR A SPECTRA AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATION ON APPLICABLE STATUTORY RIGHTS OF A CONSUMER, SO THE ABOVE EXCLUSION AND LIMITATIONS MAY NOT APPLY TO YOU.

13. LIMITATION OF LIABILITY

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL SPECTRA, ITS AFFILIATES OR LICENSEES, BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE PRODUCT OR THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES, EVEN IF SPECTRA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN ANY CASE, SPECTRA'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS EULA SHALL BE LIMITED TO THE AMOUNT ACTUALLY PAID BY YOU FOR THE SOFTWARE PRODUCT; PROVIDED HOWEVER, IF YOU HAVE ENTERED INTO A MASTER SUPPORT AGREEMENT, SPECTRA'S ENTIRE LIABILITY REGARDING SUPPORT SERVICES SHALL BE GOVERNED BY THE TERMS OF THAT AGREEMENT. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

14. CONTROLLING LAW AND SEVERABILITY

This EULA will be governed by and construed in accordance with the laws of the State of Colorado, as applied to agreements entered into and to be performed entirely within Colorado between Colorado residents. This EULA shall not be governed by the United Nations Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. If for any reason a court of competent jurisdiction finds any provision, or portion thereof, to be unenforceable, the remainder of this EULA shall continue in full force and effect.

Contacting Spectra Logic

To Obtain General Information

Spectra Logic Website: www.spectralogic.com

United States Headquarters

Spectra Logic Corporation
6285 Lookout Road
Boulder, CO 80301
USA
Phone: 1.800.833.1132 or 1.303.449.6400
International: 1.303.449.6400
Fax: 1.303.939.8844

European Office

Spectra Logic Europe Ltd.
329 Doncastle Road
Bracknell
Berks, RG12 8PE
United Kingdom
Phone: 44 (0) 870.112.2150
Fax: 44 (0) 870.112.2175

Spectra Logic Technical Support

Technical Support Portal: support.spectralogic.com

United States and Canada

Phone:
Toll free US and Canada: 1.800.227.4637
International: 1.303.449.0160

Europe, Middle East, Africa

Phone: 44 (0) 870.112.2185
Deutsch Sprechende Kunden
Phone: 49 (0) 6028.9796.507
Email: spectralogic@stortrec.de

Mexico, Central and South America, Asia, Australia, and New Zealand

Phone: 1.303.449.0160

Spectra Logic Sales

Website: <http://shop.spectralogic.com/>

United States and Canada

Phone: 1.800.833.1132 or 1.303.449.6400
Fax: 1.303.939.8844
Email: sales@spectralogic.com

Europe

Phone: 44 (0) 870.112.2150
Fax: 44 (0) 870.112.2175
Email: eurosales@spectralogic.com

To Obtain Documentation

Spectra Logic Website: support.spectralogic.com/documentation

Spectra Tape Libraries Contents

About This Guide 12

CONTENTS OF THIS MANUAL	12
RELATED PUBLICATIONS	13
Spectra Tape Libraries	13
LTO Ultrium Tape Drives	13
TS11x0 Technology Drives	14
Standards	14

Chapter 1 – Overview of the Library as a SCSI Device 15

SCSI DEVICE RELATIONSHIPS	15
ELEMENTS AND ELEMENT ADDRESSES	16
SCSI COMMAND FORMAT	16
SCSI COMMAND STATUS BYTES	18

Chapter 2 – GTAOS (A4h) 19

COMMAND DESCRIPTION	19
WHAT YOU SEND TO THE LIBRARY	20
GTAOS Parameter List	20
COMMAND STATUS	23

Chapter 3 – Initialize Element Status (07h) 25

ABOUT THIS COMMAND	25
COMMAND RESPONSE	26
COMMAND STATUS	26

Chapter 4 – Initialize Element Status With Range (37h or E7h) 27

COMMAND DESCRIPTION	27
---------------------------	----

Chapter 5 – Inquiry (12h) 28

COMMAND DESCRIPTION	28
WHAT YOU SEND TO THE LIBRARY	29

COMMAND RESPONSE	30
Standard Inquiry Data Page	30
Supported Vital Product Data Page (Page Code 00h)	33
Unit Serial Number Data Page (Page Code 80h)	35
Device Identification Page (Page Code 83h)	36
TAOS Serial Number Association Page (Page Code D0h)	38
COMMAND STATUS	40
Chapter 6 – Mode Select (15h)	41
COMMAND DESCRIPTION	41
WHAT YOU SEND TO THE LIBRARY	42
Mode Parameter Lists	43
Parameter List Header	43
Element Address Assignment Page (Page Code 1Dh)	44
COMMAND STATUS	46
Chapter 7 – Mode Sense (1Ah)	48
COMMAND DESCRIPTION	49
WHAT YOU SEND TO THE LIBRARY	50
COMMAND RESPONSE	51
Parameter List Header	51
Element Address Assignment Page (Page Code 1Dh)	52
Transport Geometry Parameters (Page Code 1Eh)	55
Device Capabilities Page (Page Code 1Fh)	56
COMMAND STATUS	58
Chapter 8 – Move Medium (A5h)	59
COMMAND DESCRIPTION	59
WHAT YOU SEND TO THE LIBRARY	60
COMMAND STATUS	60
Chapter 9 – Prevent/Allow Medium Removal (1Eh)	63
COMMAND DESCRIPTION	63
WHAT YOU SEND TO THE LIBRARY	63
COMMAND STATUS	64

Chapter 10 – Read Buffer (3Ch)	65
COMMAND DESCRIPTION	65
What You Send to the Library	66
COMMAND RESPONSE	66
COMMAND STATUS	67
Chapter 11 – Read Element Status (B8h)	68
COMMAND DESCRIPTION	68
What You Send to the Library	71
COMMAND RESPONSE	72
Element Status Header	73
Element Status Pages	74
ELEMENT DESCRIPTORS	75
Medium Transport Element Descriptor	76
Storage Element Descriptor	80
Data Transfer Element Descriptor	84
Import/Export Element Descriptor	91
TFinity Libraries with Enable Media Zoning Selected	98
Command Status	100
Chapter 12 – Release (17h)	101
COMMAND DESCRIPTION	101
WHAT YOU SEND TO THE LIBRARY	102
COMMAND STATUS	102
Chapter 13 – Report LUNs (A0h)	104
COMMAND DESCRIPTION (NOT SUPPORTED FOR PARALLEL SCSI LIBRARIES)	104
WHAT THE LIBRARY RETURNS	106
Command Status	107
Chapter 14 – Request Sense (03h)	108
COMMAND DESCRIPTION	108
WHAT YOU SEND TO THE LIBRARY	108
COMMAND RESPONSE	109
COMMAND STATUS	111

Chapter 15 – Reserve (16h)	112
COMMAND DESCRIPTION	112
WHAT YOU SEND THE LIBRARY	113
Element List Descriptor	114
COMMAND STATUS	114
Chapter 16 – RTAOS (A3h)	117
COMMAND DESCRIPTION	117
WHAT YOU SEND TO THE LIBRARY	118
RTAOS Parameter Data	118
COMMAND STATUS	121
Chapter 17 – Send Diagnostic (1Dh)	123
COMMAND DESCRIPTION	123
WHAT YOU SEND TO THE LIBRARY	124
Send Diagnostic Assignment Page (Page Code 80h)	124
COMMAND RESPONSE	125
Chapter 18 – Test Unit Ready (00h)	126
COMMAND DESCRIPTION	126
COMMAND STATUS	126
Appendix A – Error Reporting	128
SENSE KEYS	128
Sense Keys Not Used	129
ADDITIONAL SENSE CODES AND QUALIFIERS	129
Index	144

ABOUT THIS GUIDE

This manual provides reference information for developing SCSI applications for use with a Spectra tape library (referred to as the *library*). Each logical library (partition) defined within a physical library uses the same SCSI communication protocol as the physical library.

Note: The SCSI operations performed by the library are separate from the SCSI operations performed by the enclosed drives. For drive SCSI operations, refer to the appropriate drive documentation.

CONTENTS OF THIS MANUAL

This manual contains the following information:

- [Chapter 1 – Overview of the Library as a SCSI Device](#), beginning on [page 15](#) provides a general overview of the library as a SCSI device, including descriptions of the elements in the library, the SCSI command format, and definitions of the status byte returned by the library in response to SCSI commands.
- [Chapter 3 – Initialize Element Status \(07h\)](#), beginning on [page 25](#) through [Chapter 18 – Test Unit Ready \(00h\)](#), beginning on [page 126](#) contain information about individual SCSI commands. For ease of reference, the commands are presented in alphabetical order.
- [Appendix A](#) lists the sense keys, ASCs (Additional Sense Codes), and ASCQs (Additional Sense Code Qualifiers) returned by the library in response to a **REQUEST SENSE** command.

RELATED PUBLICATIONS

For additional information about the Spectra tape libraries, refer to the following publications.

Spectra Tape Libraries

The most current version of this guide and the following documents related to the Spectra tape libraries are available on the Spectra Logic website at support.spectrallogic.com/documentation.

- The *User Guide* for each library describes the configuration and operation of the library.
- The *Release Notes and Documentation Updates* for each library provides the most up-to-date information about the library, drives, and media.

LTO Ultrium Tape Drives

The following documents provide information that is applicable to all IBM LTO tape drives.

- *IBM Tape Device Drivers Installation and User's Guide*
Note: This guide also provides information about using the IBM Tape Diagnostic Tool (ITDT) to troubleshoot drive problems.
- *IBM TotalStorage LTO Ultrium Tape Drive: SCSI Reference* (LTO-1 through LTO-4)
- *IBM TotalStorage LTO Ultrium Tape Drive: SCSI Reference* (LTO-5 and LTO-6)

For drive-specific information, search for the product name (for example, LTO 5) on the documentation page on the IBM website. You can also search the IBM Support Portal at <http://www-947.ibm.com/support/entry/portal/Documentation>.

TS11x0 Technology Drives

The following documents provide information that is applicable to TS11x0 technology drives.

- *IBM Operator Guide 3592 Models J1A, E05, E06, EU6, J70 and C06* at <http://publibfp.dhe.ibm.com/epubs/pdf/a86opg02.pdf>
- *IBM System Storage Tape Drive 3592 SCSI Reference* at <https://www-304.ibm.com/support/docview.wss?uid=ssg1S7003248>
- *IBM Tape Device Drivers Installation and User's Guide* at <https://www-304.ibm.com/support/docview.wss?rs=577&uid=ssg1S7002972>

Note: This guide also provides information about using the IBM Tape Diagnostic Tool (ITDT) to troubleshoot drive problems.

Standards

- *Small Computer System Interface — 3 (SCSI-3)*
- *SCSI Primary Commands—3 (SPC-3), Revision 23*
- *SCSI Media Changer Commands — 2 (SMC-2), Revision 7*
- *SCSI Stream Command Set — 2 (SSC-2), Revision*
- *SCSI Stream Command Set — 3 (SSC-3), Revision*

Typographical Conventions

This document uses the following conventions to highlight important information:

Note: Read text marked with “Note” for additional information or suggestions about the current topic.



Important

Read text marked by the “Important” icon for information that will help you complete a procedure or avoid extra steps.



Caution

Read text marked by the “Caution” icon for information you must know to avoid damaging the library, the tape drives, or losing data.



WARNING

Read text marked by the “Warning” icon for information you must know to avoid personal injury.

CHAPTER 1

Overview of the Library as a SCSI Device

This chapter provides background information for understanding how a tape library operates as a SCSI device.

SCSI DEVICE RELATIONSHIPS

The Small Computer System Interface (SCSI) is a standard that enables a host computer and peripheral equipment, such as the library and its tape drives, to communicate. The library and the tape drives each support an independent set of SCSI commands. When a library is divided into multiple partitions using Shared Library Services (SLS), each partition is treated as an independent logical library.

The physical components of the SCSI system consist of the following:

- **Initiator** A computer equipped with a host bus adapter card which allows it to send commands, messages, and data across the bus to targets such as the library or tape drives. The initiator can also receive data, messages, and status from the targets.
- **Targets** Devices capable of receiving commands from an initiator. The library and tape drives are independent targets. The library is the target for cartridge inventory and movement operations. The tape drives are the targets for read and write operations.
- **Bus** The cables that connect the initiator to the library, tape drives, host bus adaptor (HBA), and other devices form the bus and provide a pathway for passing information between the initiator and the targets. Each device attached to a bus has a unique ID that identifies it during communication.

ELEMENTS AND ELEMENT ADDRESSES

Each element in the library has a unique element address. When you issue SCSI commands to the library, you may need to specify an *element address* to identify a specific location (called an *element*) for which the particular command is intended.

The library contains the following types of elements:

- **Medium transport element** The robot (transporter) is the medium transport element that moves the cartridges in the library. Although some of the tape libraries may contain more than one robotic element, the multiple robotic elements cannot be addressed individually; the robotic movement logic for multiple robots is handled internal to the library. Therefore, there is only one robotic element address for Spectra tape libraries.
- **Storage elements** The cartridge slots in the partition's storage pool are the storage elements. These elements store the cartridges while they are not being used in the tape drives.
- **Import/export element** The import/export elements let you import media into or export media from the partition's storage pool.
 - With the exception of the T120 and T50e libraries, the import/export elements in the tape libraries are the slots assigned to the entry/exit pool for a partition. Since the number of entry/exit chambers in a partition is configurable, there is no set number of import/export elements.
 - For the T120 and T50e libraries, the import/export elements are the slots in the entry/exit port. In these libraries the import/export elements are fixed elements that cannot be altered or changed. Although, to support more than one partition, logical representations of the import/export elements can be configured. See [Overview of T120 and T50e Entry/Exit Modes](#) on page 95 for more information.
- **Data transfer elements** Each tape drive is a data transfer element, a source or destination for tape cartridges moves, for data reads and writes. Each tape drive has its own ID and responds to tape drive-specific SCSI commands.

SCSI COMMAND FORMAT

The library uses six-, ten-, and twelve-byte commands, whose formats are described in the SCSI-3 standard. Any SCSI command descriptor block (CDB) fields that are specific to the library for a given command are described in the chapter specific to that command.

Any errors caused by illegal parameters in a CDB or parameter list for a particular command are listed at the end of the chapter specific to that command. Errors of this type return a sense key of Illegal Request (5h).

Table 1-1 lists the CDB fields that are common to every command.

Table 1-1: Definitions of CDB Field common to all commands

Field	Description
Logical Unit Number (LUN) Field	The library is a single device target and only supports a LUN of 0. The LUN field for each CDB must be set to 0. Note: If the Identify message is sent before the CDB, the LUN field in the CDB is ignored. However, the LUN field in the Identify message must be set to 0.
Reserved Fields	The word <i>Reserved</i> in a field definition for a SCSI command refers to fields defined as reserved by the SCSI-3 standard. The library checks these fields for a value of 0. If a 0 is not present, the library returns Check Condition status with a sense key of Illegal Request (5h).
Obsolete Fields	The word <i>Obsolete</i> in a field definition for a SCSI command refers to a field that was defined in a previous SCSI standard but has been removed from the current SCSI standard. The library ignores any value in these fields.
Control Byte	The vendor unique portion of the Control byte (as indicated in the SCSI-3 standard) is defined for each specific command, if used. The library does not support linked commands or recognize the Flag bit.

SCSI COMMAND STATUS BYTES

The library sends one status byte to the initiator in response to each command. [Table 1-2](#) summarizes the status bytes used by the library.

Table 1-2: SCSI command status bytes supported by the library

Status	Hex Value	Description
Good	00h	Indicates that the library successfully completed the operation specified by the CDB. The library returns Good status to indicate that the operation specified by the CDB completed normally.
Check Condition	02h	Indicates an error, exception, or abnormal condition that has caused sense information to be set. The library returns Check Condition status to indicate that an error occurred while it was executing a command. The library reports Check Condition status as soon as it detects the error unless it is disconnected from the SCSI bus. If the library is disconnected, it reports Check Condition status after the reconnect process. For specific situations that return Check Condition status, refer to the command descriptions in Chapter 3 – Initialize Element Status (07h) , beginning on page 25 through Chapter 18 – Test Unit Ready (00h) , beginning on page 126 .
Busy	08h	Indicates that the library is unable to accept a command from an initiator. The library returns Busy status to any initiator that sends a command other than INQUIRY or REQUEST SENSE when the library is disconnected from the SCSI bus or when it is waiting for a SCSI motion process to abort. If allowed, the library disconnects from the SCSI bus when performing any lengthy operations, such as a move operation. The library cannot abort a motion process until the full motion recovery operation completes. The library reports BUSY and cannot process commands other than INQUIRY and REQUEST SENSE until recovery completes.
Reservation Conflict	18h	Indicates that the elements or the library identified in the command are reserved by another initiator. The library returns Reservation Conflict status to indicate that either the entire library or the elements requested to be accessed are currently reserved by another initiator. This status is reported until the initiator that reserved the library or elements issues a RELEASE (17h) command or a reset condition occurs. The library does not support Persistent Reservations (SPC-3).

CHAPTER 2

GTAOS (A4h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (A4h)							
01	Reserved			Service Action (1Dh)				
02	Reserved				Process (010b)			
03	Reserved				LBA Type (000b)			
04	Reserved							
05	Reserved							
06	(MSB)							
...	Parameter List Length							
09	(LSB)							
10	Reserved							
11	Control Byte							

Note: This command is supported on TFinity libraries running BlueScale12.8.0 and later. See “Enable Time-based Access Order System (TAOS)” in the *Spectra TFinity Library User Guide* for instructions for enabling TAOS in a partition.

COMMAND DESCRIPTION

The **GTAOS (GENERATE TIME-BASED ACCESS ORDER SYSTEM)** command enables the host to send a list of proposed reads for reordering. The **RTAOS (RECEIVE TIME-BASED ACCESS ORDER SYSTEM)** command is then used to receive a list of reads reordered by the library to minimize the amount of seek time required to process the reads.

- Notes:**
- After issuing the **GTAOS** command, issue a **RTAOS** command (see [RTAOS \(A3h\)](#) on page 117).
 - This command can only be issued to a tape drive that is exporting a "SPECTRA TAOS" device on LUN 1. Use Inquiry page [TAOS Serial Number Association Page \(Page Code D0h\)](#) on page 38 to determine the drive serial number and associate it with a library partition.

- This command is supported for LTO-7 and later generation drives.
- The recommended timeout for this command is 20 minutes or 1200 seconds.

WHAT YOU SEND TO THE LIBRARY

To request the generation of a Time-Based Access Order System list, send a **GTAOS** command with the following parameters, followed by a parameter list in the Data Out phase.

Table 2-1: GTAOS CDB parameter values

Field Name	Values Allowed	Meaning
Service Action	1Dh	Indicates that the command is requesting a device server to send the requested information. This is the only supported Service Action for LUN 1.
Process	010b	Requests generation of the TAOS list. This is the only Process option supported for LUN 1.
LBA Type	000b	Indicates to generate a TAOS list without geometry. This is the only LBA Type supported for LUN 1.
Parameter List Length	Varies	<p>This field indicates the length of the entire parameter list transferred. The parameter list length is equal to the length of one Parameter List Header (8 bytes) plus the lengths of all Logical Block Address Descriptors to be transferred.</p> <p>When the value of the parameter list length is 00h (no data transferred) or 08h (header only transferred), the TAOS list is cleared. These are not considered errors.</p> <p>The data length for a single Logical Block Address Descriptors returned by the library is 32 bytes (20h). A maximum of 3000 Logical Block Descriptors are allowed for a total size of 96,000 bytes, plus the 8 byte header.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ If the parameter list length results in the truncation of a Logical Block Address Descriptor, the drive sled returns CHECK CONDITION status with associated sense data of 5/2400 (ILLEGAL REQUEST, INVALID FIELD IN CDB). ▪ If your drive uses firmware lower than JAYE, the maximum number of Logical Block Address descriptors is 2000.

GTAOS Parameter List

Following the command block, the initiator sends the Parameter List Header, typically followed by one or more Logical Block Address Descriptors containing information about requested reads.

GTAOS Parameter List Header

If you send one or more Logical Block Address Descriptors with the **GTAOS** command, you must send a Parameter List Header. Sending the Parameter List Header alone clears the TAOS list.

Bit Byte	7	6	5	4	3	2	1	0
00	Reserved							
01								
02								
03								
04 ... 07	(MSB)	Additional Date (N-7)						(LSB)
	Logical Black Address Descriptors							
x	Logical Block Address Descriptors (First)							
	...							
y n	Logical Block Address Descriptors (Last)							

Table 2-2: Data sent in the Parameter List Header

Field Name	Value	Meaning
Additional Data	$n-7$ where n is the Parameter List Length	Indicates the length of all Logical Block Address Descriptors to be transferred. To clear the list, send 0000h.

GTAOS Logical Block Address Descriptor

Bit Byte	7	6	5	4	3	2	1	0
00	(MSB) Descriptor Length (1Eh) (LSB)							
01								
02	Reserved							
03	Reserved							
04	Reserved							
05 ... 14	LBA Name							
15	Partition Number							
16 ... 23	(MSB) Beginning Logical Object of Logical Block Address (LSB)							
24 ... 31	(MSB) Ending Logical Object of Logical Block Address (LSB)							

Table 2-3: Data sent in the Logical Block Address descriptor

Field Name	Value	Meaning
Descriptor Length	1Eh	The length of the data to follow. The data length for each Logical Block Address sent to the library is 30 bytes (1Eh) plus this Descriptor Length field.
LBA Name	Varies	LBA (Logical Block Address) Name is set by the host and is returned unchanged by the RTAOS command . The data type is ignored.
Partition Number	Varies	The number of the partition on the tape containing the data block.
Beginning Logical Object of Logical Block Address	Varies	The first block in the Logical Block Address. This field is an 8-byte unsigned integer field and takes values from 0 to 1,152,921,504,606,846,975.
Ending Logical Object of Logical Block Address	Varies	The last block in the Logical Block Address. This field is an 8-byte unsigned integer field and takes values from 0 to 1,152,921,504,606,846,975.

COMMAND STATUS

The library returns a status byte after processing the **GTAOS** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on page 112 for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- Attempting a **GTAOS** command when a tape is not threaded in the drive.
- A parameter in the CDB on a **GTAOS** page is invalid (see [Table 2-4](#) for sense data).

Table 2-4: Invalid parameters in the GTAOS CDB and GTAOS Parameter list

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	1Ah	00h	1	1	0	0	00 04h	Invalid Parameter List Length.
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	24h	00h	1	1	1	2	1	Service Action set to a value other than 1Dh.
5h	24h	00h	1	1	1	2	3	LBA Type set to a value other than 0.
5h	24h	00h	1	1	1	2	2	Process set to a value other than 2.
5h	24h	00h	1	1	1	0	6	Allocation Length invalid or too large.
5h	24h	00h	1	1	1	0	0	Read bad wrap data from drive.

CHAPTER 3

Initialize Element Status (07h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (07h)							
01	Obsolete ^a				Reserved			
02	Reserved							
03								
04								
05	Control							

a. These bits are ignored.

ABOUT THIS COMMAND

The **INITIALIZE ELEMENT STATUS** command does not do anything. The inventory is already known. For the T50e and T120, the inventory is scanned during initialization; for the T200, T380, T680, T950, and TFinity, the inventory is stored in nonvolatile cache. The library automatically updates the element inventory each time the TeraPack Access Port (TAP) or entry/exit port is opened and closed or whenever the library robotics moves media from one element to another. The inventory information can be returned to the initiator using the **READ ELEMENT STATUS** (B8h) command (see [Chapter 11 – Read Element Status \(B8h\)](#), beginning on page 68).

Note: The recommended timeout for this command is 5 minutes or 300 seconds.

COMMAND RESPONSE

The library returns a status bit in response to the **INITIALIZE ELEMENT STATUS** command. No data is returned.

COMMAND STATUS

The library returns a status byte after processing the **INITIALIZE ELEMENT STATUS** command as follows:

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on page 112 for more information about the **RESERVE** command.

Check Condition

Check Condition status is returned for the following reasons:

- A Unit Attention condition is pending for the initiator.
- The command is issued to an invalid LUN.
- The library has experienced an unrecoverable hardware error.
- The library encounters a problem while scanning the cartridges.
- A reserved bit is set to 1 in the CDB or a parameter in the CDB is invalid (see [Table 3-1](#) for sense data).

Table 3-1: Sense data for invalid parameters in the INITIALIZE ELEMENT STATUS CDB

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.

CHAPTER 4

Initialize Element Status With Range (37h or E7h)

Bit Byte	7	6	5	4	3	2	1	0	
00	Operation Code (E7h or 37h)								
01	Reserved						Fast ^a	Range ^b	
02	(MSB)	Starting Element Address ^b						(LSB)	
03									
04	Reserved								
05									
06	(MSB)	Number of Elements ^b						(LSB)	
07									
08	Reserved								
09	Control ^b								

a. These bits are ignored.

COMMAND DESCRIPTION

INITIALIZE ELEMENT STATUS WITH RANGE is included in the command set for the tape libraries to support the library's emulation of other libraries.

When the library receives this command, it performs as though it had received the **INITIALIZE ELEMENT STATUS** (07h) command, ignoring any additional parameters supplied with this command. See [Chapter 3 – Initialize Element Status \(07h\)](#), beginning on [page 25](#) for information about the **INITIALIZE ELEMENT STATUS** command.

Note: The recommended timeout for this command is 5 minutes or 300 seconds.

CHAPTER 5

Inquiry (12h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (12h)							
01	Obsolete ^a			Reserved			CMDDDT ^b	EVPD
02	Page Code							
03	Reserved							
04	Allocation Length							
05	0	0	Reserved			0	0	

a. These bits are ignored.

COMMAND DESCRIPTION

The **INQUIRY** command requests that the library send information regarding its parameters to the initiator. The library can return the following categories of data in response to this command:

- The Standard Inquiry Data page, described starting on [page 30](#), contains basic information about the library, including the product identification.

Note: All of the Spectra Logic tape libraries return SPECTRA PYTHON as the device identifier in response to an **INQUIRY** command.

- The Vital Product Data pages, described starting on [page 33](#), contain additional detailed information about the library. For example, the Unit Serial Number page (Page Code 0x80), described starting on [page 35](#), contains an ASCII representation of the library serial number. Each Vital Product Data page requires a separate **INQUIRY** command from the initiator.

Note: The recommended timeout for this command is 60 seconds.

WHAT YOU SEND TO THE LIBRARY

The data returned by the **INQUIRY** command depends on the values of the parameters in the CDB.

Table 5-1: INQUIRY CDB parameter values

Field Name	Values Allowed	Meaning
CMDDT (Command Support Data)	0	The library does not support returning optional command support data.
EVPD (Enable Vital Product Data)	0	Requests the Standard Inquiry Data page (described on page 30). Note: If the EVPD bit is set to 0, the Page Code must be 00h.
	1	Request Vital Product Data specific pages (described on page 33), based on the value of the Page Code field (byte 02).
Page Code	00h	Requests the Supported Vital Product Data page (described on page 33)
	80h	Requests the Unit Serial Number page (described on page 35)
	83h	Requests the Device Identification page (described on page 36)
	0Dh	Requests the TAOS Serial Number Association page (described on page 38) Note: Supported by TFinity libraries running BlueScale12.8.0 or later.
Allocation Length	00–FFh	<p>Specifies the number of bytes that are allocated by the initiator for returned inquiry data. A value of 0 indicates that no inquiry data is to be transferred. This condition is not an error.</p> <p>The library terminates the Data In phase when it transfers either the number of bytes specified by the Allocation Length field or all of the available inquiry data, whichever is less.</p> <p>The lengths for inquiry data pages returned by the library are:</p> <ul style="list-style-type: none"> ▪ Standard Inquiry Data: <ul style="list-style-type: none"> ▪ 24h (36 bytes) if the library is exported by a QIP or RIM –OR– ▪ 3Ah (58 bytes) if the library is exported by a tape drive ▪ Supported Vital Product Data Pages: 08h (8 bytes) ▪ Unit Serial Number: 0Eh (14 bytes) ▪ Device Identification: 36h (54 bytes) ▪ TAOS Serial Number Association: 2Ah (42 bytes)

COMMAND RESPONSE

The data returned in response to the **INQUIRY** command depends on the values for the EVPD, Page Code, and Allocation Length fields in the CDB, as described in the following sections.

Standard Inquiry Data Page

When the EVPD bit (byte 01, bit 0) is 0, the library returns either 36 bytes or 58 bytes of Standard Inquiry Data.

Bit Byte	7	6	5	4	3	2	1	0	
00	Peripheral Qualifier				Peripheral Device Type				
01	RMB	Reserved							
02	Version (03h)								
03	AERC	RSVD	Norm ACA	HiSup	Response Data Format				
04	Additional Length								
05	SCCS	ACC	ALUA		3PC	Reserved			
06	BQue	EncServ	RSV	MultiP	MChngr	Obsolete		Addr16	
07	RelAdr	Obsolete	Wbus16	Sync	Linked	Obsolete	Cmd Que	VS	
08 ... 15	(MSB) Vendor Identification (LSB)								
16 ... 31	(MSB) Product Identification (LSB)								
32 ... 35	(MSB) Firmware Revision Level (LSB)								
36 ... 55	(MSB) Vendor Specific ^a (LSB)								
56	Reserved ^a				Clocking ^a		QAS ^a	IUS ^a	
57	Reserved ^a								

a. Only returned when the library is exported by a direct-attached SCSI tape drive.

Table 5-2: Data returned on the Standard Inquiry Data page

Field Name	Value Returned	Meaning
Peripheral Qualifier	000b	The library is a single LUN device. The value of the Logical Unit Number (LUN) field in the CDB must be set to 0h.
Peripheral Device Type	08h	Identifies the library as a media changer device.
RMB	1	Indicates media is removable from the library.
Version	03h	RIM and QIP exported libraries complies to ANSI INCITS 301-1997.
	05h	ADI exported libraries complies to ANSI INCITS 408-2005 (SPC-3).
NormACA	0	The library does not support setting the Normal ACA Supported bit to 1.
HiSup	0	The library does not use the hierarchical addressing model to assign LUNs to logical units.
Response Data Format	2h	INQUIRY data returned by the library conforms to the format defined in the SPC-3 Standard.
Additional Length	31 or 53	Indicates the number of bytes of data following this byte. <ul style="list-style-type: none"> ▪ Libraries exported through QIPs or RIMs return 31 bytes of additional data (Bytes 5 through 35). ▪ Libraries exported through a direct-attached SCSI drive return 53 bytes of additional data (Bytes 5 through 57) which include information from the exporting tape drive (Bytes 36 through 57). ▪ Libraries exported through a direct-attached Fibre Channel drive return 31 bytes of additional data (Bytes 5 through 35). <p>Notes:</p> <ul style="list-style-type: none"> ▪ Not all tape libraries support direct-attached SCSI drives. ▪ Refer to the tape drive manufacturer's SCSI specification for a definition of the vendor specific bytes (Bytes 36 through 55) and the bits for clocking, QAS, and IUS in Byte 56.
SCCS	0	The library does not contain an embedded storage array controller component.
ACC	0	No access controls coordinator may be addressed through this logical unit.
ALUA	0	The SCSI target device does not support asymmetric logical unit access or vendor-specific asymmetric access. Neither the REPORT TARGET GROUPS command nor the SET TARGET GROUPS command is supported.

Table 5-2: Data returned on the Standard Inquiry Data page

Field Name	Value Returned	Meaning
3PC	0	The library does not support third-party copy or EXTENDED COPY commands. A 3PC bit of zero indicates that device support for such commands is disabled.
BQue	0	The library does not support tagged tasks (command queuing).
EncServ	0	The library does not contain an embedded enclosure services component.
VS (Vendor Specific)	0	The library does not support vendor-specific data.
MultiP	1	Two primary ports exist but may not both be populated with transceivers.
MChngr	0	The library is not embedded within or attached to a medium transport element.
Addr16	0	When the library is exported through a QIP, RIM, or direct-attached Fibre Channel tape drive, wide SCSI addressing is not supported.
	1	When the library is exported through a direct-attached SCSI drive, wide SCSI addressing is supported.
RelAdr	0	The library does not support relative addressing.
WBus16	0	When the library is exported through a QIP, RIM, or direct-attached Fibre Channel tape drive, 16-bit wide transfers are not supported.
	1	When the library is exported through a direct-attached SCSI drive, 16-bit wide transfers are supported.
Sync	0	When the library is exported through a QIP, RIM, or direct-attached Fibre Channel tape drive, synchronous data transfers are not supported.
	1	When the library is exported through a direct-attached SCSI drive, synchronous data transfers are supported.
Linked	0	The library does not support command linking.
CmdQue	0	The library does not support tagged command queuing.
Vendor Identification	SPECTRA	The left-justified ASCII representation of SPECTRA (uppercase) followed by an ASCII space character. ^a

Table 5-2: Data returned on the Standard Inquiry Data page

Field Name	Value Returned	Meaning
Product Identification	PYTHON	The left-justified ASCII representation of PYTHON (uppercase) followed by two ASCII space characters. This product identification is returned by all tape libraries. ^a
	TAOS	When you enable TAOS the product identification in all inquiry pages reports "TAOS". See "Enable Time-based Access Order System (TAOS)" in the <i>Spectra TFinity Library User Guide</i> for instructions for enabling TAOS in a partition.
Firmware Revision Level	Varies	The left-justified ASCII representation of the product firmware revision level followed by sufficient ASCII space characters (20h) to fill four bytes. For example, a firmware version of ASCII 106 requires one space character to fill the four-byte field; ASCII 2000 fills all four bytes and does not require space characters. Note: Currently, this field is fixed to 2000 to prevent operating system drivers from reloading when the firmware version changes.
Clocking	0	The device server only supports single timing.
	00b ^b	Set if the host interface speed has been set to limit transfers to 80 MB/s.
	11b ^b	Set if the host interface speed has not been set to limit transfers to 80 MB/s.
QAS	0	The device server does not support quick arbitration and selection.
IUS	0	The device server does not support information unit transfers.

a. The Vendor Identification and Product Identification data fields change when the library is configured to emulate another vendor's library.

b. Only supported in libraries exported by a direct-attached Ultra160 SCSI drive.

Supported Vital Product Data Page (Page Code 00h)

When the EVPD bit is 1 and the Page Code is 00h, the library returns the Supported Vital Product Data page. The Supported Vital Product Data page lists page codes supported by this device that supply additional Inquiry type data, as described below.

Bit Byte	7	6	5	4	3	2	1	0
00	Peripheral Qualifier			Peripheral Device Type				
01	Page Code (00h)							
02	Reserved							
03	Page Length (03h)							
04	First Page Code Supported (00h – Supported Vital Product Data page)							
05	Second Page Code Supported (80h – Unit Serial Number Data page (see page 35))							
06	Third Page Code Supported (83h – Device Identification page (see page 36))							
07	Fourth Page Code Supported (D0h – TAOS Serial Number Association page (see page 38)) Note: Supported by TFinity libraries running BlueScale12.8.0 or later.							
08	Reserved							

Unit Serial Number Data Page (Page Code 80h)

When the EVPD bit is 1 and the Page Code is 80h, the library returns the Unit Serial Number page as described below.

Bit Byte	7	6	5	4	3	2	1	0	
00	Peripheral Qualifier			Peripheral Device Type					
01	Page Code (80h)								
02	Reserved								
03	Page Length								
04	(MSB)	Unit Serial Number (ASCII)							
...									
13								(LSB)	

Table 5-3: Data returned on the Unit Serial Number Data page

Field Name	Value Returned	Meaning
Peripheral Qualifier	000b	The library is a single LUN device. The value of the Logical Unit Number (LUN) field in the CDB must be set to 0h.
Peripheral Device Type	08h	Identifies the library as a media changer device.
Page Code	80h	The current page is the Unit Serial Number Data page.
Page Length	0Ah	The length of the serial number.
Serial Number	Varies	The 10 byte null terminated ASCII representation of the library serial number.

Device Identification Page (Page Code 83h)

The Device Identification page allows the library to report its device identifiers, including its product identifier and serial number. The library returns the Device Identification page when the EVPD bit in the CDB is 1 and the Page Code is 83h

Bit Byte	7	6	5	4	3	2	1	0
00	Peripheral Qualifier				Peripheral Device Type			
01	Page Code (83h)							
02	Reserved							
03	Page Length							
04	Reserved				Code Set			
05	Reserved				Identifier Type			
06	Reserved							
07	Identifier Length							
08 ... 15	(MSB) Vendor Identification (LSB)							
16 ... 31	(MSB) Product Identification (LSB)							
32 ... 41	(MSB) Unit Serial Number (LSB)							
42	Reserved				Code Set – Node ^a			
43	Reserved	Association – Node ^a			Identifier Type – Node ^a			
44	Reserved							
45	Identifier Length – Node (8h) ^a							
46 ... 53	(MSB) Node Identifier ^a (LSB)							

a. Applicable only to Fibre Channel and Gigabit Ethernet (iSCSI) libraries. These fields are not returned on SCSI interface systems.

Table 5-4: Data returned on the Device Identification page

Field Name	Value Returned	Meaning
Peripheral Qualifier	000b	The library is a single LUN device. The value of the Logical Unit Number (LUN) field in the CDB must be set to 0h.
Peripheral Device Type	08h	Identifies the library as a media changer device.
Page Code	83h	The current page is the Device Identification page.
Page Length	26h	A library (partition) exported through a direct-attached SCSI drive returns 38 (26h) bytes following the Page Length byte. Note: Not all tape libraries support direct-attached SCSI drives.
	32h	A library (partition) exported through a QIP or RIM returns 50 (32h) bytes following the Page Length byte.
Code Set	02h	The Identifier field (bytes 08 through 43) contains ASCII data.
Identifier Type	01h	The T10 vendor ID (ASCII) Name_Identifier.
Identifier Length	22h	The identifier returned by the library is 34 (22h) bytes in length.
Vendor Identification	SPECTRA ^a	The left-justified ASCII representation of SPECTRA (uppercase) followed by an ASCII space character.
Product Identification	PYTHON ^a	The left-justified ASCII representation of PYTHON (uppercase) followed by ten ASCII space characters. This product identification is returned by all tape libraries unless emulation is configured.
Unit Serial Number	Variable ^b	The 10 byte ASCII representation of the library serial number.
Code Set — Node	01h	The Node Identifier field (bytes 48 through 55) contains binary data.
Identifier Type — Node	03h	The Node Identifier contains an FC_PH Name_Identifier (WWN) associated with the port that received the request (the node).
Identifier Length — Node	08h	The identifier returned by the library is 8 bytes in length.
Node Identifier ^c	Variable	The 64-bit WWN of the exporting QIP, RIM, or direct-attached Fibre Channel tape drive port that received the request.

a. The data returned in the Vendor Identification and Product Identification data fields changes when the library is configured to emulate another vendor's library.

b. The serial number can be up to 10 characters in length.

c. This field is valid only for libraries exported by a Fibre Channel QIP (F-QIP) or RIM and for Fibre Channel drives.

TAOS Serial Number Association Page (Page Code D0h)

The LUN1 of each tape drive in the partition reports itself as a Media Changer Device. The TAOS Serial Number Association page returns the drives' Serial Numbers. The host uses this to match the LUN1 library with the tape drive to know where to send the GTAOS and RTAOS commands. The library returns the TAOS Serial Number Association page when the EVPD bit in the CDB is 1 and the Page Code is D0h.

- Notes:**
- This page is not valid for QIP or RIM exporting media changer devices.
 - This page is supported by TFinity libraries running BlueScale12.8.0 or later. See “Enable Time-based Access Order System (TAOS)” in the *Spectra TFinity Library User Guide* for instructions for enabling TAOS in a partition.

Bit Byte	7	6	5	4	3	2	1	0
00	Peripheral Qualifier				Peripheral Device Type			
01	Page Code (D0h)							
02	Reserved							
03	Page Length							
04	Reserved				Code Set			
05	Reserved				Identifier Type			
06	Reserved							
07	Identifier Length							
08 ... 15	(MSB) Vendor Identification (LSB)							
16 ... 31	(MSB) Product Identification (LSB)							
32 ... 41	(MSB) Unit Serial Number (LSB)							

Table 5-5: Data returned on the Device Identification page

Field Name	Value Returned	Meaning
Peripheral Qualifier	000b	The library is a single LUN device. The value of the Logical Unit Number (LUN) field in the CDB must be set to 0h.
Peripheral Device Type	08h	Identifies the library as a media changer device.
Page Code	83h	The current page is the Associated Tape Drive WWN and Serial Number page.
Page Length	26h	A library (partition) exported through a direct-attached SCSI drive returns 38 (26h) bytes following the Page Length byte.
Code Set	02h	The Identifier field (bytes 08 through 43) contains ASCII data.
Identifier Type	01h	The T10 vendor ID (ASCII) Name_Identifier.
Identifier Length	22h	The identifier returned by the library is 34 (22h) bytes in length.
Vendor Identification	SPECTRA	The left-justified ASCII representation of SPECTRA (uppercase) followed by an ASCII space character.
Product Identification	TAOS	The left-justified ASCII representation of TAOS (uppercase) followed by 12 ASCII space characters. This product identification is returned by all tape libraries unless emulation is configured.
Unit Serial Number	Variable ^a	The 10 byte ASCII representation of the tape drive serial number as reported in the Read Element Status, see Read Element Status (B8h) on page 68..

a. The serial number can be up to 10 characters in length.

COMMAND STATUS

The library returns a status byte after processing the **INQUIRY** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

The library never returns Busy status for the **INQUIRY** command.

Reservation Conflict

The library never returns Reservation Conflict status for the **INQUIRY** command.

Check Condition

The library returns Check Condition status for the following reasons:

- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB is invalid (see [Table 5-6](#) for sense data).

Table 5-6: Invalid parameters in the INQUIRY CDB

Sense Key	ASC	ASC Q	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	24h	00h	1	1	0	0	00 02h	Invalid Page Code.
5h	24h	00h	1	1	1	7	00 02h	Page value set but EVPD is 0.

CHAPTER 6

Mode Select (15h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (15h)							
01	Obsolete ^a			PF	Obsolete			SP
02	Reserved							
03								
04	Parameter List Length							
05	0	0	Reserved				0	0

a. These bits are ignored.

COMMAND DESCRIPTION

The **MODE SELECT** command enables you to specify operating parameters for the library. These parameters configure the library when it is powered on or receives a Bus Device Reset message. The library supports the following **MODE SELECT** parameter list pages:

- The Element Address Assignments Page (1Dh) has the following changeable parameters:
 - Medium Transport Element Address (transporter), bytes 2–3
 - First Storage Element Address (magazine slots), bytes 6–7
 - First Import/Export Element Address (TAP), bytes 10–11
 - First Data Transfer Element Address (drives), bytes 14–15
- The Transport Geometry Page (1Eh) has no changeable parameters
- The Device Capabilities Page (1Fh) has no changeable parameters

Any changed parameters apply to all initiators in the same partition, in a multi-initiator environment. If a **MODE SELECT** is issued, the library generates a Unit Attention message to all initiators for the partition with sense information to indicate if any mode parameters changed.

- Notes:**
- Before issuing any **MODE SELECT** command, issue a **MODE SENSE** command (see [Mode Sense \(1Ah\) on page 48](#)) with the following values in the CDB:
 - **Page Code = 3Fh**—Causes the library to return all mode pages.
 - **Page Control = 01**—Causes the library to indicate which fields are changeable.
 - The recommended timeout for this command is 5 minutes or 300 seconds.

WHAT YOU SEND TO THE LIBRARY

To change parameter values, send a **MODE SELECT** command with the following parameters, followed by a parameter list in the Data Out phase.

Table 6-1: MODE SELECT CDB parameter values

Field Name	Values Allowed	Meaning
PF	1	The library supports the page format defined by the SPC-3 standard.
SP (Save Pages)	0	Current configuration values are changed to the values sent to the library. Saved values stored in nonvolatile memory are not affected. The default values are restored when the device is reset or power cycled.
	1 ^a	Current configuration values are changed to the values sent to the library and saved in nonvolatile memory.
Parameter List Length	00–FFh	<p>This field indicates the length of the entire parameter list. The parameter list length is equal to the length of one Parameter List Header (4 bytes) plus the lengths of all pages to be transferred. When the value of the parameter list length is 00h, no parameter list is transferred from the initiator. This is not considered an error. The data length for all mode parameter pages returned by the library is 48 bytes (30h).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ A parameter list length of 4 is not valid. When you send the Parameter List Header, you must send at least one page with it. ▪ Before issuing a MODE SELECT command, issue a MODE SENSE command (see Mode Sense (1Ah) on page 48) with the Page Control field set to 1 and the Page Code field set to 3Fh. This allows you to determine the supported pages, the changeable parameters within the pages, and the supported length of each page.

a. This is only allowed for page 1Dh.

Mode Parameter Lists

During the Data Out phase following the command block the initiator sends the Parameter List Header, followed by one or more parameter list pages containing the new parameter values of the library.

Parameter List Header

If you send one or more parameter pages with the **MODE SELECT** command, you must send a Parameter List Header. Do not send the Parameter List Header if you are not sending any parameter pages.

Bit Byte	7	6	5	4	3	2	1	0
00	Reserved							
01								
02								
03								

All fields of the Parameter List Header are reserved and must be set to zero.

Element Address Assignment Page (Page Code 1Dh)

The library only supports changing the element addresses.



Important

The element addresses for the elements in an element group must not overlap the addresses for other element groups.



Important

The elements in an element group (that is, cartridge slots, robotics, and drives) must be assigned contiguous addresses.



Important

Element addresses must be between 0 and 65,535 (FFFFh).

Bit Byte	7	6	5	4	3	2	1	0
00	PS	Reserved	Page Code (1Dh)					
01	Parameter Length (12h)							
02	(MSB)	Medium Transport Element Address (default=00 01h)						(LSB)
03								
04	(MSB)	Number of Medium Transport Elements ^a (fixed at 01h for all tape libraries)						(LSB)
05								
06	(MSB)	First Storage Element Address (default=10 00h)						(LSB)
07								
08	(MSB)	Number of Storage Elements ^a (depends on partition size)						(LSB)
09								
10	(MSB)	First Import/Export Element Address (default=0010h)						(LSB)
11								
12	(MSB)	Number of Import/Export Elements ^a (depends on partition configuration)						(LSB)
13								
14	(MSB)	First Data Transfer Element Address (default=0100h)						(LSB)
15								
16	(MSB)	Number of Data Transfer Elements ^a (depends on partition size)						(LSB)
17								
18	Reserved							
19								

a. The data **MUST** match the response from **MODE SENSE** page 1Dh. It cannot be set to zero.

Table 6-2: Data sent on the Element Address Assignment page

Field Name	Value	Meaning
PS (Pages Saveable)	0	The Element Address Parameter page can be saved to nonvolatile memory by setting the SP field in the MODE SELECT command.
Page Code	1Dh	Identifies the Element Address Assignment page.
Parameter List Length	12h (18)	Indicates that there are an additional 18 bytes of element address data that follow this byte.
Medium Transport Element Address	Varies	Indicates the element address for the medium transport element (the transporter). The default value is 00 01h.
Number of Medium Transport Elements	01h ^a	The library has only one medium transport element (the transporter). This is also true for libraries that may have more than one physical robot like the TFinity.
First Storage Element Address	Varies	Indicates the element address for the first storage element (magazine slot) in the logical library (partition). The default is 10 00h (4096).
Number of Storage Elements	Varies ^a	Indicates the configured number of storage locations (magazine slots) within the logical library (partition). Note: This parameter depends on partition size and cannot be changed.
First Import/Export Element Address	Varies	Indicates the element address of the first import/export element. The default is 00 10h (16).
Number of Import/Export Elements	Varies ^a	Indicates the total number of locations (slots) used for importing and exporting cartridges into and out of the logical library (partition). Notes: <ul style="list-style-type: none"> ▪ This parameter depends on partition configuration and cannot be changed. ▪ For all tape libraries except the T120 and the T50e, the import/export elements are the slots assigned to the entry/exit pool for the partition. ▪ For the T120 and the T50e libraries, the import/export elements are the slots in the entry/exit port.
First Data Transfer Element Address	Varies	Indicates the element address of the first data transfer element (a drive). The default is 01 00h (256).
Number of Data Transfer Elements	Varies ^a	Indicates the total number of data transfer elements. Note: This parameter depends on partition size and cannot be changed.

a. The data MUST match the response from **MODE SENSE** page 1Dh. It cannot be set to zero.

COMMAND STATUS

The library returns a status byte after processing the **MODE SELECT** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors (that is, when the requested **MODE SELECT** parameters have been copied over the current **MODE SELECT** settings).

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on page 112 for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- The command is issued to an invalid LUN.
- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB.
- The library detects an unrecoverable parity error while receiving the **MODE SELECT** data.
- A parameter in the CDB on a **MODE SELECT** page is invalid (see Table 6-3 for sense data).

Table 6-3: Invalid parameters in the MODE SELECT CDB and mode data

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	1Ah	00h	1	1	0	0	00 04h	Invalid Parameter List Length.
5h	21h	01h	1	0	0	0	^a	Address overlap. The field pointer is set to 00 0Ah, indicating that there is an address overlap for a Storage Element Address in the Element Address Assignment page.
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	24h	00h	1	1	1	4h	00 01h	Invalid PF (page format). Must be set to 1.
5h	26h	00h	1	0	0	0	^a	<ul style="list-style-type: none"> ▪ Invalid values in the Parameter List Header. All values must be 0. The value of the field pointer is the value of the first field that contains a non-zero value (00, 01, 02, or 03). ▪ Invalid Parameter Length. ▪ Reserved bits set in the reserved fields 22 or 23 (bytes 18 or 19 of the Element Address Assignment page). ▪ Storage element addresses are not consecutive. ▪ Address wrap. Number of elements causes the address range to wrap back to 00 00.
5h	26h	00h	1	0	1	5h	^a	Invalid Page Code.
5h	26h	00h	1	0	1	7h	^a	Reserved bits set in the first byte of one of the MODE SELECT pages.

a. Field pointer depends on the order in which the pages are sent.

CHAPTER 7

Mode Sense (1Ah)

The SPC-3 Standard provides both a 6-byte and a 10-byte **MODE SENSE** command. Spectra tape libraries only support the 6 byte **MODE SENSE** command.

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (1Ah)							
01	Obsolete ^a			Reserved	DBD	Reserved		
02	PC		Page Code					
03	Reserved							
04	Allocation Length							
05	0	0	Reserved			0	0	0

a. These bits are ignored.

COMMAND DESCRIPTION

The **MODE SENSE** command enables the library to report its operating mode parameters to the initiator. The initiator can request one or all of the supported mode pages. Each response includes four bytes for the Parameter List Header, followed by the specified number of bytes for each page:

- 20 bytes for the Element Address Assignment page (1Dh)
- 4 bytes for the Transport Geometry Descriptor page (1Eh)
- 20 bytes for the Device Capabilities page (1Fh)

These pages are described in detail under [Command Response on page 51](#).

You can change the element address parameters on the Element Address Assignment page using the **MODE SELECT** (15h) command (see [Chapter 6 – Mode Select \(15h\)](#), beginning on [page 41](#)). The Transport Geometry Descriptor page and the Device Capabilities page do not have any changeable parameters.

Note: The recommended timeout for this command is 5 minutes or 300 seconds.

WHAT YOU SEND TO THE LIBRARY

The data returned by the **MODE SENSE** command depends on the values of the parameters in the CDB.

Table 7-1: MODE SENSE CDB parameter values.

Field Name	Values Allowed	Meaning
DBD (Disable Block Descriptors)	0 or 1	The library does not return block descriptors even if requested to do so. This is not an error condition. The library always returns a block descriptor length of 0.
Page Control	0 (00b)	Requests the current parameter values. The current values returned are: <ul style="list-style-type: none"> ▪ The parameters set in the last successful MODE SELECT command. ▪ The saved values, if a MODE SELECT command has not been executed since the last power-on or reset. ▪ The default values, if saved values are not available.
	1 (01b)	Requests the changeable parameters. The pages you request are returned and indicate which parameters you can change. All bits of parameters that you can change are set to 1. All bits of parameters that you cannot change are set to 0. The Page Code and Parameter List Length fields contain actual values. Note: Before issuing a MODE SELECT command, issue a MODE SENSE command with the PC field set to 1 and the Page Code field set to 3Fh. This allows you to determine the supported pages, the changeable parameters within the pages, and the supported length of each page.
	2 (10b)	Requests default values. The pages you request are returned with the default value for each supported parameter. Parameters that are not supported by the library are set to 0.
	3 (11b)	Requests saved values. The pages you request are returned with the saved setting for each supported parameter. Parameters that are not supported by the library are set to 0. Note: If changes to the page have not been saved, the library returns the current values.
Page Code	3Fh	Requests that the library return all available mode pages.
	1Dh	Requests Element Address Assignment page only.
	1Eh	Requests Transport Geometry Parameters page only.
	1Fh	Requests Device Capabilities page only.
	00h	Not used.

Table 7-1: MODE SENSE CDB parameter values.

Field Name	Values Allowed	Meaning
Allocation Length	00–FFh	Specifies the length of the parameter list the library will return. The maximum length required to receive all pages is 60 bytes (3Ch). No mode data is transferred if you specify zero. This condition is not considered an error. The library terminates the Data In phase when it transfers either the number of bytes specified by the Allocation Length or when all available MODE SENSE data have been transferred, whichever is less.

COMMAND RESPONSE

This section describes the page structure for mode data and the pages that the library supports. The **MODE SENSE** command returns a single mode data page or all mode data pages as specified in the Page Code field of the CDB. Each mode data page begins with a four-byte Parameter List Header, followed by zero or more variable-length mode data parameters defined for the specified page.

If all mode pages are requested, the library returns 60 bytes of mode sense data to the initiator, structured as follows:

- 4 bytes of Parameter List Header data
- 20 bytes of Element Address Assignments data
- 4 bytes of Transport Geometry Descriptors data
- 20 bytes of Device Capabilities Parameters data
- 12 bytes of special “vendor” data

Note: When a specific page is requested, the library returns only the Parameter List Header data and the specified page.

Parameter List Header

6-Byte

Bit Byte	7	6	5	4	3	2	1	0
00	Mode Data Length							
01	Reserved							
02								
03								

Mode Data Length indicates the number of bytes of parameter information following the Mode Data Length byte. For the 6-Byte SCSI command, if all mode pages are requested, this value is 59 (3Bh).

Element Address Assignment Page (Page Code 1Dh)

The library returns the following data for the Element Address Assignment page. See [Elements and Element Addresses](#) on page 16 for additional information.

Note: If the library (or partition) is configured to emulate another vendor's library, the format of the element address data returned by this page may change.

Bit Byte	7	6	5	4	3	2	1	0
00	PS	Reserved	Page Code (1Dh)					
01	Parameter Length (12h)							
02	(MSB)	Medium Transport Element Address						(LSB)
03	(default=00 01h)							
04	(MSB)	Number of Medium Transport Elements						(LSB)
05	(fixed at 01h for all tape libraries)							
06	(MSB)	First Storage Element Address						(LSB)
07	(default=10 00h)							
08	(MSB)	Number of Storage Elements						(LSB)
09	(depends on partition size)							
10	(MSB)	First Import/Export Element Address						(LSB)
11	(default=0010h)							
12	(MSB)	Number of Import/Export Elements						(LSB)
13	(depends on configuration)							
14	(MSB)	First Data Transfer Element Address						(LSB)
15	(default=0100h)							
16	(MSB)	Number of Data Transfer Elements						(LSB)
17	(depends on partition size)							
18	Reserved							
19	Reserved							

Table 7-2: Data returned on the Element Address Assignment page

Field Name	Value Returned	Meaning
PS (Pages Saveable)	1	The Element Address Assignment page can be saved to nonvolatile memory by setting the SP field in the MODE SELECT command. See Chapter 6 – Mode Select (15h) , beginning on page 41 for details.
Page Code	1Dh	Identifies the Element Address Assignment page.
Parameter List Length	12h (18)	Indicates that there are an additional 18 bytes of element address data that follow this byte.
Medium Transport Element Address	Varies	Indicates the element address for the medium transport element (the transporter). The default value is 00 01h.
Number of Medium Transport Elements	01h	The library has only one medium transport element (the transporter). This is also true for libraries that may have more than one physical robot like the TFinity.
First Storage Element Address	Varies	Indicates the starting address for the storage elements (magazine slots) in the logical library (partition). The default starting address is 10 00h (4096). You can change this address with the MODE SELECT (15h) command.
Number of Storage Elements	Varies ^a	Indicates the configured number of storage locations (magazine slots) within the logical library (partition).
First Import/Export Element Address	Varies	Indicates the element address of the first import/export element. The default is 00 10h (16).
Number of Import/Export Elements	Varies ^b	Indicates the total number of locations (slots) used for importing and exporting cartridges into and out of the logical library (partition). Notes: <ul style="list-style-type: none"> ▪ For all tape libraries except the T120 and the T50e, the import/export elements are the slots assigned to the entry/exit pool for the partition. ▪ For the T120 and the T50e libraries, the import/export elements are the slots in the entry/exit port.
First Data Transfer Element Address	Varies	Indicates the element address of the first data transfer element (a drive). The default is 01 00h (256).
Number of Data Transfer Elements	Varies ^b	Indicates the total number of data transfer elements.

a. Depends on the partition size.

b. Depends on the partition configuration.

Transport Geometry Parameters (Page Code 1Eh)

The library returns the following data for the Transport Geometry Parameter page.

Note: The parameters on the Transport Geometry Parameter page cannot be changed using a **MODE SELECT** command.

Bit Byte	7	6	5	4	3	2	1	0
00	PS	Reserved	Page Code (1Eh)					
01	Parameter Length							
02	Reserved							Rotate
03	Member Number in Transport Element Set							

Table 7-3: Data returned on the Transport Geometry Parameter page

Field Name	Value Returned	Meaning
PS (Pages Saveable)	0	The Transport Geometry Parameter page cannot be saved to nonvolatile memory.
Page Code	1Eh	Identifies the Transport Geometry Parameter page.
Parameter List Length	02h	Indicates the number of additional bytes of transport geometry descriptor data that follow the header. Each descriptor consists of two bytes of information. The library has only one transport mechanism (transporter), so the value returned for this field is always 02h even for libraries that have more than one physical robot like the TFinity.
Rotate	0b	Indicates the ability of the transport mechanism to handle two-sided media. The library only uses one-sided media, so the value returned for this field is always 0.
Member Number in Transport Element Set	00h	Indicates the specific transport element in the system to which this descriptor is applied. The library has only one medium transport element, so the value returned for this field is always 0. This is true even for libraries that may have more than one physical robot like the TFinity.

Device Capabilities Page (Page Code 1Fh)

The library returns the following data for the Device Capabilities page.

Note: The parameters on the Device Capabilities page cannot be changed using a **MODE SELECT** command.

Bit Byte	7	6	5	4	3	2	1	0
00	PS	RSVD	Page Code (1Fh)					
01	Parameter Length (12h)							
02	Reserved				DT 1	I/E 1	ST 1	MT 0
03	Reserved							
04	Reserved				MT→DT 1	MT→I/E 1	MT→ST 1	MT→MT 0
05	Reserved				ST→DT 1	ST→I/E 1	ST→ST 1	ST→MT 0
06	Reserved				I/E→DT 1	I/E→I/E 1	I/E→ST 1	I/E→MT 0
07	Reserved				DT→DT 1	DT→I/E 1	DT→ST 1	DT→MT 0
08 ... 11	Reserved							
12	Reserved (0)				MT↔DT 0	MT↔I/E 0	MT↔ST 0	MT↔MT 0
13	Reserved (0)				ST↔DT 0	ST↔I/E 0	ST↔ST 0	ST↔MT 0
14	Reserved (0)				IE↔DT 0	IE↔I/E 0	IE↔MT 0	IE↔MT 0
15	Reserved (0)				DT↔DT 0	DT↔I/E 0	DT↔ST 0	DT↔MT 0
16 ... 19	Reserved							

Table 7-4: Data returned on the Device Capabilities page

Field Name	Value Returned	Meaning
PS (Pages Saveable)	0	The Device Capabilities page cannot be saved to nonvolatile memory.
Page Code	1Fh	Identifies the Device Capabilities page.
Parameter List Length	12h	Indicates the number of additional bytes of Device Capabilities data that follow the header. See Table 7-5 for the definition of abbreviations used.

The following abbreviations and definitions apply to the fields in the Device Capabilities page:

Table 7-5: Field definitions for the Device Capabilities page

Abbreviation or Symbol	Definition
DT	Data transfer element (tape drive)
IE	Import/export element (TAP)
ST	Storage element (magazine slot)
MT	Medium transport element (transporter)
Stor	A value of 1 in a StorXX bit indicates media can be stored at elements of type XX . A value of 0 indicates that they cannot. For example, the 1 in the StorDT bit indicates that media can be stored at data transfer element addresses (tape drives).
→	A value of 1 in a XX → YY bit indicates that media can be moved from elements of type XX to elements of type YY. A value of 0 indicates that media cannot be moved from elements of type XX to elements of type YY. For example, the 0 in the MT→MT bit indicates that media cannot be moved from one medium transport element to another medium transport element. This is because there is only one medium transport element.
↔	A 1 in a XX↔YY bit indicates that media can be exchanged between elements of types XX and YY. All of these values are 0 because the library does not support media exchanges.

COMMAND STATUS

The library returns a status byte after processing the **MODE SENSE** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when the library is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on page 112 for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- The command is issued to an invalid LUN.
- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB is invalid (see [Table 7-6](#) for sense data).

Table 7-6: Invalid parameters in the MODE SENSE CDB

Sense Key	ASC	ASC Q	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	24h	00	1	1	1	3h	00 01h	Invalid value in DBD field. Must be 1.
5h	24h	00	1	1	1	5h	00 02h	Invalid Page Code.

CHAPTER 8

Move Medium (A5h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (A5h)							
01	Obsolete ^a			Reserved				
02	(MSB) Transport Element Address (LSB)							
03								
04	(MSB) Source Address (LSB)							
05								
06	(MSB) Destination Address (LSB)							
07								
08	Reserved							
09								
10	Reserved							Invert
11	0	0	Reserved			0	0	0

a. These bits are ignored.

COMMAND DESCRIPTION

The **MOVE MEDIUM** command requests that the library move media from one element location to another. The locations are identified by their element addresses. For the valid source element and destination element combinations for the **MOVE MEDIUM** command, see [Device Capabilities Page \(Page Code 1Fh\)](#) on page 56.

Send a **READ ELEMENT STATUS** command to the library to determine the current element addresses and which elements contain media (see [Chapter 11 – Read Element Status \(B8h\)](#), beginning on page 68).

Note: The recommended timeout for this command is 20 minutes or 1200 seconds per library partition.

WHAT YOU SEND TO THE LIBRARY

The behavior of the library in response to the **MOVE MEDIUM** command depends on the values of the parameters in the CDB.

Table 8-1: MOVE MEDIUM CDB field values

Field Name	Values Allowed	Meaning
Transport Element Address	Varies ^a	The element address of the picker (the default is 00 01h). This value should match the value from MODE SENSE or be 00 00h.
Source Address	Varies ^a	The current element address of the slot or drive where the cartridge is located.
Destination Address ^b	Varies ^a	The element address of the slot or drive where the cartridge will be moved.
Invert	0	tape libraries use single-sided media and do not support the invert function.

a. Permitted values for the Transport Element Address, Source Address, and Destination Address can be changed with the **MODE SELECT** command (see [Chapter 6 – Mode Select \(15h\)](#), beginning on [page 41](#)). Use the **MODE SENSE** command to determine the current element address settings, including the default element addresses (see [Chapter 7 – Mode Sense \(1Ah\)](#), beginning on [page 48](#)).

b. Moves to or from the medium transport element (transporter) are not allowed.

COMMAND STATUS

The library returns a status byte after processing the **MOVE MEDIUM** command.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on [page 112](#) for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- A Unit Attention condition is pending for the initiator.
- The library has experienced an unrecoverable hardware error.
- A reserved bit is set to 1 in the CDB.
- The information in the cartridge inventory indicates that the requested cartridge move operation cannot be performed.
- After the library attempts to move a cartridge, it finds that the source is empty or the destination is occupied.
- The library encounters a problem while trying to move a cartridge. For example, it encounters a place or put error while moving a cartridge.
- A parameter in the CDB is invalid (see [Table 8-2](#) for sense data).

Table 8-2: Invalid parameters in the MOVE MEDIUM CDB and move errors

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
3h	53h	00h	0	0	0	0	0	Media load or eject failed
4h	85h	01h						Move failed; tape left in picker.
4h	85h	02h						Move failed; tape left in source.
5h	21h	01h	1	1	0	0	00 02h	Invalid transport element address.
5h	21h	01h	1	1	0	0	00 04h	Invalid source element address.
5h	21h	01h	1	1	0	0	00 06h	Invalid destination element address.
5h	24h	00	1	1	1	0	00 0Ah	Invalid Invert field.
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	3Bh	0Dh	0	0	0	0	0	Destination element is occupied.
5h	3Bh	0Eh	0	0	0	0	0	Source element is empty.
5h	3Bh	11h						Media magazine not accessible. This will only occur in libraries with TeraPack magazines.
5h	80h	05h	0	0	0	0	0	Source drive not installed.
5h	80h	06h	0	0	0	0	0	Destination drive not installed.
5h	80h	18h						Reservation conflict. Element is reserved. This occurs when the slot is reserved by the front panel for queued ejects. See Overview of T120 and T50e Entry/Exit Modes on page 95 .

CHAPTER 9

Prevent/Allow Medium Removal (1Eh)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (1Eh)							
01	Obsolete ^a				Reserved			
02								
03								
04	Reserved					Prevent		
05	0	0	Reserved			0	0	0

a. These bits are ignored.

COMMAND DESCRIPTION

The **PREVENT/ALLOW MEDIUM REMOVAL** command requests that the library enable or disable removal of media through the import/export elements.

Note: The recommended timeout for this command is 5 minutes or 300 seconds.

WHAT YOU SEND TO THE LIBRARY

The library behavior as a result of the **PREVENT/ALLOW MEDIUM REMOVAL** command depends on the value of the Prevent bit in the CDB.

Table 9-1: PREVENT/ALLOW MEDIUM REMOVAL CDB parameter values

Field Name	Values Allowed	Meaning
Prevent	0 (00b)	Media removal is allowed.
	1 (01b)	Media removal is prevented.

Note: When the Prevent bit is set to 01b, media cannot be accessed in the import/export elements until one of the following occurs:

- All initiators that have issued **PREVENT MEDIUM REMOVAL** commands issue **ALLOW MEDIUM REMOVAL** commands with the Prevent bit set to 0.
- The library is reset.

COMMAND STATUS

The library returns a status byte after processing the **PREVENT/ALLOW MEDIUM REMOVAL** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator and a request is made to prevent medium removal. See [Chapter 15 – Reserve \(16h\)](#), beginning on [page 112](#) for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status when:

- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB

Table 9-2: Invalid parameters in the PREVENT/ALLOW MEDIUM REMOVAL CDB

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers show the bit in error.

CHAPTER 10

Read Buffer (3Ch)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (3Ch)							
01	Reserved			Mode				
02	Buffer ID (00h)							
03	Buffer Offset (00h, 00h, 00h)							
...								
05								
06	Allocation Length (00h, 00h, 10h)							
...								
08								
09	0	0	Reserved			0	0	0

COMMAND DESCRIPTION

The **READ BUFFER** command is only provided to retrieve the library's serial number, IP address, library name, and partition name.

This library serial number is the same as the BlueScale license serial number used to issue license keys for BlueScale features. This serial number is different than the one reported from the **INQUIRY** command. This value is not changeable.

Note: The recommended timeout for this command is 20 minutes or 1200 seconds.

What You Send to the Library

The following parameters set the **READ BUFFER** command to retrieve the library's serial number.

Table 10-1: READBUFFER CDB field values

Field Name	Values Allowed	Meaning
Mode	02h	Set mode to data only. This is the preferred method.
	03h	Set mode to descriptor only.
Buffer ID	00h	Specifies the buffer ID for the library serial number.
Buffer Offset	00 00 00 h	Specifies the buffer offset for the library serial number. The library does not support buffer offsets. This value must be set to 0.
Allocation Length	00 00 10 h	Specifies the length of the data returned. For the library serial number, the recommended value is 00 00 10h.

The following parameters set the **READ BUFFER** command to retrieve the library's IP address, library name, and partition name.

Table 10-2: READBUFFER CDB field values

Field Name	Values Allowed	Meaning
Mode	02h	Set mode to data only. This is the preferred method.
	03h	Set mode to descriptor only.
Buffer ID	01h	Specifies the buffer ID for the library IP address, library name, and partition name.
Buffer Offset	00 00 00 h	Specifies the buffer offset for the data returned. The library does not support buffer offsets. This value must be set to 0.
Allocation Length	00 00 66 h	Specifies the length of the data returned. For the library's IP address, library name, and partition name, the value is 00 00 66 h.

COMMAND RESPONSE

For Buffer ID 00h, the 16-byte response returned by the library is the library serial number, left justified with trailing zeros (0).

For Buffer ID 01h, the data returned is:

- Four bytes of IP address
- 65 bytes for the Library Name
- 33 bytes for the Partition Name

COMMAND STATUS

The library returns a status byte after processing the **READ BUFFER** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when the library is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on [page 112](#) for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- The command is issued to an invalid LUN.
- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB is invalid (see [Table 10-3](#) for sense data).

Table 10-3: Invalid parameters in the MODE SENSE CDB

Sense Key	ASC	ASC Q	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	24h	00	1	1	1	3h	00 01h	Invalid value in DBD field. Must be 1.
5h	24h	00	1	1	1	5h	00 02h	Invalid Page Code.

CHAPTER 11

Read Element Status (B8h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (B8h)							
01	Obsolete ^a			VolTag	Element Type Code			
02	(MSB) Starting Element Address							
03	(LSB)							
04	(MSB) Number of Elements							
05	(LSB)							
06	Reserved					CurData	DVCID	
07	(MSB) Allocation Length							
08								
09	(LSB)							
10	Reserved							
11	0	0	Reserved		0	0	0	

a. These bits are ignored.

COMMAND DESCRIPTION

The **READ ELEMENT STATUS** command requests that the library return the status of the selected elements in the library. An element's status includes its element address, element type, whether it contains media, whether it is accessible, and whether it is in an abnormal state.

Note: The recommended timeout for this command is 20 minutes or 1200 seconds.

- If the VolTag bit is set, media barcode information is also returned.

- If **Include tape generation in Read Element Status** is selected on the BlueScale Advanced Partition Settings screen (see the *User Guide* for your library for information on accessing the screen), Media Domain, Media Type, Drive Domain, and Drive Type are included. See [Media Domain on page 82](#), [Media Type^c on page 83](#), [Drive Domain^d on page 89](#), and [Drive Type^d on page 89](#) for details. This information may be needed by some storage management software.

Advanced Partition Settings

<< Previous Cancel >> Next

These settings allow you to control the library emulation for the partition. Choose a preset user emulation or choose "USER DEFINED" and enter the Vendor and Model below.

Emulation: Use preset: SPECTRA PYTHON ▾

Use custom: Vendor:

Model:

Note: Select the STK L700 preset when configuring the partition for use with StorNext software.

Emulation Options: Include tape generation in Read Element Status

Figure 1 Enable including media and drive generation information in the Read Element Status on the BlueScale Advanced Partition Settings screen.

- **For TFinity libraries only**, If **Enable media zone information** is selected on the BlueScale Advanced Partition Settings screen (see the *Spectra TFinity Library User Guide* for information on accessing the screen), zone information and TeraPack barcodes are included. See *TFinity Libraries with Enable Media Zoning Selected* on page 98 for details.

Note: To fully take advantage of this feature, the partition requires more than one exporting RIM.

Figure 2 Use the BlueScale Advanced Partition Settings screen to enable including zone information and TeraPack barcodes in the Read Element Status.

What You Send to the Library

The data returned by the **READ ELEMENT STATUS** command depends on the values of the parameters in the CDB.

Table 11-1: READ ELEMENT STATUS CDB parameter values


Field Name	Values Allowed	Meaning
VolTag	0	Do not return volume tag (barcode label) information.
	1	Return volume tag (barcode label) information.  Important: VolTag must be set to 1 if you want the library to return the barcode label information for the media at the specified element address.
Element Type Code	0h	Return status for all element types. For an Element Type Code of 0h, the element types are reported in element address order, beginning with the Starting Element Address. ^a
	1h	Return status for the Medium Transport Element (transporter).
	2h	Return status for the Storage Elements (magazine slots).
	3h	Return status for the I/E Port Elements (TAP).
	4h	Return status for the Data Transfer Elements (drives).
Starting Element Address	Varies ^a	Indicates the element address at which to start the transfer of data. Only data for elements of the specified type with addresses greater than or equal to the starting address are reported.
Number of Elements	Varies ^b	Specifies the maximum number of element descriptors to be returned. This is the actual number of element descriptors to be returned, not an element address range. The largest value supported is FFFFh. Specifying FFFFh will return all elements with addresses greater than or equal to the starting element address.
CURDATA	—	The CURDATA (current data) bit determines whether the library allows device motion in order to update element status. This bit is ignored because the library maintains an updated inventory.
DVCID	0	The library will not return device identifiers.
	1	The library will return device identifiers, if available. Currently, only the Data Transfer Element Descriptor provides the device identifier information.

Table 11-1: READ ELEMENT STATUS CDB parameter values

Field Name	Values Allowed	Meaning
Allocation Length	Any ^b	<p>Specifies the amount of space, in bytes, that you are allocating for the element descriptors returned by the command. Only complete element descriptors are returned.</p> <p>An Allocation Length of at least 8-bytes is required to get the Element Status Header. A smaller Allocation Length will return a sense code of 5,24,0, or no error and no data, depending on the library interface.</p> <p>To request the Element Status Header and the Element Status Page header, use an Allocation Length of 16-bytes.</p> <p>To get the Element Status Header, the Element Status Page Header, the Element Status Page, you must request 16 bytes plus the Element Descriptor size, which is dependent on the element and the options supplied in the CDB.</p> <p>The library returns element descriptors until one of the following conditions is met:</p> <ul style="list-style-type: none"> ▪ All available element descriptors have been returned. ▪ The number of element descriptors specified in the Number of Elements field has been returned. ▪ The remaining Allocation Length is smaller than the next complete element descriptor or header to be returned.

a. The Starting Element Address can be from zero to the maximum number for the type of element. Permitted values for the Starting Element Address can be changed with the MODE SELECT command (see [Chapter 6 – Mode Select \(15h\)](#), beginning on [page 41](#)). Use the MODE SENSE command to determine the current element address settings, including the default element addresses (see [Chapter 7 – Mode Sense \(1Ah\)](#), beginning on [page 48](#)).

b. Setting these fields to zero does not constitute an error.

COMMAND RESPONSE

This section describes the Element Status page structure and the element descriptors that the library supports.

The **READ ELEMENT STATUS** command returns an eight-byte header followed by one Element Status Page for each group of element descriptors of the same type.

Each Element Status Page contains a header and Element Descriptors for each element reported. Each Element Type has a different format, and the data size varies by element type, and options enabled on the library, such as **Enable media zone information**. The header defines this information for each element type. The following sections illustrate the Element Descriptors for each element type.

Element Status Header

This header is returned once for each **READ ELEMENT STATUS** command received by the library.

Bit Byte	7	6	5	4	3	2	1	0
00	(MSB) First Element Address Reported							(LSB)
01								
02	(MSB) Number of Elements Reported							(LSB)
03								
04	Reserved							
05	(MSB) Byte Count of Element Status Pages for Elements that Meet CDB Requirements							(LSB)
06	(does not include this header)							
07								

Table 11-2: Element Status Header parameter values returned for the READ ELEMENT STATUS command

Field Name	Value Returned	Meaning
First Element Address Reported	Varies ^a	Indicates the smallest element address found that meets the CDB requirements.
Number of Elements Reported	Varies	Indicates the total number of elements that meet the CDB requirements. If the Element Type Code parameter is 0, this number will be the total number of elements in the library. If the Element Type Code is 1, 2, 3, or 4, this number will be the number of elements of the specified type (see Element Type Code on page 71). The library returns element descriptors for all of these elements if you specified a sufficient Allocation Length.
Byte Count of Element Status Pages for Elements that Meet CDB Requirements	Varies	Indicates the total number of bytes of element status page data available for the element types specified in the RES command. This value is not adjusted to match the value that you specified for the Allocation Length field in the CDB, but reports the total bytes available for the element type specified.

- a. The Starting Element Address can be from zero to the maximum number for the type of element. Permitted values for the Starting Element Address can be changed with the MODE SELECT command (see [Chapter 6 – Mode Select \(15h\)](#), beginning on [page 41](#)). Use the MODE SENSE command to determine the current element address settings, including the default element addresses (see [Chapter 7 – Mode Sense \(1Ah\)](#), beginning on [page 48](#)).

Element Status Pages

The Element Status Header is followed immediately by Element Status Pages for each element descriptor type reported. Each Element Status Page consists of a header and, if the Allocation Length allows, one or more Element Descriptor(s) for the element type indicated in the header.

The Element Status Page is only returned if the element type exists in the library.

Bit Byte	7	6	5	4	3	2	1	0
00	Element Type Code							
01	PVolTag	AVolTag	Reserved					
02	(MSB) Element Descriptor Length							
03	(depends on VolTag bit and DVCID bit settings) (LSB)							
04	Reserved							
05	(MSB) Byte Count of Descriptor Data Available							
06	(For this Element Status Page only, not including this header, $n-7$)							
07	(LSB)							
8	(MSB)							
...	Element Descriptor(s)							
n	(Length depends on element type, see descriptions below) (LSB)							

Table 11-3: Parameter values returned in the Element Status Page header

Field Name	Value Returned	Meaning
Element Type Code	1h	This page reports the Medium Transport Element (transporter).
	2h	This page reports the Storage Elements (magazine slots).
	3h	This page reports the I/E Port Elements (TAP).
	4h	This page reports the Data Transfer Elements (drives).
PVolTag	0	Indicates that the primary volume tag (barcode) information is omitted from the element descriptors that follow.
	1	Indicates that the primary volume tag (barcode) information field is present in each of the element descriptors that follow.
AVolTag	0	Not supported

Table 11-3: Parameter values returned in the Element Status Page header

Field Name	Value Returned	Meaning
Element Descriptor Length	Varies	Indicates the number of bytes returned for each element descriptor of this type returned by the command. This is dependent on the value of PVolTag and DVCID sent in the command. In addition, this value is also dependent on whether Include tape generation in Read Element Status and Enable media zone information are selected for the partition.
Byte Count of Descriptor Data Available	Varies	Indicates the total number of bytes of element descriptor data available for the element types specified in the RES command. This value is not adjusted to match the value that you specified for the Allocation Length field in the CDB, but reports the total bytes available for the element type specified.
Element Descriptor(s)	Varies	See <ul style="list-style-type: none"> ▪ Medium Transport Element Descriptor on page 76 ▪ Storage Element Descriptor on page 80 ▪ Data Transfer Element Descriptor on page 84 ▪ Import/Export Element Descriptor on page 91

ELEMENT DESCRIPTORS

Following each Element Status Page header are one or more Element Descriptors, one for each element reported of the type identified by the Element Type Code in the header. Each element descriptor includes the element address and element status. An element descriptor can also contain sense code information as well as other information, depending on the element type. The data returned depends on the value of PVolTag and DVCID sent in the command as well as whether **Include tape generation in Read Element Status** and **Enable media zone information** are selected for the partition.

Note: The element descriptors for the elements are very similar, with the exception of a few of the fields. Note the differences in bytes 02, 06, and 07 for the element descriptors.

The four types of Element Status Pages are:

- [Medium Transport Element Descriptor on page 76](#)
- [Storage Element Descriptor on page 80](#)
- [Data Transfer Element Descriptor on page 84](#)
- [Import/Export Element Descriptor on page 91](#)

Medium Transport Element Descriptor

The medium transport element is the transporter (robot). The library contains one medium transport element (even if it contains two robots), for which it returns the following medium transport element descriptor.

Bit Byte	7	6	5	4	3	2	1	0
00	(MSB) Element Address (LSB)							
01								
02	Reserved				Except	Reserved	Full	
03	Reserved							
04	Additional Sense Code							
05	Additional Sense Code Qualifier							
06	Reserved							
07								
08								
09	SValid	Invert	Reserved					
10	(MSB) Source Storage Element Address (LSB)							
11								
12	Primary Volume Tag Information (field omitted if PVolTag = 0)							
...								
47								
48	Reserved (field moved up if PVolTag = 0)							
...								
51								
52	Media Domain (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
53	Media Type (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
54 to 55	Reserved (00h, 00h) (field moved up if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen. Field moved up if PVolTag = 0)							

Table 11-4: Parameter values returned in the Medium Transport Element descriptor

Field Name	Value Returned	Meaning
Element Address	Varies	Shows the current element address of the medium transport element (the transporter). The default element address is 00 01h.
Except	0	Indicates that the medium transport element is in a normal state. Note: The Except bit is never set, even when there is a problem with the robotics. Check Sense Data for move commands to determine robotic problems.
Full	0	Indicates that the medium transport element does not contain media. Note: The Medium Transport Element will never show the Full bit set, even if media is physically loaded.
Additional Sense Code (ASC)	Varies	The ASC and ASCQ together may provide more information about the condition that caused the Except bit to be set to 1.
Additional Sense Code Qualifier (ASCQ)	Varies	Their meaning here is the same as the ASC and ASCQ returned to the REQUEST SENSE command. See Appendix A – Error Reporting , beginning on page 119 for information about the meanings of all ASC/ASCQ combinations.
SValid (Source Valid)	0	Not used for this element.
Invert	0	The Spectra Tape Libraries do not support two-sided media and do not invert the media. This bit is always 0.
Source Storage Element Address	0	Not used for this element.
Primary Volume Tag Information	Varies ^a	Null or space padded depending on the interface (ADI/QIP/RIM). Note: There is rarely a barcode associated with the medium transport element.
Media Domain ^b	43h	Indicates that the element contains a cleaning cartridge.
	4Ch	Indicates that the element contains an LTO cartridge.
	4Ah	Indicates that the element contains a TS11x0 technology cartridge.
	FFh	Indicates that there is no media present or the media domain cannot be determined.

Table 11-4: Parameter values returned in the Medium Transport Element descriptor

Field Name	Value Returned	Meaning
Media Type ^c <ul style="list-style-type: none"> Media Type with Media Domain 43h (cleaning) 	55h	Indicates a universal LTO cleaning cartridge.
	FEh	Indicates a universal TS11x0 technology cleaning cartridge.
	FFh	Indicates the media type cannot be determined.
<ul style="list-style-type: none"> Media Type with Media Domain 4Ch (LTO) 	31h	Indicates an LTO Generation 1 cartridge.
	32h	Indicates an LTO Generation 2 cartridge.
	33h	Indicates an LTO Generation 3 cartridge.
	34h	Indicates an LTO Generation 4 cartridge.
	35h	Indicates an LTO Generation 5 cartridge.
	36h	Indicates an LTO Generation 6 cartridge.
	37h	Indicates an LTO Generation 7 cartridge.
	38h	Indicates an LTO Generation 8 or M8 cartridge.
<ul style="list-style-type: none"> Media Type with Media Domain 4Ah (TS11x0 technology) 	FFh	Indicates the media type cannot be determined.
	43h	Indicates a JC cartridge.
	44h	Indicates a JD cartridge.
	45h	Indicates a JE cartridge.
<ul style="list-style-type: none"> Media Type with Media Domain FFh 	FFh	Indicates that there is no media present or the media domain cannot be determined.

a. The library reports the right most 16 characters of barcode data. It is important to make sure that the checksum barcode options are set correctly for the barcodes used. See “Configure Barcode Reporting” or “Select Barcode Options” in your library *User Guide*.

b. This field is omitted if **Include tape generation in Read Element Status** is not selected on the BlueScale Advanced Partition Settings screen.

Storage Element Descriptor

Each magazine slot in the library is a storage element. For each storage element, the library returns the following storage element descriptor.

Bit Byte	7	6	5	4	3	2	1	0
00	(MSB) Element Address (LSB)							
01								
02	Reserved			Access	Except	RSVD	Full	
03	Reserved							
04	Additional Sense Code							
05	Additional Sense Code Qualifier							
06	Reserved							
07								
08								
09	SValid	Invert	Reserved		Element Disabled	Reserved		
10	(MSB) Source Storage Element Address/Media Zone (LSB)							
11								
12 ... 47	Primary Volume Tag Information (field omitted if PVolTag = 0)							
48 ... 51	Reserved (field moved up if PVolTag = 0)							
52	Media Domain (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
53	Media Type (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
54 to 55	Reserved (00h, 00h) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
n ... n+19	(MSB) TFinity libraries with Enable media zone information selected on the Advanced Partitions screen also return TeraPack barcode information. See TFinity Libraries with Enable Media Zoning Selected on page 98 for more information. (LSB)							

Table 11-5: Parameter values for the Storage Element descriptor

Field Name	Value Returned	Meaning
Element Address	Varies ^a	Shows the address of the storage location (the cartridge slot).
Access	0	Indicates that the medium transport element cannot access the media at the storage location. This is possible when there is not a magazine in the specified location or the slot is reserved by the front panel. If the slot is reserved by the front panel, the Except bit will be set and the ASC and ASCQ values will be set to 80h, 18h.
	1	Indicates that the medium transport element can access the media at the storage location.
Except	0	Indicates that the storage element is in a normal state. Any data in the Additional Sense Code and Additional Sense Code Qualifier fields is invalid.
	1	Indicates that the storage element is in some sort of abnormal state or the element is reserved by the front panel for queued ejects. See Overview of T120 and T50e Entry/Exit Modes on page 95 for a description of queued ejects. More information on the nature of the exception is available in the Additional Sense Code and Additional Sense Code Qualifier fields.
Full	0	Indicates that the storage element does not contain media.
	1	Indicates that the storage element contains media.
Additional Sense Code (ASC)	Varies	The ASC and ASCQ together may provide more information about the condition which caused the Except bit to be set to 1. Their meaning here is the same as the ASC and ASCQ returned to the REQUEST SENSE command. For a listing of the meanings of all ASC-ASCQ combinations, see Appendix A – Error Reporting , beginning on page 119.
Additional Sense Code Qualifier (ASCQ)	Varies	

Table 11-5: Parameter values for the Storage Element descriptor

Field Name	Value Returned	Meaning
SValid (Source Valid)	0	Indicates that the value in the Source Storage Element Address field is not valid.
	1	Indicates that the value in the Source Storage Element Address field is a valid source element address.
<ul style="list-style-type: none"> Without Media Zoning enabled 	0	Indicates that the Source Storage Element Address field is used to convey zoning information (see TFinity Libraries with Enable Media Zoning Selected on page 98).
<ul style="list-style-type: none"> With Media Zoning Enabled (TFinity library only) 	0	Indicates that the Source Storage Element Address field is used to convey zoning information (see TFinity Libraries with Enable Media Zoning Selected on page 98).
Invert	0	The tape libraries do not support two-sided media and do not invert the media. This bit is always 0.
Element Disabled	1	Rely on the Access bit rather than the Element Disabled bit. Note: May only be returned if the robotic control path for the partition is provided by a tape drive.
Source Storage Element Address without Media Zoning enabled	Varies ^a	Shows the storage element address where the media was previously located.
Source Storage Element Address with Media Zoning enabled (TFinity library only)	0	The element is stored in the left half of the library as viewed from the front.
	1	The element is stored in the right half (which includes the center frame if the number of frames is odd) of the library as viewed from the front.
Primary Volume Tag Information	Varies ^b	<ul style="list-style-type: none"> If the PVolTag bit in the data header is 1, this field contains the 36-byte barcode label (volume tag) information for the media occupying this location. The barcode is left justified and is padded to the right with spaces (0x20) or NULL depending on the interface. If the barcode does not exist or is not readable, the entire field is space (0x20) padded or NULL. If the PVolTag bit is 0, this field is omitted entirely.
Media Domain ^c	43h	Indicates that the element contains a cleaning cartridge.
	4Ch	Indicates that the element contains an LTO cartridge.
	4Ah	Indicates that the element contains a TS11x0 technology cartridge.
	FFh	Indicates that there is no media present or the media domain cannot be determined.

Table 11-5: Parameter values for the Storage Element descriptor

Field Name	Value Returned	Meaning
Media Type ^c <ul style="list-style-type: none"> Media Type with Media Domain 43h (cleaning) 	55h	Indicates a universal LTO cleaning cartridge.
	FEh	Indicates a universal TS11x0 technology cleaning cartridge.
	FFh	Indicates the media type cannot be determined.
<ul style="list-style-type: none"> Media Type with Media Domain 4Ch (LTO) 	31h	Indicates an LTO Generation 1 cartridge.
	32h	Indicates an LTO Generation 2 cartridge.
	33h	Indicates an LTO Generation 3 cartridge.
	34h	Indicates an LTO Generation 4 cartridge.
	35h	Indicates an LTO Generation 5 cartridge.
	36h	Indicates an LTO Generation 6 cartridge.
	37h	Indicates an LTO Generation 7 cartridge.
	38h	Indicates an LTO Generation 8 or M8 cartridge.
	FFh	Indicates the media type cannot be determined.
<ul style="list-style-type: none"> Media Type with Media Domain 4Ah (TS11x0 technology) 	43h	Indicates a JC cartridge.
	44h	Indicates a JD cartridge.
	45h	Indicates a JE cartridge.
	FFh	Indicates the media type cannot be determined.
<ul style="list-style-type: none"> Media Type with Media Domain FFh 	FFh	Indicates that there is no media present or the media domain cannot be determined.

a. The Range of Values is supported by the MODE SELECT command.

b. The library reports the right most 16 characters of barcode data. It is important to make sure that the checksum barcode options are set correctly for the barcodes used. See “Configure Barcode Reporting” or “Select Barcode Options” in your library *User Guide*.

c. This field is omitted if **Include tape generation in Read Element Status** is not selected on the BlueScale Advanced Partition Settings screen.

Data Transfer Element Descriptor

The descriptor returned depends on whether DVCID is 0 or 1.

For DVCID = 0, the library returns the following data transfer element descriptor for each drive installed.

Bit Byte	7	6	5	4	3	2	1	0
00	(MSB) Element Address (LSB)							
01								
02	Reserved			Access	Except	Reserved	Full	
03	Reserved							
04	Additional Sense Code							
05	Additional Sense Code Qualifier							
06	Obsolete	Reserved	Obsolete	Obsolete	Reserved	Obsolete		
07	Obsolete							
08	Reserved							
09	SValid	Invert	Reserved					
10	(MSB) Source Storage Element Address/ Zone Number (LSB)							
11								
12	Primary Volume Tag Information (omitted if PVolTag = 0)							
...								
47								
48	Reserved (field moved up if PVolTag = 0)							
...								
51								
52	Media Domain (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
53	Media Type (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
54	Drive Domain (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
55	Drive Type (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
56	(MSB) Device Identifier (Only returned if the robotic control path for the partition is provided by a tape drive. Field moved up if PVolTag = 0) (LSB)							
...								
87								

For DVCID = 1, the library returns the following data transfer element descriptor for each drive installed.

Bit Byte	7	6	5	4	3	2	1	0
00	(MSB) Element Address (LSB)							
01								
02	Reserved			Access	Except	Reserved	Full	
03	Reserved							
04	Additional Sense Code							
05	Additional Sense Code Qualifier							
06	Obsolete	Reserved	Obsolete	Obsolete	Reserved	Obsolete		
07	Obsolete							
08	Reserved							
09	SValid	Invert	Reserved					
10	(MSB) Source Storage Element Address (LSB)							
11								
12	Primary Volume Tag Information (omitted if PVolTag = 0)							
...								
47								
48								
49	Reserved			Identifier Type (field moved up if PVolTag=0)				
50	Reserved (field moved up if PVolTag = 0)							
51	Identifier Length (1Eh) (field moved up if PVolTag = 0)							
52	(MSB) Device Identifier (field moved up if PVolTag = 0) (LSB)							
...								
83								
84	Media Domain (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
85	Media Type (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
86	Drive Domain (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
87	Drive Type (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							

Table 11-6: Parameter values for the Data Transfer Element descriptor

Field Name	Value Returned	Meaning
Element Address	Varies ^a	Shows the address for the data transfer element (drive).
Access	0	Indicates that the medium transport element cannot access the drive.
	1	Indicates that the medium transport element can access the drive.
Except	0	Indicates that the drive is in a normal state. Any data in the Additional Sense Code and Additional Sense Code Qualifier fields is invalid.
	1	Indicates that the drive is in some sort of abnormal state. More information on the nature of the exception is available in the Additional Sense Code and Additional Sense Code Qualifier fields.
Full	0	Indicates that the drive does not contain media.
	1	Indicates that the drive contains media.
ASC	Varies	The ASC and ASCQ together may provide more information about the condition which caused the Except bit to be set to 1. Their meaning here is the same as the ASC and ASCQ returned to the REQUEST SENSE command. For a listing of the meanings of all ASC-ASCQ combinations, see Appendix A – Error Reporting , beginning on page 119 .
ASCQ		

Table 11-6: Parameter values for the Data Transfer Element descriptor

Field Name	Value Returned	Meaning
SValid (Source Valid)	0	Indicates that the value in the Source Storage Element Address field is not valid.
	1	Indicates that the value in the Source Storage Element Address field is a valid source element address.
<ul style="list-style-type: none"> Without Media Zoning enabled 	0	Indicates that the Source Storage Element Address field is used to convey zoning information (see TFinity Libraries with Enable Media Zoning Selected on page 98).
	1	Indicates that a tape is loaded in the drive.
Invert	0	The tape libraries do not support two-sided media and do not invert the media. This bit is always 0.
Source Storage Element Address	Varies ^a	Shows the storage element address where the media was previously located.
<ul style="list-style-type: none"> Without Media Zoning enabled 	0	The drive is in the left half of the library as viewed from the front (see TFinity Libraries with Enable Media Zoning Selected on page 98).
	1	The drive is in the right half (which includes the center frame if the number of frames is odd) of the library as viewed from the front (see TFinity Libraries with Enable Media Zoning Selected on page 98).
<ul style="list-style-type: none"> With Media Zoning Enabled (TFinity library only) and SValid is 0 	0	The drive is in the left half of the library as viewed from the front (see TFinity Libraries with Enable Media Zoning Selected on page 98).
<ul style="list-style-type: none"> With Media Zoning Enabled (TFinity library only) and SValid is 1 	1	The drive is in the right half (which includes the center frame if the number of frames is odd) of the library as viewed from the front (see TFinity Libraries with Enable Media Zoning Selected on page 98).
<ul style="list-style-type: none"> With Media Zoning Enabled (TFinity library only) and SValid is 1 	Varies ^a	Shows the storage element address where the media was previously located.
Primary Volume Tag Information	Varies ^b	<ul style="list-style-type: none"> If the PVolTag bit in the data header is 1, this field contains the 36-byte barcode label (volume tag) information for the media occupying this location. The barcode is left justified and is padded to the right with spaces (0x20) or NULL depending on the interface. If the barcode does not exist or is not readable, the entire field is space (0x20) padded or NULL. If the PVolTag bit is 0, this field is omitted entirely.
CodeSet	0	When the DVCID = 0, the Identifier field is not valid.
	2	When DVCID = 1 and CodeSet = 2, the Identifier field (bytes 52 through 83) contains ASCII data.
Identifier Type	1	The identifier is the drive serial number. Note: This definition is not consistent with the SCSI communication protocol.

Table 11-6: Parameter values for the Data Transfer Element descriptor

Field Name	Value Returned	Meaning
Identifier Length ^c	00h	The drive identifier is omitted.
	20h	The drive identifier is 32 bytes in length.
Device Identifier	Varies ^c	The 32 byte null terminated ASCII representation of the Spectra Logic drive serial number.
Media Domain ^d	43h	Indicates that the element contains a cleaning cartridge.
	4Ch	Indicates that the element contains an LTO cartridge.
	4Ah	Indicates that the element contains a TS11x0 technology cartridge.
	FFh	Indicates that there is no media present or the media domain cannot be determined.
Media Type ^c ▪ Media Type with Media Domain 43h (cleaning)	55h	Indicates a universal LTO cleaning cartridge.
	FEh	Indicates a universal TS11x0 technology cleaning cartridge.
	FFh	Indicates the media type cannot be determined.
▪ Media Type with Media Domain 4Ch (LTO)	31h	Indicates an LTO Generation 1 cartridge.
	32h	Indicates an LTO Generation 2 cartridge.
	33h	Indicates an LTO Generation 3 cartridge.
	34h	Indicates an LTO Generation 4 cartridge.
	35h	Indicates an LTO Generation 5 cartridge.
	36h	Indicates an LTO Generation 6 cartridge.
	37h	Indicates an LTO Generation 7 cartridge.
	38h	Indicates an LTO Generation 8 or M8 cartridge.
FFh	Indicates the media type cannot be determined.	
▪ Media Type with Media Domain 4Ah (TS11x0 technology)	43h	Indicates a JC cartridge.
	44h	Indicates a JD cartridge.
	45h	Indicates a JE cartridge.
	FFh	Indicates the media type cannot be determined.
▪ Media Type with Media Domain FFh	FFh	Indicates that there is no media present or the media domain cannot be determined.

Table 11-6: Parameter values for the Data Transfer Element descriptor

Field Name	Value Returned	Meaning
Drive Domain ^d	4Ch	Indicates that the element contains an LTO drive.
	4Ah	Indicates that the element contains a TS11x0 technology drive.
	54h	Indicates that the element contains a T10K drive.
	FFh	Indicates that the element is empty or the drive type cannot be determined.
Drive Type ^d ▪ Drive Type with Drive Domain 4Ch (LTO)	31h	Indicates an IBM LTO Generation 1 drive.
	33h	Indicates an HP LTO Generation 2 drive.
	34h	Indicates an IBM LTO Generation 2 drive.
	36h	Indicates an HP LTO Generation 3 drive.
	37h	Indicates an IBM LTO Generation 3 drive.
	3Ah	Indicates an IBM LTO Generation 4 drive.
	3Ch	Indicates an IBM LTO Generation 5 drive.
	3Eh	Indicates an IBM LTO Generation 6 drive.
	2Dh	Indicates an IBM LTO Generation 7 drive.
	2Eh	Indicates an IBM LTO Generation 8 drive.
	FFh	Indicates the drive type cannot be determined.
▪ Drive Type with Drive Domain 4Ah (TS11x0 technology)	43h	Indicates a TS1140 technology drive.
	44h	Indicates a TS1150 or TS1155 technology drive.
	45h	Indicates a TS1160 technology drive.
	FFh	Indicates the drive type cannot be determined.
▪ Drive Type with Drive Domain 54h (T10K)	FFh	Indicates the drive type cannot be determined.
▪ Drive Type with Drive Domain FFh	FFh	Indicates that the element is empty or the drive type cannot be determined.

- a. Refer to [Chapter 6 – Mode Select \(15h\)](#), beginning on [page 41](#) for information about the valid values for the element addresses.
- b. The library reports the right most 16 characters of barcode data. It is important to make sure that the checksum barcode options are set correctly for the barcodes used. See “Configure Barcode Reporting” or “Select Barcode Options” in your library *User Guide*.
- c. The identifier is omitted if DVCID (in the Read Element Status CDB) was set to 0 (as is shown by the 00h return for Identifier Length).
- d. This field is omitted if **Include tape generation in Read Element Status** is not selected on the BlueScale Advanced Partition Settings screen.

Import/Export Element Descriptor

The import/export element is used to import tape cartridges into or export tape cartridges from the library.

- For all tape libraries other than T120 and the T50e, the import/export elements are the slots assigned to the entry/exit pool during partition creation. It is possible not to have any import/export elements assigned.
- For the T120 and the T50e, the import/export elements are the physical slots in the entry/exit port. See [Overview of T120 and T50e Entry/Exit Modes](#) on page 95 for more information.

Bit Byte	7	6	5	4	3	2	1	0
00	(MSB) Element Address (LSB)							
01								
02	Reserved	CMC	InEnab	ExEnab	Access	Except	ImpExp	Full
03	Reserved							
04	Additional Sense Code							
05	Additional Sense Code Qualifier							
06	Reserved							
07								
08								
09	SValid	Invert	Reserved					
10	(MSB) Source Storage Element Address/Zone Number (LSB)							
11								
12 ... 47	Primary Volume Tag Information (field omitted if PVolTag = 0)							
48	Reserved				Code Set			
49	Reserved				Identifier Type			
50	Reserved							
51	Identifier Length							
52	Media Domain (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							
53	Media Type (field moved up if PVolTag = 0) (field omitted if Include tape generation in Read Element Status is not selected on the BlueScale Advanced Partition Settings screen)							

Bit Byte	7	6	5	4	3	2	1	0
54 to 55	Reserved (00h, 00h) (field omitted if PVoITag = 0)							
n	(MSB) TFinity libraries with Enable media zone information selected on the Advanced Partitions screen also return TeraPack barcode information. See TFinity Libraries with Enable Media Zoning Selected on page 98 for more information.							
...								
n+19								

Table 11-7: Parameter values for the Import/Export element descriptor.

Field Name	Value Returned	Meaning
Element Address	Varies ^a	The address of the import/export element slot.
Access	0	The import/export element is not accessible by the picker.
	1	The import/export element is accessible by the picker.
CMC	0	The library does not support Connected Media Changer.
InEnab	0	The import/export element does not support movement of media into the location.
	1	The import/export element supports movement of media into the location by the robot or Medium transport element.
ExEnab	0	The import/export element does not support movement of media out of the location.
	1	The import/export element supports movement of media out of the location by the robot or Medium transport element.
Except	0	Indicates that the import/export element is in a normal state. Any data in the ASC and ASCQ fields is invalid.
	1	Indicates that the import/export element is in some sort of abnormal state. More information on the nature of the exception is available in the ASC and ASCQ fields.
ImpExp	0	Indicates that a tape is present in the import/export element and was put there by the medium transport element (the transporter).
	1	Indicates that media is present in the import/export element and was put there by an operator (import).
Full	0	Indicates that the import/export element does not contain media.
	1	Indicates that the import/export element contains media.

Table 11-7: Parameter values for the Import/Export element descriptor.

Field Name	Value Returned	Meaning
ASC	Varies	The ASC and ASCQ together provide more information about the condition that caused the Except bit to be set to 1. Their meaning here is the same as the ASC and ASCQ returned to the REQUEST SENSE command. See Appendix A – Error Reporting , beginning on page 119.
ASCQ	Varies	
SValid (Source Valid)	0	Indicates that the value in the Source Storage Element Address field is not valid or that Media Zoning is Enabled for a TFinity Library (see TFinity Libraries with Enable Media Zoning Selected on page 98).
	1	Indicates that the value in the Source Storage Element Address field is valid.
Invert	0	The tape libraries do not support two-sided media and do not invert the media. This bit is always 0.
Source Storage Element Address	Varies ^a	Shows the storage element address where the media was previously located.
<ul style="list-style-type: none"> ▪ Without Media Zoning enabled 		
<ul style="list-style-type: none"> ▪ With Media Zoning enabled (TFinity library only) 	0	The TeraPack magazine is stored in the left half of the library as viewed from the front (see TFinity Libraries with Enable Media Zoning Selected on page 98).
	1	The TeraPack magazine is stored in the right half (which includes the center frame if the number of frames is odd) of the library as viewed from the front (see TFinity Libraries with Enable Media Zoning Selected on page 98).
Primary Volume Tag Information	Varies ^b	<ul style="list-style-type: none"> ▪ If the PVolTag bit in the data header is 1, this field contains the 36-byte barcode label (volume tag) information for the media occupying this location. The barcode is left justified and is padded to the right with spaces (0x20) or NULL depending on the interface. If the barcode does not exist or is not readable, the entire field is space (0x20) padded or NULL. ▪ If the PVolTag bit is 0, this field is omitted entirely.
CodeSet	0	The Identifier fields are not valid.
Identifier Length	0	No Identifier is returned.
Media Domain ^c	43h	Indicates that the element contains a cleaning cartridge.
Note: This field is not valid if the Full bit is not set.	4Ch	Indicates that the element contains an LTO cartridge.
	4Ah	Indicates that the element contains a TS11x0 technology cartridge.

Table 11-7: Parameter values for the Import/Export element descriptor.

Field Name	Value Returned	Meaning
Media Type ^c Note: This field is not valid if the Full bit is not set. <ul style="list-style-type: none"> Media Type with Media Domain 43h (cleaning) 	55h	Indicates a universal LTO cleaning cartridge.
	FEh	Indicates a universal TS11x0 technology cleaning cartridge.
	FFh	Indicates the media type cannot be determined.
<ul style="list-style-type: none"> Media Type with Media Domain 4Ch (LTO) 	31h	Indicates an LTO Generation 1 cartridge.
	32h	Indicates an LTO Generation 2 cartridge.
	33h	Indicates an LTO Generation 3 cartridge.
	34h	Indicates an LTO Generation 4 cartridge.
	35h	Indicates an LTO Generation 5 cartridge.
	36h	Indicates an LTO Generation 6 cartridge.
	37h	Indicates an LTO Generation 7 cartridge.
	38h	Indicates an LTO Generation 8 or M8 cartridge.
	FFh	Indicates the media type cannot be determined.
<ul style="list-style-type: none"> Media Type with Media Domain 4Ah (TS11x0 technology) 	43h	Indicates a JC cartridge.
	44h	Indicates a JD cartridge.
	45h	Indicates a JE cartridge.
	FFh	Indicates the media type cannot be determined.

a. See [Chapter 7 – Mode Sense \(1Ah\)](#), beginning on [page 48](#) for range of values supported for element addresses.

b. The library reports the right most 16 characters of barcode data. It is important to make sure that the checksum barcode options are set correctly for the barcodes used. See “Configure Barcode Reporting” or “Select Barcode Options” in your library *User Guide*.

c. This field is omitted if **Include tape generation in Read Element Status** is not selected on the BlueScale Advanced Partition Settings screen.

Overview of T120 and T50e Entry/Exit Modes

The Entry/Exit mode determines how the Entry/Exit port (E/E port) operates. Entry/Exit modes are only applicable to the T120 and T50e libraries. The T120 supports Standard, Queued Eject, and Shared modes; while the T50e only supports the Standard and Queued Eject modes.

For additional information about the Entry/Exit modes, log on to the Support portal at <http://support.spectrallogic.com> and read Knowledge Base article 469.

Standard Mode. When the Entry/Exit port is set to Standard mode, a single data partition “owns” the Entry/Exit port; additional data partitions cannot be configured. Both the T120 and the T50e support Standard mode. In Standard mode, the library’s response to a **READ ELEMENT STATUS** command from the backup software indicates that it has eight slots (for a T120) or one slot (for a T50e) in the E/E port and that all of the slots are import-enabled, export-enabled, and accessible.

E/E Slot	Import-Enabled Bit (InEnab)	Export-Enabled Bit (ExEnab)	Access Bit	Full Bit
1	Always set (allows use for tape imports)	Always set (allows use for tape exports)	Is set (allows access by the backup software) if the E/E port is closed and cleared when the E/E port is open	Is set if a slot contains a tape, and cleared if a slot does not contain a tape
2				
3				
4				
5				
6				
7				
8				

The Full bit is set as appropriate, to indicate whether each slot has a cartridge in it. The backup software has full import/export access to these slots at any time. All moves are physical moves to and from the E/E port slots, so the number of cartridges that can be imported or exported by the software is limited by the physical capacity of the E/E port.

Shared Mode (T120 only). When the library is set to Shared mode, it allows two or more partitions in the library to share the E/E port. The library’s response to a **READ ELEMENT STATUS** command from the backup software indicates that it has nine slots in the E/E port:

E/E Slot	Import-Enabled Bit (InEnab)	Export-Enabled Bit (ExEnab)	Access Bit	Full Bit
1	Always set (allows use for tape imports)	Always cleared (exports to this slot are not allowed)	Is set ONLY for the selected partition during import operations when the E/E port is closed	Is set if a slot contains a tape, and cleared if a slot does not contain a tape
2				
3				
4				
5				
6				
7				
8				
9	Always cleared (imports from this slot are not allowed)	Always set (allows use for tape exports)	Always set (allow access by the backup software)	Always cleared (the slot always appears empty)

- Slots 1 through 8 correspond to the physical slots in the E/E port and are import-only (the Import Enabled bit is set, but the Export Enabled bit is not). In addition, the slots have the Access bit cleared (access not allowed) until an import operation is initiated from the front panel of the library. When a front panel import operation is initiated for a partition, the Access bit for that partition is set, which enables access to the E/E port for import operations. The backup software can then use the E/E port to import cartridges into the partition.

Note: The Access bit is only set for the partition for which the import operation is requested. The E/E port remains inaccessible for any other partitions configured in the library.

- In addition to the eight physical slots, the E/E port has an additional virtual slot (Slot 9), which is export-only (the Export Enabled bit is set, but the Import Enabled bit is not). For E/E Slot 9, the Access bit is always set, and the Full bit is always cleared. As a result, the response to an **READ ELEMENT STATUS** command indicates that Slot 9 is always empty and available for export operations.

When the backup software exports a cartridge, the cartridge remains in its current storage slot. No physical move occurs, although the library reports that the move is complete. The Exception bit for the slot where the cartridge is located is set to indicate that the slot is in an “abnormal” state. Because the virtual export slot (Slot 9) never contains a cartridge, the library continues to report that the slot is empty and available for use, regardless of the number of cartridges that are exported using this method.

When an Eject Queued Tapes operation is requested from the front panel, the exported cartridges are physically moved to the eight slots in the E/E port so that they can be removed from the library. After the cartridges are removed, all of the Exception bits that were set for the storage slots are cleared and the Access bits are set, making those slots once again accessible to the backup software.

If the library is powered on with cartridges already in the E/E port, the cartridges are initially accessible by any partition (because the library does not know which partition should “own” them). In this case, selecting a partition and opening/closing the E/E port makes the cartridges accessible to the selected partition, just as with any import operation. A partition also gains ownership of the E/E port when you use the front panel to move cartridges to or from the E/E port.

Queued Eject Mode. Queued Ejects allow two or more partitions in the library to share the E/E port. Access to certain tapes and slots may be restricted and imports/exports may not be handled the way you may expect. Both the T120 and the T50e support Queued Eject mode. When the Entry/Exit port is set to Queued Eject mode, the library's response to a **READ ELEMENT STATUS** command from the backup software indicates that it has only one export-only E/E slot.

E/E Slot	Import-Enabled Bit (InEnab)	Export-Enabled Bit (ExEnab)	Access Bit	Full Bit
1	Always cleared (imports from this slot are not allowed)	Always set (allows use for tape exports)	Always set (allows access by the backup software)	Always cleared (the slot always appears empty)

The single E/E slot is functionally identical to the virtual E/E slot in Shared mode. As with Shared mode, the Exception bit is set and the Access bit cleared for any storage slots that contain cartridges that have been exported.

The BlueScale software treats all eject operations initiated by the backup software as logical moves to the E/E slot. The move is reported as successful, but the ejected cartridge is left in its original slot. The Exception bit for the slot is set for the storage slot and the Access bit for the slot is cleared, making the storage slot inaccessible to the backup software.

When an Eject Queued Tapes operation is requested from the front panel, the exported cartridges are physically moved to the single slot in a T50e or the eight slots in a T120 E/E port so that they can be removed from the library. After the cartridges are removed, all of the Exception bits that were set for the storage slots are cleared and the Access bits are set, making those slots once again accessible to the backup software.

Because the slot(s) in the E/E port are not import-enabled, the only way to import cartridges into a partition is by using either a move queue or a bulk load command from the library front panel. This type of import operation does not automatically update the cartridge inventory maintained by the backup software. You must force the software to re-inventory the partition after the import operation is complete to ensure that the inventory is accurate.

TFinity Libraries with Enable Media Zoning Selected

For TFinity libraries only, If **Enable media zone information** is selected on the BlueScale Advanced Partition Settings screen (see the *Spectra TFinity Library User Guide* for information on accessing the screen), zone information and TeraPack barcodes are appended to the Storage Element and Import Export Element descriptors. The starting byte depends on the value for PVolTag and whether **Include tape generation in Read Element Status** is enabled.

Bit Byte	7	6	5	4	3	2	1	0
n	Protocol Identifier (0)				Code Set (2h)			
n + 1	PIV (0)	Reserved	Association (0)		Designator Type (0)			
n + 2	Reserved							
n + 3	TeraPack Barcode Length (10h)							
n + 4 to n + 19	TeraPack Barcode							

Table 11-8: Parameter values for media zone information.

Field Name	Value Returned	Meaning
Protocol Identifier	0	Ignored.
Code Set	02h	The TeraPack Barcode field contains ASCII data.
PIV	0	Indicates that the Protocol Identifier should be ignored.
Association	0	Ignored.
Designator Type	0	The ASCII data is Vendor Specific Data.
TeraPack Barcode Length	10h	The library reports 16 characters of the TeraPack barcode.
TeraPack Barcode	Varies	The TeraPack barcode. The TeraPack barcode is left justified and NULL padded.

Command Status

The library returns a status byte after processing the **READ ELEMENT STATUS** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on page 112 for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB is invalid (see [Table 11-10](#) for sense data).

Table 11-9: Invalid parameters in the READ ELEMENT STATUS CDB

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	21h	01h	1	1	0	0	00 02h	Invalid starting element address.
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB or the Allocation Length is invalid (less than 8 bytes). The pointers indicate the bit in error.
5h	24h	00	1	1	1	3h	00 01h	Invalid element type code.

CHAPTER 12

Release (17h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (17h)							
01	Obsolete ^a			3rdPty	Third Party Device ID			Element
02	Reservation ID							
03	Reserved							
04								
05	0	0	Reserved			0	0	

a. These bits are ignored.

COMMAND DESCRIPTION

The **RELEASE** command enables the initiator to release reservations on the library or library elements that were set by the **RESERVE** (16h) command. For information on the **RESERVE** command, see [Chapter 15 – Reserve \(16h\)](#), beginning on [page 112](#).

Only the initiator that reserved the library or its elements can release them. If another initiator attempts to release a reserved library or its elements, the library returns a Reservation Conflict status. Releasing an unreserved library or unreserved library elements is not an error.

Note: The recommended timeout for this command is 5 minutes or 300 seconds.

WHAT YOU SEND TO THE LIBRARY

Table 12-1: RELEASE CDB field values

Field Name	Values Allowed	Meaning
3rdPty	0	RELEASE is not being requested for a third-party reservation.
	1	RELEASE is being requested for a reservation made previously by this initiator for the third-party device identified in the Third Party Device ID.
Third Party Device ID	0–7h	Shows the SCSI ID of the third-party device for which the library or some of its elements were previously reserved. This field is ignored if the 3rdPty bit is 0.
Element	0	The library releases all active reservations, for the entire unit or any of its elements, which came from this initiator (or were for the third-party device specified, if the 3rdPty bit is 1)
	1	The library releases the element reserved for this initiator with the matching Reservation ID. See Chapter 15 – Reserve (16h) , beginning on page 112 for information about assigning Reservation ID numbers using the RESERVE command.
Reservation ID	Varies ^a	If the Element bit is 1, this field is checked to determine which elements to release. If the Element bit is 0, this field is ignored.

a. Any valid storage slot in the library reported by the MODE SENSE command. You cannot reserve an Import/Export, Medium Transport, or Data Transfer Element.

COMMAND STATUS

The library returns a status byte after processing the **RELEASE** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library never returns Reservation Conflict status for the **RELEASE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB is invalid (see [Table 12-2](#) for sense data).

Table 12-2: Invalid parameters in the RELEASE CDB

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	24h	00	1	1	1	1h	00 01h	LongID field is set to 1.
5h	24h	00	1	1	1	1h	00 00h	Element field is set to 1.

CHAPTER 13

Report LUNs (A0h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (A0h)							
01	Reserved							
...								
05								
06	(MSB)	Allocation Length						(LSB)
...								
09								
10	Reserved							
11	Control							

COMMAND DESCRIPTION (NOT SUPPORTED FOR PARALLEL SCSI LIBRARIES)

The **REPORT LUNS** command requests that the inventory of peripheral device logical units that are accessible to the initiator via the addressed SCSI target port be sent to the application client. The logical unit inventory is a list that includes the LUNs of all logical units having a Peripheral Qualifier value of 000b. Returning LUNs for logical units with Peripheral Qualifier values of 100b, 101b, 110b, or 111b is not supported.

The library supports a **REPORT LUNS** command when it is addressed to LUN zero. Support of the **REPORT LUNS** command by logical units other than logical unit zero is not supported.

Note: Devices compliant with SPC return a Check Condition status with sense key Illegal Request and additional sense data set to Invalid Field In CDB when the allocation length is less than 16 bytes.

The **REPORT LUNS** command returns Check Condition status only when the device server is unable to return the requested report of the logical unit inventory.

If a **REPORT LUNS** command is received from an initiator with a pending Unit Attention condition (that is, before the device server reports Check Condition status), the device server performs the **REPORT LUNS** command.

If the Unit Attention condition was established because of a change in the logical unit inventory, that Unit Attention condition is cleared for that initiator by the **REPORT LUNS** command. Unit Attention conditions established for other reasons are not cleared by the **REPORT LUNS** command.

The **REPORT LUNS** data should be returned even though the device server is not ready for other commands. The default report of the logical unit inventory should be available without incurring any media access delays. The default report of the logical unit inventory contains at least LUN 0.

If the logical unit inventory changes for any reason, including completion of initialization, removal of a logical unit, or creation of a logical unit, the device server generates a unit attention command for all initiators.

The device server sets the additional sense code to Reported LUNs Data Has Changed. The execution of a **REPORT LUNS** command to any valid and installed logical unit clears the Unit Attention condition that has a sense code of Reported LUNs Data Has Changed for all logical units of that target with respect to the requesting initiator. A valid and installed logical unit is one having a peripheral qualifier of 000b in the standard **INQUIRY** data.

Note: The recommended timeout for this command is 20 minutes or 1200 seconds.

WHAT THE LIBRARY RETURNS

The LUN List Length field contains the length in bytes of the LUN list that is available to be transferred. The LUN list length is the number of logical unit numbers in the logical unit inventory multiplied by eight. If the allocation length in the CDB is too small to transfer information about the entire logical unit inventory, the LUN list length value is not adjusted to reflect the truncation.

Bit Byte	7	6	5	4	3	2	1	0
00 to 03	LUN List Length							
04 to 07	Reserved							

LUN List

08 ... 15	(MSB)	First LUN (00)	(LSB)
16 ... 23	(MSB)	Second LUN (01)	(LSB)
N-7 N	(MSB)	Last LUN	(LSB)

Spectra Logic libraries always report the LUNs sequentially, as illustrated in the following table.

Table 13-1: Examples of LUNs reported by a Spectra Logic library

LUNs	Configuration 1	Configuration 2	Configuration 3	Configuration 4	Configuration 5
0	Drive 1	Library 1	Library 1	Library 1	Library 1
1	Drive 2	Drive 1	Drive 1	Drive 1	Library 2
2	Drive 3	Drive 2	Drive 2	Library 2	
3	Drive 4	Drive 3	Library 2	Drive 1 (3)	
4		Drive 4	Drive 1 (3)		
5			Drive 2 (4)		

Configuration 1 The QIP only has drives attached.

Configuration 2 The QIP is an exporting library QIP and has drives attached.

Configuration 3 and Configuration 4 The QIP is exporting two separate partitions (virtual libraries).

Configuration 5 The RIM is exporting two separate partitions (virtual libraries).

Command Status

The library returns a status byte after processing the **REPORT LUNS** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on [page 112](#) for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB is invalid (see [Table 13-2](#) for sense data).

Table 13-2: Invalid parameters in the READ ELEMENT STATUS CDB

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	24h	00	1	1	1	3h	00 01h	Invalid element type code.

CHAPTER 14

Request Sense (03h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (03h)							
01	Obsolete ^a			Reserved				
02	Reserved							
03								
04	Allocation Length							
05	0	0	Reserved				0	0

a. These bits are ignored.

COMMAND DESCRIPTION

The **REQUEST SENSE** command requests that the library transfer sense data to the initiator. It is generally issued immediately after the library reports a Check Condition status for the previous command.

Note: The recommended timeout for this command is 60 seconds.

WHAT YOU SEND TO THE LIBRARY

Allocation Length (byte 04) is the space allocated by the initiator for the sense data. The library returns a total of 52 bytes of sense data available to send. If you specify an Allocation Length greater than 52 bytes, the library sends 52. If you specify an Allocation Length less than 52 bytes, the library truncates the sense data at the specified Allocation Length.

COMMAND RESPONSE

The library returns the standard sense data, as described in the following table.

Bit Byte	7	6	5	4	3	2	1	0
00	Valid	Error code						
01	Segment Number 00h (not used)							
02	Reserved for other device types				Sense Key			
03	(MSB) Information Bytes							
...								
06	(LSB)							
07	Additional Sense Length = 2Ch							
08	(MSB) Command Specific Information (not used)							
...								
11	(LSB)							
12	Additional Sense Code (ASC)							
13	Additional Sense Code Qualifier (ASCQ)							
14	Field Replaceable Unit Code							
15	SKSV	(MSB)						
16	Command Specific Information (not used)							
17	(LSB)							
18	ASCII Representation of Sense Data (not used)							
...								
51								

The sense data is valid for the Check Condition status just presented to the initiator. This sense data is preserved in the library for the initiator receiving the Check Condition status. Sense data is cleared when any subsequent command that is not a **REQUEST SENSE** or an **INQUIRY** (12h) command is received from the initiator.

Refer to [Appendix A – Error Reporting](#), beginning on page 119 for a list and description of sense codes.

Table 14-1: Field values for the data returned by the REQUEST SENSE command

Field Name	Value Returned	Meaning
Valid	1b	Indicates the sense data conforms to the SPC-3 Standard.
Error Code	70h	Indicates the sense data is for the current error. The library does not perform deferred error reporting (error code 71h).
Segment Number	00h	This field is not implemented in the tape libraries.
Sense Key (General Error Category) See Appendix A – Error Reporting , beginning on page 119 for more information.	0h	No Sense. No specific sense information to report.
	2h	Not Ready. Indicates that the library cannot be accessed.
	4h	Hardware Error. The library detected a nonrecoverable hardware failure.
	5h	Illegal Request. There was an illegal parameter in the CDB or additional parameters supplied as data for some commands (for example, in MODE SELECT).
	6h	Unit Attention. The library's condition has somehow changed. For example, media may have been moved, or the unit may have been reset.
	9h	Vendor-unique. Sense information is specific to the tape libraries. The Additional Sense Code and Additional Sense Code Qualifier provide additional information.
Command Specific Information	0h	This field is not implemented in the tape libraries.
Additional Sense Length	2Ch	Indicates that 44 bytes (2Ch) of sense data follow this byte (52 total).
Additional Sense Code (ASC)	Varies	Provide further information about the nature of the error condition, beyond that reported in the Sense Key field. See Appendix A – Error Reporting , beginning on page 119 for descriptions of all ASCs and ASCQs that the library supports and how to interpret the values returned.
Additional Sense Code Qualifier (ASCQ)	Varies	
Field Replaceable Unit Code	00h	No specific unit failure has been identified.
SKSV	0b	Indicates the data in the Sense-Key Specific field is not valid. No sense-key specific information applies to the library.
ASCII Representation of Sense	Varies	This field is not implemented in the Spectra tape libraries.

COMMAND STATUS

The library returns a status byte after processing the **REQUEST SENSE** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

The library never returns Busy status for the **REQUEST SENSE** command.

Reservation Conflict

The library never returns Reservation Conflict status for the **REQUEST SENSE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB is invalid (see [Table 14-2](#) for sense data).

Table 14-2: Invalid parameters in the READ ELEMENT STATUS CDB

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.

CHAPTER 15

Reserve (16h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (16h)							
01	Obsolete ^a							Element
02	Reservation ID							
03	(MSB)	Element List Length						(LSB)
04								
05	Control							

a. These bits are ignored.

COMMAND DESCRIPTION

The **RESERVE** command allows the initiator to reserve the library (partition) as a whole. Reserving the library prevents another user from moving media to the import/export element of the library using the library's touch screen control panel.

If the superseding reservation does not result in any reservation conflicts or error conditions, the library releases the previous reservation and completes the new reservations. A unit reservation of the library supersedes any previous element reservations by the same initiator.

The reserved library is released by issuing a **RELEASE** (17h) command from the same initiator, a bus device reset condition, a SCSI bus reset, or power-cycling the library.

Note: The recommended timeout for this command is 5 minutes or 300 seconds.

WHAT YOU SEND THE LIBRARY

Table 15-1: RESERVE CDB parameter values

Field Name	Values Allowed	Meaning
Element	0	Requests reservation of entire library. If the library is reserved by another initiator, the library rejects this command with Reservation Conflict status.
Reservation ID	0	This field is only checked if the Element bit is set to 1. Because the Element bit is always set to 0, this field is ignored.
Element List Length	0	Because the library does not support reserving individual elements, the command is not followed by an element list.

COMMAND STATUS

The library returns a status byte after processing the **RESERVE** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when the library is reserved by a different initiator

Check Condition

The library returns Check Condition status for the following reasons:

- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB or element descriptor data is invalid (see [Table 15-2](#) for sense data).

Table 15-2: Invalid parameters in the RESERVE CDB and element descriptor data

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	^a	—	—	The value for a field in the CDB is invalid. The pointers indicate the field in error.

a. Value depends on which bit is wrong.

CHAPTER 16

RTAOS (A3h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (A3h)							
01	LBA Limits	Reserved		Service Action (1Dh)				
02	RTAOS List Offset							
...								
05								
06	(MSB)							
...	Allocation Length							
09	(LSB)							
10	Reserved				LBA Type (000b)			
11	Control Byte							

Note: This command is supported on TFinity libraries running BlueScale12.8.0 and later. See “Enable Time-based Access Order System (TAOS)” in the *Spectra TFinity Library User Guide* for instructions for enabling TAOS in a partition.

COMMAND DESCRIPTION

The **RTAOS (RECEIVE TIME-BASED ACCESS ORDER SYSTEM)** command is used by the host to request an RTAOS list generated using the **GTAOS (GENERATE TIME-BASED ACCESS ORDER SYSTEM)** command to minimize the amount of seek time required to process the reads.

- Notes:**
- Before issuing the **RTAOS** command, issue a **GTAOS** command (see [GTAOS \(A4h\)](#) on page 19).
 - This command can only be issued to a tape drive that is exporting a "SPECTRA TAOS" device on LUN 1. Use Inquiry page [TAOS Serial Number Association Page \(Page Code D0h\)](#) on page 38 to determine the drive serial number and associate it with a library partition.

- This command is supported for LTO-7 and later generation drives.
- The recommended timeout for this command is 20 minutes or 1200 seconds.

WHAT YOU SEND TO THE LIBRARY

To retrieve the Time-Based Access Order System list generated by the drive sled in response to a **GTAOS** command, send an **RTAOS** command with the following parameters.

Table 16-1: RTAOS CDB parameter values

Field Name	Values Allowed	Meaning
LBA Limits	0b	Indicates to return the RTAOS list.
	1b	Indicates to return the LBA Limits page.
Service Action	1Dh	Indicates that the command is requesting a device server to send the requested information. This is the only supported Service Action for LUN 1.
RTAOS List Offset	Varies	If LBA Limits=0b, this indicates the offset into the RTAOS list from which to begin returning data. The RTAOS List Offset must be in multiples of 32 bytes for each LBA descriptor plus 8 bytes for the RTAOS List header (from 8 bytes to 96,008 bytes in increment of 32). If LBA Limits=1b, this must be 0.
Allocation Length	Varies	The maximum number of bytes to be returned. To get full LBA descriptors use from 0 - 96,000 bytes in increments of 32.
LBA Type	000b	Indicates that the drive sled is generating Logical Block Address descriptors without geometry. This is the only supported LBA Type.

RTAOS Parameter Data

The parameter data received from an **RTAOS** command is defined below.

- If LBA LIMITS = 1b, then the RTAOS parameter data is defined by [LBA Limits Page](#), below.
- If LBA LIMITS = 0b, then the RTAOS parameter data is defined by [RTAOS List on page 119](#).

LBA Limits Page

Bit Byte	7	6	5	4	3	2	1	0		
00 01	(MSB)							Maximum LBA (BB8h)		(LSB)
02 03	(MSB)							Maximum LBA Size (020h)		(LSB)

Table 16-2: Data sent in the LBA Limits Page

Field Name	Value	Meaning
Maximum LBA	BB8h	3000 decimal. Indicates the number of Logical Block Address descriptors that the drive sled will return. Note: If your drive uses firmware lower than JAYE, the maximum number of Logical Block Address descriptors is 2000.
Maximum LBA Size	20h	32 decimal. Indicates the size of the Logical Block Address descriptor.

RTAOS List

RTAOS Parameter List Header

Bit Byte	7	6	5	4	3	2	1	0		
00	Reserved					Process (010b)				
01	Reserved					Status				
02	Reserved									
03	Reserved									
04 ... 07	(MSB)							Additional Data (N-7)		(LSB)
	Logical Black Address Descriptors									
x	Logical Block Address Descriptors (First)									
	...									
y n	Logical Block Address Descriptors (Last)									

Table 16-3: Data returned in the Parameter List Header

Field Name	Value	Meaning
Process	010b	Requests the RTAOS list. This is the only Process option supported for LUN 1.
Status	000b	The RTAOS list does not contain a valid list (for example, the GTAOS command invalidated the list).
	001b	The RTAOS list contains a valid TAOS list without geometry.
	010b	The RTAOS list contains a list matching the order of the list passed in the GTAOS command but has not processed the list due to an inability to do so at this time.
Additional Data	$n-7$ where n is the Parameter List Length	Indicates the length of all Logical Block Address Descriptors to be transferred.

RTAOS Logical Block Address Descriptor

Bit Byte	7	6	5	4	3	2	1	0							
00	Descriptor Length (1Eh)														
01									(MSB)						
02	Reserved														
03	Reserved														
04	Reposition Time														
05	LBA Name														
...															
14															
15	Partition Number														
16	Beginning Logical Object of Logical Block Address														
...									(MSB)						
23															(LSB)
24	Ending Logical Object of Logical Block Address														
...									(MSB)						
31															(LSB)

Table 16-4: Data returned in the Logical Block Address Descriptor

Field Name	Value	Meaning
Descriptor Length	1Eh	The length of the data to follow. The data length for each Logical Block Address sent to the library is 30 bytes (1Eh) excluding the Descriptor Length.
Reposition Time	Varies	Estimation of nominal time in seconds required to move from the previous position (beginning of tape or previous LBA) to the current LBA.
LBA Name	Varies	LBA (Logical Block Address) Name set by the host in the GTAOS command. The data type is ignored.
Partition Number	Varies	The number of the partition on the tape containing the data block.
Beginning Logical Object of Logical Block Address	Varies	The first block in the logical block address. This field is an 8-byte unsigned integer field and takes values from 0 to 1,152,921,504,606,846,975.
Ending Logical Object of Logical Block Address	Varies	The last block in the logical block address. This field is an 8-byte unsigned integer field and takes values from 0 to 1,152,921,504,606,846,975.

COMMAND STATUS

The library returns a status byte after processing the **RTAOS** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on [page 112](#) for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- The command is issued to an invalid LUN.
- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB.
- The library detects an unrecoverable parity error while receiving the **RTAOS** data.
- A parameter in the CDB on a **RTAOS** page is invalid (see [Table 16-5](#) for sense data).

Table 16-5: Invalid parameters in the GTAOS CDB and TAOS Parameter list

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.
5h	24h	00h	1	1	1	2	1	Service Action set to a value other than 1Dh.
5h	24h	00h	1	1	1	0	10	LBA Type set to a value other than 0.
5h	24h	00h	1	1	1	0	2	A Limits Page request with Offset set to anything other than 0.
5h	24h	00h	1	1	1	0	2	An RTAOS List request with Offset not a multiple of 4.

CHAPTER 17

Send Diagnostic (1Dh)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (1Dh)							
01	Obsolete ^a			PF	Reserved	SelfTest	DevOfL	UnitOfL
02	Reserved							
03	(MSB) Parameter List Length (LSB)							
04								
05	0	0	Reserved				0	0

a. These bits are ignored.

COMMAND DESCRIPTION

The **SEND DIAGNOSTIC** command causes the library to perform its diagnostic self-tests or it causes the LCM to reset. Spectra tape libraries support the Default Self-Test (SelfTest bit = 1 and Parameter List Length = 0) and Reset LCM (PF=1, SelfTest bit = 1, and Parameter List Length = 8).

If a self-test or reset is successful, the library returns Good status; otherwise, it returns Check Condition status.

Note: The recommended timeout for this command is 20 minutes or 1200 seconds.

WHAT YOU SEND TO THE LIBRARY

Table 17-1: SEND DIAGNOSTIC CDB field values

Field Name	Values Allowed	Meaning
PF (Page Format)	0 or 1	0 for library self-test (SelfTest must be 1), 1 for LCM reset (SelfTest must be 0).
SelfTest	0 or 1	1 for library self-test (PF must be 0) 0 for LCM reset (PF must be 1).
DevOfL (Device Off-Line)	0	The library may not perform diagnostic tests whose results may be detected by subsequent I/O processes.
UnitOfL (Unit Off-Line)	0	The library may not perform diagnostic tests that might affect the the positioning of media inside the library.
Parameter List Length	0 - ffff	Specifies the length (in bytes) of the list to be transferred to the library. A length of 0 indicates that no data is to be transferred. This is not considered an error. For the Reset LCM diagnostic the data out length should be 8. For the Default Self-Test diagnostic this should be set to zero.

Send Diagnostic Assignment Page (Page Code 80h)

Bit Byte	7	6	5	4	3	2	1	0	
00	Page Code (80h)								
01	Reserved								
02	(MSB)				Page Length				(LSB)
03	(00 04h)								
04	(MSB)				Diagnostic ID				(LSB)
05	(00 01h)								
06	(MSB)				Reserved				(LSB)
07									

Table 17-2: Data sent on the Send Diagnostic Assignment page

Field Name	Value	Meaning
Page Code	08h	Identifies the Send Diagnostic Assignment page.
Page Length	00 04h	Indicates that there are an additional 4 bytes of element address data that follow this byte.
Diagnostic ID	00 01h	Indicates the Reset LCM diagnostic.

COMMAND RESPONSE

Because the library only supports the default self-test and LCM reset, there is no data returned from the **SEND DIAGNOSTIC** command. If the command is successful, a Good status is returned. Otherwise, a Check Condition status is returned. The sense information is available with a **REQUEST SENSE** command. Additional information may be returned in the ASC and ASCQ.

Check Condition

The library returns Check Condition status for the following reasons:

- A Unit Attention condition is pending for the initiator.
- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB or element descriptor data is invalid (see [Table 17-3](#) for sense data).

Table 17-3: Invalid parameters in the SEND DIAGNOSTIC CDB and element descriptor data

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
5h	24h	00h	1	1	^a	—	—	The value for a field in the CDB is invalid. The pointers indicate the field in error.
5h	26h	00h	1	0	0	0	^b	<ul style="list-style-type: none"> ▪ Invalid values in the Parameter List Header. All values must be 0. The value of the field pointer is the value of the first field that contains a non-zero value (00, 01, 02, or 03). ▪ Invalid Parameter Length. ▪ Reserved bits set in the reserved fields 22 or 23 (bytes 18 or 19 of the Element Address Assignment page). ▪ Storage element addresses are not consecutive. ▪ Address wrap. Number of elements causes the address range to wrap back to 00 00.
5h	26h	00h	1	0	1	5h	^a	Invalid Page Code.
5h	26h	00h	1	0	1	7h	^a	Reserved bits set in the first byte of one of the MODE SELECT pages.

a. Value depends on which bit is wrong.

b. Field pointer depends on the order in which the pages are sent.

CHAPTER 18

Test Unit Ready (00h)

Bit Byte	7	6	5	4	3	2	1	0
00	Operation Code (00h)							
01	Obsolete ^a			Reserved				
02	Reserved							
...								
04								
05	0	0	Reserved				0	0

a. These bits are ignored.

COMMAND DESCRIPTION

The **TEST UNIT READY** command lets the initiator determine whether the library is ready to accept all other valid commands, including motion commands. This is not a request for a library self-test, which occurs at power-on.

Note: The recommended timeout for this command is 60 seconds.

COMMAND STATUS

The library returns a status byte after processing the **TEST UNIT READY** command. This section describes when each type of status byte might be returned.

Good

The library returns Good status when it is able to process the command without errors. The library is ready to accept any valid command.

Busy

Busy status indicates that the library is temporarily unable to accept a command from this initiator. The initiator may retry the command later.

Reservation Conflict

The library returns Reservation Conflict status when it is reserved by a different initiator. See [Chapter 15 – Reserve \(16h\)](#), beginning on [page 112](#) for more information about the **RESERVE** command.

Check Condition

The library returns Check Condition status for the following reasons:

- A Unit Attention condition is pending for the initiator.
- The library is not ready because it has just powered up, it received a bus device reset message, or after a power-on reset. The sense key is set to Unit Attention (6h).
- The library has experienced an unrecoverable hardware error.
- A reserved bit is set to 1 in the CDB.
- A parameter in the CDB or parameter list is invalid (see [Table](#) for sense data).

Table 18-1: Invalid parameters in the TEST UNIT READY CDB and parameter list

Sense Key	ASC	ASCQ	SKSV Bit	C/D Bit	BPV Bit	Bit Pointer	Field Pointer	Error
2h	04h	00h	0	0	0	0	0	Unit not ready, manual intervention required.
5h	24h	00h	1	1	1	—	—	A reserved bit is set in the CDB. The pointers indicate the bit in error.

APPENDIX A

Error Reporting

This appendix lists the Sense Keys, ASCs (Additional Sense Codes), and ASCQs (Additional Sense Code Qualifiers) for library errors. The ASCs and ASCQs are associated with the sense keys returned by the library in response to a **REQUEST SENSE** command (see [Chapter 14 – Request Sense \(03h\)](#), beginning on [page 108](#)). These three pieces of information combine to indicate a specific error condition.

Note: For error codes returned by tape drives (medium errors), refer to the tape drive manual for that specific drive type. See [Related Publications on page 13](#).

SENSE KEYS

The following table describes the sense keys returned by the library. The sense key provides a general indication of the type of error that occurred.

Sense Key	Meaning	Explanation
0h	No Sense	There is no specific sense key information.
2h	Not Ready	Library cannot be accessed. Operator intervention may be required to correct this condition. See the additional sense code description for more information.
4h	Hardware Error	Library detected a non-recoverable hardware failure while performing the command or during a self-test. See the ASC description for more information.
5h	Illegal Request	Invalid command request received or the library is in the wrong mode to process the command.
6h	Unit Attention	Indicates that the data cartridge inventory may have been changed.
9h	Vendor Specific	Indicates vendor-specific sense data for tape libraries.

Sense Keys Not Used

The libraries *do not* use the following sense keys:

Sense Key	Meaning
1h	Recovered Error
3h	Medium Error
7h	Data Protect
8h	Blank Check
Ah	Copy Aborted
Bh	Aborted Command
Ch	Equal
Dh	Volume Overflow
Eh	Miscompare

ADDITIONAL SENSE CODES AND QUALIFIERS

Combining the Sense Key with the Additional Sense Code (ASC) and Additional Sense Code Qualifier (ASCQ) returned in response to a **REQUEST SENSE** command, provides the most complete error description available from the library. The following table describes the ASC/ASCQ associated with each sense key returned by the library. The error descriptions are listed in order by ASC and ASCQ for each of the sense keys.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
0h No Sense	00h	00h	Unit ready.	No problems; no additional sense information.
2h Not Ready	04h	00h	Unit not ready.	The unit is not yet ready to accept commands.
	04h	01h	Unit is becoming ready.	The unit is in the process of becoming ready.
	04h	03h	Unit NOT Ready, Manual Intervention Required.	The library has a hardware issue that must be manually resolved. Manually resolve the hardware issue.
	04h	83h	Door is open, robot disabled.	Close the door.
	3Ah	00h	Tape is not loaded and threaded.	Load a tape or allow time for the tape to thread.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors	05h	00h	Logical unit does not respond; device is permanently inaccessible.	This is returned by the Fibre-SCSI bridge only when the library claims the presence of a tape drive that cannot be found on the internal SCSI bus, and for which inquiry data cannot be obtained. These tape drives appear to the host, but any attempts to access them returns this error.
	2Eh	01h	Third party device failure. There are problems communicating with the third party device.	Check the sense codes returned from the third party device to determine the problem. Correct the problem before attempting to communicate with the device again.
	2Eh	02h	Copy target device is unreachable. The target device specified is invalid.	Verify that the specified target device is correct. Also verify that the device is powered on and ready.
	2Eh	04h	Copy target device data under-run.	This code is reserved and represents an internal error that should not occur. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	2Eh	05h	Copy target device data overrun.	This code is reserved and represents an internal error that should not occur. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	40h	D1h	Import/export door could not be extended.	Check door for obstruction.
	40h	D2h	Import/export door could not be retracted.	Check door for obstruction.
	4Ch	00h	Unit failed initialization.	Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	81h	01h	Drive failed to unload.	Retry the move. Tape may be stuck in drive.
	81h	02h	Tape failed load; move marked successful.	Drive, tape, or tape sensor may be bad.
	81h	04h	Drive failed to come ready.	The tape may be broken or is a cleaning tape, or the drive may be broken.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors (continued)	85h	01h	Move failed; tape left in picker.	The robotic picker may have lost its calibration, or there were obstructions at both the source and destination slot. Manually remove the tape from the picker's jaws and recalibrate the robot. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	85h	02h	Move failed; tape left in source.	Retry the move.
	85h	03h	Move failed; picker will reset.	Retry the move after reset.
	85h	04h	Long axis motor blocked.	Remove obstruction and cycle power.
	85h	05h	Gripper motor blocked.	Remove obstruction and cycle power.
	85h	06h	Rotary motor blocked.	Remove obstruction and cycle power.
	85h	07h	Medium axis motor blocked.	Remove obstruction and cycle power.
	85h	08h	Short axis motor blocked.	Remove obstruction and cycle power.
	85h	09h	Parameter block is corrupted.	Erase parameter block and cycle power.
	85h	0Ah	Picker failed to park.	Check for obstruction beneath picker.
85h	0Bh	Picker failed initialization—cannot communicate with barcode scanner.	The barcode scanner is essential for robotic operation, so the picker fails initialization if it cannot communicate with it. The picker needs to be power cycled. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).	

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors (continued)	85h	0Eh	Cartridge stuck in slot; the robotic picker was unable to pull the tape from the source.	<p>There may a problem with the picker's alignment, the tape, or the magazine.</p> <ol style="list-style-type: none"> 1. Retry the operation and watch as the picker attempts to grab the tape. Is the picker properly aligned? 2. If that fails, manually remove the tape from the slot. 3. If that fails, try to reseal the magazine. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	85h	25h	Cartridge stuck in drive; the robot was unable to remove the tape from the drive. (The tape is usually left in the mouth of the drive.)	<p>The robot may be misaligned or the tape may be broken (with the tape possibly wrapped around the drive heads).</p> <ol style="list-style-type: none"> 1. Re-issue the command, either from the front panel or the software. 2. If that fails, remove the drive, being careful of the tape position so that it clears the metal parts of the library when you pull the drive out. CAREFULLY try to remove the tape from the drive manually; do NOT force it. If you cannot remove the tape from the drive, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7) to arrange for an RMA drive replacement. 3. If the tape was not sitting in the mouth of the drive and re-issuing the command did not work, reseal the drive and again re-issue the command. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	85h	90h	No mechanical picker version defined.	Run diagnostic to set picker version from front panel.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors (continued)	85h	91h	Calibration block not found.	Check for obstruction in base of unit and cycle power to retry.
	85h	92h	No rack version defined.	Run Diagnostic Check to set rack version from front panel.
	85h	99h	General robotics failure.	The library has a unknown hardware error. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	86h	00h	Fibre failed initialization.	Unplug and replug the F-QIP or RIM.
	87h	00h	Invalid FEPROM / invalid ID bits.	Bad FEPROM, Check 12V or invalid device.
	87h	01h	FEPROM ERASE operation failed.	Bad FEPROM, Check 12V or invalid device.
	87h	02h	FEPROM write operation failed.	Bad FEPROM, Check 12V or invalid device.
	88h	00h	General picker definition error.	General picker definition error.
	88h	01h	Invalid picker type.	The picker type is invalid.
	88h	02h	Invalid rack type.	The rack type is invalid.
	88h	03h	Invalid library size.	The library size is invalid.
	88h	04h	Invalid chassis type.	The chassis type is invalid.
	88h	05h	Invalid IE door type.	The IE door type is invalid.
	90h	00h	Internal SCSI error unknown.	Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	90h	01h	Internal SCSI command failed.	
	90h	02h	SCSI command timed out.	Check device power and cables. Reset the drive. Go to the Status screen and then to the Drive screen to see if the library shows a problem with the drive.
	90h	03h	Internal SCSI command was aborted by host.	Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors (continued)	90h	04h	Initiator detected Error Message Received.	Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	90h	05h	Internal SCSI command reselect timeout.	
	91h	XXh	Internal SCSI chip failure.	
	92h	00h	Unknown error on internal SCSI chip.	
	92h	01h	Internal SCSI port does not exist.	
	92h	02h	Internal SCSI port is non-functional.	
	92h	03h	Internal SCSI port is disabled.	
	92h	04h	Interface hardware is not supported.	
	92h	05h	Requested data transfer length is too long.	The data transfer length for any single command is limited by the total buffer space available (between 4 and 16 MB). Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	06h	DMA error.	Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	07h	Command phase overrun—device demanded more CDB bytes than available.	
	92h	08h	Device supplied excess status bytes.	
	92h	09h	Device did not complete command with Command Complete.	
	92h	0Ah	Device skipped MSG OUT phase after Selection.	
92h	0Bh	Device rejected extended ID message.		

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors (continued)	92h	0Ch	Device rejected Initiator Detected Error message.	Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	0Dh	Device rejected Abort message.	
	92h	0Eh	Device rejected Reject message.	
	92h	0Fh	Device rejected NOOP message.	
	92h	10h	Device rejected Parity Error message.	
	92h	11h	Device rejected Bus Device Reset message.	
	92h	12h	Device rejected Identify message.	
	92h	13h	Device went to Bus Free illegally.	
	92h	14h	Device skipped a phase illegally.	
	92h	15h	Device did not return GOOD status to automatic REQUEST SENSE .	
	92h	16h	Queued command requested without disconnect privilege.	This error code is reserved and represents an internal error that should not occur. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	17h	Queued command requested to a target routine.	
	92h	18h	Queued command requested with queuing disabled.	
	92h	19h	Bad IOQB entry submitted to hardware.	This error code is reserved and represents an internal error that should not occur. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	1Ah	Device does not respond—it is powered off, not attached, or non-functional.	Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors (continued)	92h	1Bh	Interface command queue is full.	This error code is reserved and represents an internal error that should not occur. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	1Ch	Device operation did not complete for unknown reason.	Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	1Dh	Device operation was aborted.	
	92h	1Eh	Device operation was aborted with a Bus Device Reset.	
	92h	1Fh	Device operation was aborted with a BUS RESET.	
	92h	20h	Device operation timed out.	This error code is reserved and represents an internal error that should not occur. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	21h	Device operation failed with a parity error.	Reset the F-QIP or RIM and retry the operation. You may also have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	22h	Device operation failed because device never logged in.	This applies only to Fibre Channel initiator interfaces attempting to talk to Fibre Channel targets. Reset the F-QIP or RIM and retry the operation. You may have to reboot the server. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	23h	Device operation failed because device logged out.	
	92h	24h	Device operation failed because device logged in again.	
	92h	25h	Internal control function resulted in error.	This error code is reserved and represents an internal error that should not occur. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors (continued)	92h	26h	CAN sequence error.	<p>This represents an internal error that should not occur when the fibre side of the bridge is communicating with the SCSI side.</p> <ol style="list-style-type: none"> 1. Verify that all library modules are secured to the library frame. 2. If attempting to load code to the QIP or RIM, verify that no external connected systems are trying to communicate with the QIP or RIM. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	92h	27h	Data overrun sequence error.	<p>The command issued had either the wrong data length or an incorrect value for its length. Issuing a SCSI WRITE command with no data also produces this error.</p> <p>Verify that the command being issued is valid. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).</p>
	92h	28h	Data under-run sequence error.	
	92h	29h	Command under-run sequence error.	<p>The command issued had either the wrong CDB length or an incorrect value for its length. Issuing a SCSI WRITE command with no data also produces this error. Verify that the command being issued is valid. If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).</p>
	92h	32h	A QIP/RIM reported a CAN error.	<p>Often indicates an RCM reset during a move..</p> <p>Collect a new inventory.</p>
	99h	01h	Invalid CAN command during code load.	Restart code load.
	99h	02h	Invalid CAN address during code load.	
	99h	03h	Invalid CAN from address during code load.	
	99h	04h	Invalid CAN sequence during code load.	
	99h	05h	Checksum failed during code load.	

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
4h Hardware Errors (continued)	99h	06h	Repeated sequence during code load.	Code load continues.
	99h	07h	Frame error during code load.	
	99h	08h	Burn code to flash failed.	Restart code load.
5h Illegal Request	00h	16h	Operation in progress. The initiator is trying to initiate an additional command to the target device before the first command is complete.	The initiator cannot send more than one tape movement command at a time. 1. Wait for the previous command to complete. 2. Stop all software and reset the devices involved. 3. Verify connectivity of the device before proceeding. 4. Power cycle the device to stop the error; also stop and restart the program, daemon, or services involved.
	1Ah	00h	Parameter list length error.	The number of SCSI mode parameters passed differs from the number required.
	20h	00h	Invalid command code.	The command code received is not supported or not a valid command. Verify that the attempted command is supported, then retry the command.
	21h	01h	Invalid element address.	The command contained an invalid element address for this logical library.
	24h	00h	Invalid field in CDB.	A field in the command descriptor block was not a valid value.
	25h	00h	LUN not supported.	The requested logical unit is not supported.
	26h	00h	Invalid field in parameter list.	A parameter field was sent with an invalid value.
	26h	01h	Parameter not supported.	The parameter in the SCSI CDB is not supported. Verify that the command issued is a valid command.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
5h Illegal Request (continued)	26h	02h	Parameter value invalid.	A parameter in the CDB has a value that is out of range. Verify that the command issued is a valid command.
	26h	06h	Too many target descriptors.	Verify that the command issued is a valid command.
	26h	07h	Unsupported target descriptor type code.	Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	26h	08h	Too many segment descriptors.	
	26h	09h	Unsupported segment descriptor type code.	Verify that the command issued is a valid command.
	26h	0Ah	Unexpected inexact segment.	
	26h	0Bh	Inline data length exceeded.	This code is reserved and represents an internal error that should not occur. Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	26h	0Ch	Invalid operation for copy source or destination.	
	2Ch	00h	Command sequence error. FLASH code download to tape drive via Write Buffer failed.	
	2Eh	03h	Incorrect copy target device type.	Verify the device type of the target device. Also verify the device type being reported by the target device. Only disk and tape are supported devices.
	39h	00h	An attempt was made to save an emulated mode page; saving parameters not supported.	The current command is invalid. Use a valid command.
	3Bh	0Dh	Medium destination is full.	The destination element is full or there is an inventory sensor problem.
	3Bh	0Eh	Medium source element empty.	The source element is empty or there is an inventory sensor problem.
	3Bh	11h	Media magazine not accessible.	The slot location does not contain a magazine. This will only occur in libraries with TeraPack magazines.
	3Dh	00h	Identify message error.	The Identify message had invalid bits set in the message.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
5h Illegal Request (continued)	3Dh	80h	Disconnects must be allowed.	The host must allow SCSI disconnects for this command to complete.
	3Eh	00h	Could not get wrap information from drive.	Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	49h	00h	An attempt was made to issue an ACA Queue command.	The current command is invalid. Use a valid command.
	53h	02h	Media removal prevented.	Another initiator has prevented media from being removed from the library.
	80h	00h	Generic invalid move.	Move is invalid, reason not reportable.
	80h	01h	Picker not empty.	Remove the tape.
	80h	03h	Source magazine not available.	Install/configure magazine.
	80h	04h	Destination magazine not available.	
	80h	05h	Source drive is not available.	Install/configure drive.
	80h	06h	Destination drive is not available.	Install/configure drive.
	80h	07h	The medium source is invalid; no barcode label was detected by the robotic picker.	This error occurs when there are no barcoded tapes in the TAP when running the Picker Slot Calibration Long Axis Test. This test requires at least one barcoded tape in the TAP (any slot) for the diagnostic test to run.
	80h	18h	Element is reserved for front panel.	This occurs when the slot is reserved by the front panel for queued ejects. See Overview of T120 and T50e Entry/Exit Modes on page 95 . Re-issue command after the reservation is cancelled.
	81h	00h	Duplicate SCSI ID on this bus.	All SCSI IDs on a SCSI bus must be unique. Verify the SCSI ID's of all devices. The host system bus may have to be rebooted/reset for the new ID to be accessible.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
5h Illegal Request (<i>continued</i>)	81h	01h	TAP is Exit Only.	With Queued Unloads enabled, the TAP is Exit Only. It can export tapes but not import them. 1. If you want to use the software to import tapes from the TAP to the storage slots, you must disable the Queued Unloads option. 2. In a multi-partition library, you must manually load the tapes, using the front panel Library Controller for single-tape or bulk loading.
	81h	02h	Library is full of tapes; no more tapes may be loaded.	Unload tapes from the library and retry the operation.
	81h	03h	Cannot move tape from drive to TAP with Queued Unloads enabled.	This error is reported if the software attempts to move a tape from a drive to the TAP when Queued Unloads is enabled AND when the source slot is not an actual storage slot. Possible initial source slot moves that cause this error include moving a tape to a drive from the TAP, or moving a tape from another drive and then having the software attempt to move the tape to the TAP. If you moved a tape from a slot to a drive and then have the software move the tape to the TAP, the tape is unloaded and moved to its original slot, and then set for Queued Unloads.
	81h	10h	Unable to insert tape. The TAP is Exit Only.	Disable the Queued Unload option and retry the move.
	89h	24h	Library is full of tapes.	Remove some tapes so the drives can be unloaded.
	6h Unit Attention	28h	00h	Inventory possibly altered.
28h		01h	Door element accessed.	A tape was moved to or from the TAP.
29h		00h	A reset has occurred.	The library has been reset or powered on.

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
6h Unit Attention (continued)	29h	80h	Drive failed power-on self test (POST) or user issued diagnostic test. This is a Sony-unique error code.	<p>1. Power cycle the tape drive. (Open the library door, pull and reseal the drive, then close the library door and wait for the robot to fully initialize.)</p> <p>2. Select the Status button from the main screen of the Library Controller.</p> <p>If the problem persists, contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).</p>
	2Ah	01h	Mode parameters have changed.	The library's mode parameters have been modified.
	2Fh	00h	Commands aborted; cleared by another initiator.	Contact Spectra Logic Technical Support (see Contacting Spectra Logic on page 7).
	3Fh	01h	New firmware was loaded successfully.	<p>The library's inquiry data has changed. Treat the library as a new device. A full device discovery from the host side may be necessary.</p> <p>Some backup software does not handle firmware upgrades very well. Consult with your backup software vendor.</p>
	3Fh	03h	<p>The device's inquiry data has changed.</p> <p>A new tape library inquiry data was configured for the device.</p>	<p>It is possible that the device has been hot-swapped or that a new configuration has been saved. Treat this as a new device. A full device discovery from the host side may be necessary.</p> <p>Some backup software does not handle hot-swapping of devices very well. Consult with your backup software vendor.</p>

Sense Key	ASC	ASCQ	Error Description	Explanation or Error Remedy
9h Vendor-Specific	83h	00h	Barcode label is unread.	Reading this barcode label has not yet been attempted.
	83h	01h	Problem reading barcode label.	This barcode label could not be read.
	83h	02h	Tape is queued for unload.	This tape can only be moved by the front panel.
	84h	01h	No response from SCSI target.	SCSI target failed to respond. Check SCSI bus connections and device power.
	84h	02h	Check unexpected condition from target.	Serial SCSI command failed. Issue a REQUEST SENSE and examine the SCSI sense data to find the cause.

INDEX

A

- Additional Sense Code Qualifiers (ASCQ) 129 to 143
- Additional Sense Codes (ASC) 129 to 143
- address, default
 - data transfer element 45, 54
 - import/export element 45, 54
 - medium transport element 45, 54, 124
 - storage element 45, 54
- ASC/ASCQ for CDB
 - GTAOS command 24
 - INITIALIZE ELEMENT STATUS command 26
 - INQUIRY command 40
 - MODE SELECT command 47
 - MODE SENSE command 58
 - MOVE MEDIUM CDB 61
 - PREVENT/ALLOW MEDIUM REMOVAL command 64
 - READ BUFFER command 67
 - READ ELEMENT STATUS command 100, 107
 - RELEASE CDB 103
 - REQUEST SENSE command 111
 - RESERVE command 116, 125
 - RTAOS command 122
 - TEST UNIT READY command 127
- ASC/ASCQ, associated with
 - Hardware Error (4h) sense key 130 to 138
 - Illegal Request (5h) sense key 138 to 141
 - No Sense (0h) sense key 129
 - Not Ready (2h) sense key 129
 - Unit Attention (6h) sense key 141 to 142
 - Vendor Specific (9h) sense key 143

B

- barcode information, requesting 71
- bus, definition 15
- Busy status, definition 18

C

- cartridge slots
 - default element address 45, 54
 - See also* storage element
- Check Condition status, definition 18
- command descriptor block (CDB) 16
- commands
 - common field definitions 16
 - GTAOS (A4h) 19 to 24
 - INITIALIZE ELEMENT STATUS (07h) 25 to 26
 - INITIALIZE ELEMENT STATUS WITH RANGE (37h or E7h) 27
 - INQUIRY (12h) 28 to 40
 - MODE SELECT (15h) 41 to 47
 - MODE SENSE (1Ah or 5Ah) 49 to 58
 - MOVE MEDIUM (A5h) 59 to 62
 - PREVENT/ALLOW MEDIUM REMOVAL (1Eh) 63 to 64
 - READ BUFFER (3Ch) 65
 - READ ELEMENT STATUS (B8h) 68 to 100
 - RELEASE (17h) 101 to 103
 - REPORT LUNS (A0h) 104 to 106
 - REQUEST SENSE (03h) 108 to 111
 - RESERVE (16h) 112 to 116
 - RTAOS (A3h) 117 to 122

- commands (*continued*)
 - SEND DIAGNOSTIC (1Dh) 123 to 125
 - supported formats 16
 - TEST UNIT READY (00h) 126 to 127
 - See also* individual command entries

- contacting Spectra Logic 7
- Control byte, definition 17
- corporate headquarters, Spectra Logic 7

D

- data transfer element
 - descriptor format 84, 85
 - MODE SENSE command 45, 54
 - number of elements 45, 54
 - READ ELEMENT STATUS command 84 to 89
 - starting element address, default 45, 54
- default element addresses 45, 54
- descriptor
 - data transfer element 84, 85
 - element list 114
 - import/export element 91
 - medium transport element 76
 - storage element 80
- Device Identification Page, returned by INQUIRY command 36 to 37
- diagnostics supported by SEND DIAGNOSTICS command 124
- documentation
 - related to drive use 13
 - typographical conventions 14
- drives, general information
 - related documentation 13

E

Element Address Assignment
page, MODE SELECT and
MODE SENSE 44 to 45, 52 to 54

element addresses
defaults 45, 54, 124
definition 16

element list
descriptors 114

elements
data transfer, number of 45,
54
default addresses 45, 54
definitions 16
import/export, number of 45,
54
medium transport, number
of 45, 54, 124
releasing reserved 101
status returned by READ
ELEMENT STATUS
command 74 to 93
storage elements, number
of 45, 54

email
Spectra Logic offices 7

entry/exit, *See* import/export
element

error code data, preserved by
library 109

error codes, ASC/ASCQ for
Hardware Error (4h) sense
key 130 to 138
Illegal Request (5h) sense
key 138 to 141
No Sense sense key 129
Not Ready sense key 129
Unit Attention (6h) sense
key 141 to 142
Vendor Specific (9h) sense
key 143

error codes, sense key
definitions 128

F

fax numbers, Spectra Logic 7

Fibre Channel commands
REPORT LUNS 104

firmware revision level, in
Standard Inquiry Data 33

Flag bit, not supported 17

G

Good status
definition 18
in response to TEST UNIT
READY command 126

GTAOS (A4h) command
CDB errors reported 24
description 19
field definitions 20
Logical Block Address
Descriptor 22
parameter list 20
status reporting 23
use 19 to 24

H

Hardware Error (4h) sense key
associated ASC/
ASCQ 130 to 138
definition 128

I

identification
product, on INQUIRY Device
Identification page 37, 39
product, Standard Inquiry
Data 33
vendor, in Standard Inquiry
Data 32
vendor, on INQUIRY Device
Identification page 37, 39

Illegal Request (5h) sense key
associated ASC/
ASCQ 138 to 141
definition 128

import/export element
default address 45, 54
default element address 45,
54
definition 16
medium removal 63
READ ELEMENT STATUS
command 91 to 93

INITIALIZE ELEMENT STATUS
(07h) command
CDB errors reported 26
description 25
status reporting 26
use 25 to 26

INITIALIZE ELEMENT STATUS
WITH RANGE (37h or E7h)
command 27

initiator, definition 15

INQUIRY (12h) command
CDB errors reported 40
description 28
Device Identification
Page 36 to 37
field definitions 29
Standard Inquiry Data
page 30 to 33
status reporting 40
Supported Vital Products Data
Page 33
TAOS Serial Number
Association Page 38 to 39
Unit Serial Number Page 35
use 28 to 40

L

library
definition 15
ready for commands 126

license agreement, software 3

linked commands, not
supported 17

Logical Block Address Descriptor,
GTAOS 22

logical library, definition 15

Logical Unit Number (LUN),
definition 17

M

- magazine slots, *See* cartridge slots
 - mailing address, Spectra Logic 7
 - medium transport element
 - default element address 45, 54, 124
 - definition 16
 - status returned by READ ELEMENT STATUS command 76 to 77
 - medium transport element, definition 76
 - mode parameters
 - reloading using MODE SELECT command 41 to 45, 50, 52 to 54
 - returned by MODE SENSE command 51 to 57
 - setting using MODE SELECT command 41 to 45, 50, 52 to 54
 - MODE SELECT (15h) command
 - CDB errors reported 47
 - default element addresses 45, 54, 124
 - description 41
 - Element Address Assignment Page 44 to 45, 52 to 54
 - field definitions 42
 - parameter list 43
 - setting operating parameters 41 to 45, 52 to 54
 - status reporting 46
 - use 41 to 47
 - MODE SENSE (1Ah or 5Ah) command
 - CDB errors reported 58
 - CDB field definitions 50 to 51
 - description 49
 - Device Capabilities Page 56 to 57
 - Element Address Assignment Page 44 to 45, 52 to 54
 - Parameter List Header 51, 52
 - reporting operating parameters 51 to 57
 - status reporting 58
 - MODE SENSE (1Ah or 5Ah) command (*continued*)
 - Transport Geometry Descriptor Page 55
 - use 49 to 58
 - MOVE MEDIUM (A5h) command
 - CDB errors reported 61
 - description 59
 - errors reported 61
 - field definitions 60
 - status reporting 60
 - use 59 to 62
-
- N**
- No Sense (0h) sense key
 - associated ASC/ASCQ 129
 - definition 128
 - Not Ready (2h) sense key
 - associated ASC/ASCQ 129
 - definition 128
-
- O**
- Obsolete, field definition 17
 - operating mode
 - configurable parameters 41, 43
-
- P**
- Parameter List, GTAOS 119 to 121
 - parameters
 - configured by MODE SELECT command 41, 43
 - GTAOS command 20
 - returned by MODE SENSE command 51 to 57
 - set by MODE SELECT command 41 to 45, 52 to 54
 - setting using MODE SELECT command 50
 - partition, definition 15
 - phone numbers, Spectra Logic offices 7
-
- PREVENT/ALLOW MEDIUM REMOVAL (1Eh) command**
- CDB errors reported 64
 - CDB field definitions 63
 - status reporting 64
 - use 63 to 64
- product identification**
- in Standard Inquiry Data 33
 - on INQUIRY Device Identification page 37, 39
- PYTHON**
- in Standard Inquiry Data 33
 - on INQUIRY Device Identification page 37, 39
-
- R**
- READ BUFFER (3Ch) command**
- CDB errors reported 67
 - field definitions 66
 - status reporting 67
 - use 65
- READ ELEMENT STATUS (B8h) command**
- CDB errors reported 100, 107
 - CDB field definitions 71 to 72
 - data transfer element descriptor 84 to 89
 - description 68
 - element status reporting 74 to 93
 - field definitions 71
 - import/export element descriptor 91 to 93
 - medium transport element descriptor 76 to 77
 - requesting barcode information 71
 - status reporting 100, 107
 - storage element descriptor 80 to 82
 - use 68 to 100
- RELEASE (17h) command**
- CDB errors reported 103
 - CDB field definitions 102
 - description 101
 - status reporting 102
 - use 101 to 103

-
- REPORT LUNS (A0h) command
 status reporting 104
 use 104 to 106
- reporting errors, ASC and ASCQ data 129 to 143
- reporting errors, sense keys 128
- REQUEST SENSE (03h) command
 ASC and ASCQ data
 returned 129 to 143
 CDB errors reported 111
 sense data returned 109
 sense keys returned 128
 status reporting 111
 use 108 to 111
- Reservation Conflict status
 definition 18
 RELEASE command 101
- reservations
 conflicts 101, 112
 release using RELEASE command 101
 using RESERVE command 112
- RESERVE (16h) command
 CDB errors reported 116, 125
 CDB field definitions 113
 status reporting 114
 use 112 to 116
- Reserved, field definition 17
- robot, *See* medium transport element
- RTAOS (A3h) command
 CDB errors reported 122
 description 117
 field definitions 118
 status reporting 121
 use 117 to 122
- RTAOS (A4h) command
 Parameter List 119 to 121
-
- S**
- sales, contacting 7
- SCSI commands, *See* commands
- SEND DIAGNOSTIC (1Dh) command
 CDB field definitions 124
 description 123
 use 123 to 125
- sense data, returned by REQUEST SENSE command 110
- sense keys 128
 definitions 128
 Hardware Error (4h) 128
 Illegal Request (5h) 128
 No Sense (0h) 128
 Not Ready (2h) 128
 returned by REQUEST SENSE command 128
 Unit Attention (6h) 128
 unsupported 129
 Vendor Specific (9h) 128
- software
 license agreement 3
- SPECTRA
 vendor identification in Standard Inquiry Data 32
 vendor identification on INQUIRY Device Identification page 37, 39
- Spectra Logic
 contacting 7
 manuals, obtaining 13
- Spectra tape libraries
 product identification on INQUIRY Device Identification page 37, 39
 product identification, Standard Inquiry Data 33
- Standard Inquiry Data
 page format 30
 returned by INQUIRY command 30 to 33
- status
 data transfer elements 84 to 89
 Element Status page format 74
 import/export elements 91 to 93
 medium transport element 76 to 77
 Reservation Conflict 101
 returned by REQUEST SENSE command 111
 returned by RESERVE command 114
 returned by SEND DIAGNOSTIC command 125
- status (*continued*)
 returned by TEST UNIT READY command 126
 storage elements 80 to 82
 status byte, definitions 18
 status returned by
 GTAOS (A4h) command 23
 INITIALIZE ELEMENT STATUS command 26
 INQUIRY command 40
 MODE SELECT command 46
 MODE SENSE command 58
 MOVE MEDIUM command 60
 PREVENT/ALLOW MEDIUM REMOVAL command 64
 READ BUFFER command 67
 READ ELEMENT STATUS command 100, 107
 REPORT LUNS command 104
 RTAOS (A3h) command 121
 storage elements
 default address 45, 54
 definition 16
 number of elements 45, 54
 reported by READ ELEMENT STATUS command 80 to 82
 starting element address, default 45, 54
 Supported Vital Product Data Page 33
-
- T**
- TAOS Serial Number Association Page, returned by INQUIRY command 38 to 39
- tape cartridges, prevent/allow removal 63
- tape drives, *See* data transfer element
- target, definition 15
- technical support
 contacting 7

TEST UNIT READY (00h)
command
 CDB errors reported 127
 description 126
 status reporting 126
 use 126 to 127
tests, diagnostics supported by
 SEND DIAGNOSTICS
 command 124
transporter, *See* medium transport
 element
typographical conventions 14

U

Unit Attention (6h) sense key
 associated ASC/
 ASCQ 141 to 142
 definition 128
Unit Serial Number Page, returned
 by INQUIRY command 35
unsupported sense keys 129

V

vendor identification in Standard
 Inquiry Data 32
vendor identification, on INQUIRY
 Device Identification page 37,
 39
Vendor Specific (9h) sense key
 associated ASC/ASCQ 143
 definition 128

W

website
 obtaining Spectra Logic
 manuals 13
 Spectra Logic 7